

COSORI

User Manual

Original 3.5-Litre Air Fryer

Model: CO137-AF



Questions or Concerns?

support.eu@cosori.com

Table of Contents

Package Contents	2
Specifications	2
Important Safeguards	4
Getting to Know Your Air Fryer	6
Before First Use	7
• Setting Up	7
• Test Run	8
• Basket Tips	8
Using Your Air Fryer	9
• Preheating	9
• Air Frying	9
• Shaking Food	11
• Cooking Guide	12
Care & Maintenance	13
Accessories	13
Troubleshooting	14
Warranty Information	15
Customer Support	15

Package Contents

- 1 x Original 3.5-Litre Air Fryer
- 1 x Recipe Book
- 1 x Quick Reference Guide
- 1 x User Manual

Specifications

Power Supply	AC 220–240V, 50/60Hz
Rated Power	1500W
Capacity	3.5 L / 3.7 qt (serves 2–3 people)
Temperature Range	80°–205°C
Time Range	1–60 min
Dimensions	33.9 x 27.3 x 31.1 cm / 13.3 x 10.7 x 12.2 in
Weight	4.6 kg / 10.1 lb

 *Thank you for
your purchase!* 

(We hope you love your new air fryer as much as we do.)



join

the Cosori Cooks Community on Facebook
[facebook.com/CosoriUK](https://www.facebook.com/CosoriUK)



explore

our recipe gallery
www.cosori.com/recipes



enjoy

weekly, featured recipes
made exclusively by our in-house chefs



CONTACT OUR CHEFS

Our helpful, in-house chefs are ready to assist you with any questions you might have!

Email: recipes@cosori.com


On behalf of all of us at Cosori,

Happy cooking!


IMPORTANT SAFEGUARDS

Follow basic safety precautions when using your air fryer. Read all instructions.

Key Safety Points




Do not touch hot surfaces.
Use handle.



Only press the basket release button with the baskets resting flat on a counter or any level, heat-resistant surface.

The handle is attached to the inner basket, not the outer basket. When you press the basket release button, the outer basket will **drop**.



Do not block any ventilation openings. Hot steam is released through openings. Keep your hands and face clear of openings.

General Safety

- **Do not** immerse the air fryer housing or plug in water or liquid.
- Closely supervise children near your air fryer.
- Unplug when not in use, and before cleaning. Allow to cool before putting on or taking off parts.
- **Do not** use your air fryer if it is damaged, not working, or if the cord or plug is damaged. Contact **Customer Support** (see page 15).
- **Do not** use third-party replacement parts or accessories, as this may cause injuries.
- **Do not** use outdoors.
- **Do not** place the air fryer or any of its parts on a stove, near gas or electric burners, or in a heated oven.
- Be extremely cautious when moving your air fryer (or removing the baskets) if it contains hot oil or other hot liquids.
- **Do not** clean with metal scouring pads. Metal fragments can break off the pad and touch electrical parts, creating a risk of electric shock.
- **Do not** place anything on top of your air fryer.
- **Do not** store anything inside your air fryer.
- **Only** use your air fryer as directed in this manual.
- Not for commercial use. Household use **only**.

While Air Frying

- An air fryer works with hot air **only**. **Never** fill the baskets with oil or fat.
- **Never** use your air fryer without the baskets in place.
- **Do not** place oversized foods or metal utensils into your air fryer.
- **Do not** place paper, cardboard, non-heat-resistant plastic, or similar materials into your air fryer. You may use parchment paper or foil.
- **Never** put baking or parchment paper into the air fryer without food on top. Air circulation can cause paper to lift and touch heating coils.
- **Always** use heat-safe containers. Be extremely cautious if using containers that aren't metal or glass.
- Keep your air fryer away from flammable materials (curtains, tablecloths, etc). Use on a flat, stable, heat-resistant surface away from heat sources or liquids.
- Immediately turn off and unplug your air fryer if you see dark smoke coming out. White smoke is normal, caused by heating fat or food splashing,


but dark smoke means that food is burning or there is a circuit problem. Wait for smoke to clear before pulling the baskets out. If the cause was not burnt food, contact **Customer Support** (page 15).

- **Do not** leave your air fryer unattended while in use.

Plug and Cord

- **Do not** let the power cord (or any extension cord) hang over the edge of a table or counter, or touch hot surfaces.

Note: This air fryer uses a short power-supply cord to reduce the risk of entangling or tripping. Use extension cords with care. The marked electrical rating of the extension cord must be as great as the rating of the air fryer (see page 2).



Electromagnetic Fields (EMF)

The Cosori Air Fryer complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user manual, the appliance is safe to use based on scientific evidence currently available.

**SAVE THESE
INSTRUCTIONS**

GETTING TO KNOW YOUR AIR FRYER


Your Cosori Air Fryer uses rapid 360° air circulation technology to cook with little-to-no oil, for quick, crispy, delicious food with up to 85% fewer calories than deep fryers. With simple dials, nonstick baskets, and an intuitive, safe design, the Cosori Air Fryer is the star of your kitchen.



Note:

- **Do not** try to open the top of the air fryer. It is not a lid.
- The baskets are made of aluminium metal with nonstick coating. They are PFOA-free and BPA-free.

Air Fryer Diagram



- A.** Air Outlet
- B.** Air Inlet
- C.** Housing Handles
- D.** Power Cord
- E.** Power Indicator

- F.** Temperature Indicator
- G.** Temperature Dial
- H.** Timer Dial
- I.** Inner Basket
- J.** Sliding Button Guard

- K.** Basket Release Button
- L.** Basket Handle
- M.** Outer Basket

BEFORE FIRST USE

Setting Up

1. Remove all packaging from the air fryer, including any temporary stickers.
2. Place the air fryer on a stable, level, heat-resistant surface. Keep away from areas that can be damaged by steam (such as walls or cupboards).

Note: Leave 13 cm / 5 in of space behind and above the air fryer. [Figure 1.1] Leave enough room to remove the baskets.

3. Pull the handle to remove the baskets. Remove all plastic from the baskets.
4. Press the basket release button to separate the inner basket from the outer basket. [Figure 1.2–1.3]
5. Wash both baskets thoroughly, using either a dishwasher or a non-abrasive sponge.
6. Wipe the inside and outside of the air fryer with a slightly moist cloth. Dry with a towel.
7. Put the baskets back inside the air fryer.




Figure 1.1




Figure 1.2




Figure 1.3

Test Run

A test run will help you become familiar with your air fryer, make sure it's working correctly, and clean it of possible residues in the process.

1. Make sure the air fryer baskets are empty and plug in the air fryer.
2. Turn the temperature dial to 205°C.
3. Turn the timer dial past the 10 minute mark until the power indicator turns on. The power indicator and temperature indicator will turn on, indicating the air fryer is heating up. Then, turn it back to 5 minutes to begin preheating.
4. When the air fryer has finished preheating, the temperature indicator will turn off.
5. Pull out the baskets and let them cool for 5 minutes. Then, place the empty baskets back in the air fryer.
6. Make sure the temperature dial is set to 205°C.
7. Turn the timer dial past the 10 minute mark until the power indicator turns on. Then, turn it back to 5 minutes. The air fryer will start automatically.
8. The air fryer will chime when finished. Pull out the baskets and let them cool completely for 10–30 minutes.

Basket Tips

- **Only** separate the baskets to clean or after cooking.
- The button guard protects the basket release button from being pressed accidentally. Slide the button guard forward to press the basket release button.
- **Never** press the basket release button while carrying the baskets.
- **Only** press the basket release button with the baskets resting on a counter, or any level, heat-resistant surface.
- The handle is attached to the inner basket, not the outer basket. When you press the basket release button, the outer basket will **drop**.

Note:

- **Do not** unscrew the basket handle from the baskets.
- To order accessories, please contact **Customer Support** (see page 15).

USING YOUR AIR FRYER

Preheating

We recommend preheating for 5 minutes before placing food inside the air fryer, unless your air fryer is already hot. Food will not cook thoroughly without preheating.

1. Plug in.
2. Turn the temperature dial to at least 80°C.
3. Turn the timer dial past the 10 minute mark until the power indicator turns on. The power indicator and temperature indicator will turn on, indicating the air fryer is heating up. Then, turn the timer dial back to 5 minutes to begin preheating.
4. Once the temperature indicator turns off, the air fryer has finished preheating.

Air Frying

Note:

- **Do not** place anything on top of your air fryer. This will disrupt airflow and cause poor air frying results. [Figure 2.1]
- An air fryer is not a deep fryer. **Do not** fill the baskets with oil, frying fat, or any liquid.
- When taking the baskets out of the air fryer, be careful of hot steam, and **do not** press the basket release button.

1. Preheat your air fryer (see page 9).
2. When the temperature light turns off, add food to the baskets.
3. Turn the temperature dial to set the temperature.
4. Turn the timer dial to set the time. The air fryer will start automatically.

Note:

- If you need to set the time for less than 10 minutes, first turn the timer dial past 10 minutes. Then turn to the desired time.
- Shake food halfway through cooking to make sure your food cooks evenly.
- The timer will continue counting down even if the baskets are taken out.
- You may adjust the time and temperature anytime during cooking.

Air Frying (cont.)

5. The air fryer will chime when finished.
6. Take the baskets out of the air fryer, being careful of hot steam.
7. Remove the inner basket from the outer basket to serve food. When separating baskets:
 - a. Make sure the baskets are resting on a flat surface.
 - b. Watch for hot oil or fat collected in the outer basket. [Figure 2.2] To avoid splashing, drain oil before replacing inner basket.
8. Allow to cool before cleaning.




Figure 2.1



Figure 2.2

Automatic Shutoff

The air fryer will automatically shut off when the timer is complete.

Note: To shut off the air fryer manually, turn the timer dial counterclockwise to 0.

Shaking Food

How to Shake

During cooking, take the baskets out of the air fryer and shake, mix, or flip the food.

A. To shake food:

1. Hold the baskets just above a heat-resistant surface for safety purposes. **Do not** press the basket release button. [Figure 2.3]
2. Shake the baskets.

B. If the baskets are too heavy to shake:

1. Place the baskets on a heat-resistant holder or surface.
2. Separate the baskets. Make sure no liquids are dripping from the inner basket.
3. Carefully shake the inner basket.

Note: **Do not** use this method if there is a risk of hot liquids splashing.

C. If the baskets are too heavy to shake and there are hot liquids present:

1. Place the baskets on a heat-resistant holder or surface.
2. Use tongs to mix or flip the food.

Note:

- When you take the baskets out, the air fryer will pause heating.
- When you replace the baskets, heating will automatically resume.
- Avoid shaking longer than 30 seconds, as the air fryer may start to cool down.
- The timer will continue counting down even when the baskets are taken out.

What to Shake

- Small foods that are stacked will usually need shaking, such as fries or nuggets.
- Without shaking, foods may not be crispy or evenly cooked.
- You can flip other foods, such as steak, to ensure even browning.

When to Shake

- Shake or flip food once halfway through cooking, or more if desired.




Figure 2.3

Cooking Guide

Overfilling

- If the basket is overfilled, food will cook unevenly. [Figure 2.4]
- Food should not be filled over the “MAX” line of the inner basket. [Figure 2.5]
Do not pack in food.



Figure 2.4



Figure 2.5

Using Oil

- Adding a small amount of oil to your food will make it crispier. Use no more than 30 mL / 2 US tbsp of oil.
- Oil sprays are excellent for applying small amounts of oil evenly to all food items.

Food Tips

- You can air fry any frozen foods or goods that can be baked in an oven.
- To make cakes, hand pies, or any food with filling or batter, place food in a heat-safe container before placing in the baskets.
- Air frying high-fat foods will cause fat to drip to the bottom of the baskets. To avoid excess smoke while cooking, pour out fat drippings after cooking.
- Liquid-marinated foods create splatter and excess smoke. Pat these foods dry before air frying.

French Fries

- Add 8–15 mL / ½–1 US tbsp of oil for crispiness.
- When making fries from raw potatoes, soak uncooked fries in water for 15 minutes to remove starch prior to frying. Pat dry with a towel before adding oil.
- Cut uncooked fries smaller for crispier results. Try cutting fries into 0.6- by 7.6-cm / ¼- by 3-inch strips.

Note: For more from the Cosori Kitchen, check out our *Recipe Book and Tips from the Chef*.

CARE AND MAINTENANCE

Note:

- **Always** clean the air fryer baskets and interior after every use.
 - Lining the outer basket with foil may make cleanup easier.
1. Turn off and unplug the air fryer. Allow it to cool completely before cleaning. Pull out the baskets for faster cooling.
 2. Wipe the outside of the air fryer with a moist cloth, if necessary.
 3. The baskets are dishwasher safe. You can also wash the baskets with hot, soapy water and a non-abrasive sponge. Soak if necessary.

Note: The baskets have a nonstick coating. Avoid using metal utensils and abrasive cleaning materials.

4. For stubborn grease:
 - a. In a small bowl, mix 118 mL / ½ US cup of baking soda and a few tablespoons of water (15 mL / 1 US tbsp) to form a spreadable paste.
 - b. Use a sponge to spread the paste on the baskets and scrub. Let the baskets sit for 15 minutes before rinsing.
 - c. Wash baskets with soap and water before using.

5. Clean the inside of the air fryer with a slightly moist, non-abrasive sponge or cloth. **Do not** immerse in water. [Figure 3.1] If needed, clean the heating coil to remove food debris.
6. Dry before using.

Note: Make sure the heating coil is completely dry before turning on the air fryer.




Figure 3.1

ACCESSORIES

You can purchase more accessories for your air fryer from **Amazon** by searching for “**B07MG3FG44**” or by scanning the QR code.

If you have any questions, please contact **Customer Support** (see page 21).



TROUBLESHOOTING

Problem	Possible Solution
The air fryer will not turn on.	Make sure the air fryer is plugged in.
	Push the baskets securely into the air fryer.
Foods are not completely cooked.	Place smaller batches of food items into the inner basket. If the basket is overstuffed, then foods will be undercooked.
	Increase cooking temperature or time.
Foods are cooked unevenly.	Foods that are stacked on top of each other or close to each other need to be shaken or flipped during cooking (see Shaking Food , page 11).
Foods are not crispy after air frying.	Spraying or brushing a small amount of oil on foods can increase crispiness (see Cooking Guide , page 12).
French fries are not cooked correctly.	See French Fries , page 12.
Baskets will not slide into the air fryer securely.	Make sure the inner basket is not overfilled with food.
	Make sure the inner basket is securely inside the outer basket.
White smoke is coming out of the air fryer.	The air fryer may produce some white smoke when you use it for the first time. This is normal.
	Make sure the baskets and the inside of the air fryer are cleaned properly and not greasy.
	Cooking greasy foods will cause oil to leak into the outer basket. This oil will produce white smoke, and the baskets may be hotter than usual. This is normal, and should not affect cooking. Handle baskets with care.
Dark smoke is coming out of the air fryer.	Immediately unplug your air fryer. Dark smoke means that food is burning or there is a circuit problem. Wait for smoke to clear before pulling the baskets out. If the cause was not burnt food, contact Customer Support (page 15).
The air fryer has a plastic smell.	Any air fryer may have a plastic smell from the manufacturing process. This is normal. Follow the instructions for a Test Run (page 8) to get rid of the plastic smell. If a plastic smell is still present, please contact Customer Support (see page 15).

If your problem is not listed, please contact **Customer Support** (see page 15).

WARRANTY INFORMATION

Arovast Corporation warrants all products to be of the highest quality in material, craftsmanship, and service for 2 years, effective from the date of purchase to the end of the warranty period. Warranty lengths may vary between product categories.

If you have any questions or concerns about your new product, please contact our helpful Customer Support Team.

CUSTOMER SUPPORT

Arovast Corporation

1202 N. Miller St., Suite A
Anaheim, CA 92806
USA

Email: support.eu@cosori.com

*Please have your order invoice and order ID ready before contacting Customer Support.

SHOW US WHAT YOU'RE MAKING

We hope this has been helpful to you. We can't wait to see your beautiful results, and we think you'll want to share glam shots! Our community awaits your uploads—just pick your platform of choice below. Snap, tag, and hashtag away, Cosori chef!

#iCookCosori



@cosoricooks



Cosori Appliances

Considering what to cook? Many recipe ideas are available, both from us and the Cosori community.

MORE COSORI PRODUCTS

If you're happy with this air fryer, the line doesn't stop here. Check out www.cosori.com for a line of all our beautiful and thoughtfully designed cookware. They might be right at home in your kitchen, too!

COSORI

Questions or Concerns?

support.eu@cosori.com

JJ0220CY-M1_0120CO137-AF_uk