

# OUTDOOR PATIO HEATER

ZCV-2650-SS ZCV-2650-AB ZCV-2650-SV



#### If you smell gas:

- 1. Shut off gas to the appliance.
- 2. Extinguish any open flame.
- 3. If odor continues, keep away from the appliance and immediately call your gas supplier or fire department.

### WARNING

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance. An LP-cylinder not connected for use shall not be stored in the vicinity of this or any other appliance.

### **WARNING:** For Outdoor Use Only




#### **⚠** DANGER



CARBON MONOXIDE HAZARD
This appliance can produce
carbon monoxide which has
no odor. Using it in an enclosed
space can kill you. Never use this
appliance in an enclosed space
such as a camper, tent, car or
home.

### **WARNING**

Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury or death. Read the installation, operation and maintenance instructions thoroughly before installing or servicing this equipment.











ANS Z83.26-2014 • CSA 2.37-2014 Gas-Fired Outdoor Infrared Patio Heaters



| PART | DESCRIPTION           | QUANTITY |
|------|-----------------------|----------|
| Α    | Reflector Panel       | 1        |
| В    | Head Assembly         | 1        |
| С    | Cylinder Housing      | 1        |
| D    | Door (preassembled)   | 1        |
| E    | Post                  | 1        |
| F    | Gas Hose              | 1        |
| G    | Regulator             | 1        |
| Н    | Bucket (preassembled) | 1        |
| I    | Wheel Kit             | 2        |
| J    | Base                  | 1        |



Please read and understand this entire manual before attempting to assemble, operate or install the product.

This manual contains important information about the assembly, operation and maintenance of this patio heater. General safety information is presented in these first few pages and is also located throughout the manual. Keep this manual for future reference and to educate new users of this product. This manual should be read in conjunction with the labeling on the product. Safety precautions are essential when any mechanical or propane-fueled equipment is involved. These precautions are necessary when using, storing, and servicing this item. Using this equipment with the respect and caution demanded will reduce the possibilities of personal injury or property damage. The following symbols shown below are used extensively throughout this manual. Always heed these precautions, as they are essential when using any mechanical or fueled equipment.

# **A** DANGER

Failure to comply with the precautions and instructions provided with this heater can result in death, serious bodily injury and property loss or damage from hazards of fire, explosion, burn, asphyxiation, and/or carbon monoxide poisoning. Only persons who can understand and follow the instructions should use or service this heater.

# DANGER

#### FOR YOUR SAFETY

If you smell gas:

- 1. Shut off gas to the appliance.
- 2. Extinguish any open flame.
- 3. If odor continues, keep away from the appliance and immediately call your gas supplier or fire department.

# **DANGER**

- EXPLOSION FIRE HAZARD
- Keep solid combustibles, such as building materials, paper or cardboard, a safe distance away from the heater as recommended by the instructions.
- Provide adequate clearances around air openings into the combustion chamber.
- Never use the heater in spaces that do or may contain volatile or airborne combustibles, or products such as gasoline, solvents, paint thinner, dust particles or unknown chemicals.
- During operation, this product can be a source of ignition. Keep heater area clear and free from combustible materials, gasoline, paint thinner, cleaning solvents and other flammable vapors and liquids. Do not use heater in areas with high dust content.

  Minimum heater clearances from combustible materials: three (3) feet from the sides and two (2) feet from the top.

# **DANGER**

- CARBON MONOXIDE HAZARD
- This heater is a combustion appliance. All combustion appliances produce carbon monoxide (CO) during the combustion process. This product is designed to produce extremely minute, non-hazardous amounts of CO if used and maintained in accordance with all warnings and instructions. Do not block air flow into or out of the heater.
- Carbon Monoxide (CO) poisoning produces flu-like symptoms, watery eyes, headaches, dizziness, fatigue and possibly death. You can't see it and you can't smell it. It's an invisible killer. If these symptoms are present during operation of this product get fresh air immediately!
- For outdoor use only.
- Never use inside house, or other unventilated or enclosed areas.
- This heater consumes air (oxygen). Do not use in unventilated or enclosed areas to avoid endangering your life.

# **A** DANGER

- EXPLOSION FIRE HAZARD
- Never store propane near high heat, open flames, pilot lights, direct sunlight, other ignition sources or where temperatures exceed 120°F.
- Propane vapors are heavier than air and can accumulate in low places. If you smell gas, leave the area immediately.
- Never install or remove propane cylinder while heater is lighted, near flame, pilot lights, other ignition sources or while heater is hot to touch.
- This heater is red hot during use and can ignite flammables too close to the burner. Keep flammables at least 3 feet from sides and 2 feet from top. Keep gasoline and other flammable liquids and vapors well away from heater.
- Store the propane cylinder outdoors in a well ventilated space out of reach of children. Never store the propane cylinder in an enclosed area (house, garage, etc.). If heater is to be stored indoors, disconnect the propane cylinder for outdoor storage.

# **M** WARNING

We cannot foresee every use that may be made of our heaters.

Check with your local fire safety authority if you have questions about heater use.

Other standards govern the use of fuel gases and heat producing products for specific uses. Your local authorities can advise you about these.

If no local codes exist, follow National Fuel Gas Code, ANS Z223.1. In Canada, installation must conform to local codes. If no local codes exist, follow the current National standards of CANADA CAN/CGA-B 149.2.

# WARNING

California Proposition 65

Combustion by-products produced when using this product contain chemicals known to the state of California to cause cancer, birth defects, and other reproductive harm.

# **MARNING**

#### **BURN HAZARD**

- Never leave heater unattended when hot or in use.
- · Keep out of reach of children.

# **MARNING**

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance. An LP-cylinder not connected for use shall not be stored in the vicinity of this or any other appliance.

### WARNING

Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury or death. Read the installation, operation and maintenance instructions thoroughly before installing or servicing this equipment.

### WARNING

Certain materials or items, when stored under the heater, will be subjected to radiant heat and could be seriously damaged.

# **M** WARNING

- This product is fueled by propane gas. Propane gas is invisible, odorless, and flammable. An odorant is normally added to help detect leaks and can be described as a "rotten egg" smell.
   The odorant can fade over time so leaking gas is not always detectable by smell alone.
- Propane gas is heavier than air and leaking propane will sink to the lowest level possible.
   It can ignite by ignition sources including matches, lighters, sparks or open flames of any kind many feet away from the original leak.

Use only propane gas set up for vapor withdrawal.

• Store or use propane gas in compliance with local ordinances and codes or with ANS/NFPA 58. Turn off propane when not in use.

# CAUTION

#### SERVICE SAFETY

- Keep all connections and fittings clean. Make sure propane cylinder valve outlet is clean.
- During set up, check all connections and fittings for leaks using soapy water. Never use a flame.
- Use as a heating appliance only. Never alter in any way or use with any device.

# **M** WARNING

- Alert children and adults to the hazards of high surface temperatures. Stay away from these surfaces to avoid burning skin or igniting clothing.
- Carefully supervise young children when in the vicinity of the heater.
- Do not hang clothing or any other flammable materials from the heater, or place on or near the heater.
- Replace any guard or protective device removed for servicing the appliance prior to placing back in service.
- Installation and repair should be done by a qualified service person. The heater should be inspected before use and annually by a qualified service person.

More frequent cleaning may be required as necessary.

It is imperative that the control compartment, burners, and circulating air passageway of the appliance be kept clean.

#### **PREPARATION**

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents above. If any part is missing or damaged, do not attempt to assemble the product. Contact customer service for replacement parts.

#### **Estimated Assembly Time: 60 minutes**


Tools Required for Assembly (not included): Phillips Screwdriver and Leak Detection Solution.

1. Assemble the wheel bracket to the base with 4pcs M6X12 bolt (BB) and 4pcs M6 nut (AA). (see step 1). Assemble the other bracket in the same way.

Assemble the wheel to the bracket with 1pc M8X45 bolt (DD), 1pc Ф8 Washer (HH) and M8 Nut (CC) (see step 2). Assemble the other wheel in the same way.


Wheel assembly completed as shown in figure 1 step 3. Note: To improve stability, the preassembled bucket (N) can be filled with sand or water (not included).

#### Hardware Used





2. Attach cylinder housing (C) to base (J) with M5 x 8 mm screws (EE).


#### **Hardware Used**



3. Open the preassembled door (D) on cylinder housing (C) and place post (E) through the hole on the top.









4. Secure post (E) to cylinder housing (C) using the reinforced ring (MM), M6 x 10 mm bolts (FF) and  $\Phi$ 6 small flat washers (GG). Fasten and cover with the deco ring (NN).


#### **Hardware Used**





Unscrew stainless steel bolts (KK) from head assembly (B).

#### **Hardware Used**





6. Insert hose of head assembly (B) into post (E). Secure head assembly (B) to post (E) with stainless steel bolts (KK).


Note: The control knob on head assembly (B) should be above the decal on post (E).

#### **Hardware Used**










7. Slide Φ8 washers (HH) over the threaded ends of reflectors spacers(II). Attach reflector assembly to head assembly (B). Place Φ8 washers (HH) over threaded ends of reflector spacers(II) sticking out through reflector assembly and secure with wing nuts (JJ).

Note: Do not overtighten.

#### **Hardware Used**






8. Screw gas hose (F) and regulator (G) onto propane cylinder (not included). Do not cross-thread. Place the propane cylinder into the cylinder housing (C), then close the door (D).

Use a standard 20 lb. propane cylinder only. (approximately 12.2 in. / 31cm. in diameter and 17.9 in. / 45.5cm high).

Use this heater only with a propane vapor withdrawal supply system. See chapter 5 of the standard for storage and handling of liquefied petroleum gas, ANS/NFPA 58. Your local library or fire department should have this book. Storage of an appliance indoors is permissible only if the cylinder is disconnected and removed from the appliance. A cylinder must be stored outdoors in a well-ventilated area out of the reach of children. A disconnected cylinder must have dust caps tightly installed and must not be stored in a building, garage or any other enclosed area. The maximum inlet gas supply pressure: 250 psi /1750 kPa. The minimum inlet gas supply pressure: 5 psi /35kPa. Manifold pressure with regulator provided: 11 inch W.C/ 2.74 kPa. The pressure regulator and hose assembly supplied with the appliance must be used. The installation must conform with local codes, or in the absence of local codes, with national fuel gas code, ANS Z223.1/NFPA54, natural gas and propane Installation Code, CSA B149.1, or propane storage and handling code, B149.2.




A dented, rusted or damaged propane cylinder may be hazardous and should be checked by your cylinder supplier. Never use a propane cylinder with a damaged valve connection.


The propane cylinder must be constructed and marked in accordance with the specifications for LP gas cylinders of the U.S. Department of Transportation (DOT) or the standard for cylinders, spheres and tubes for transportation of dangerous goods and commission, CAN/CSA-B339.

The cylinder must have a listed overfilling prevention device. The cylinder must have a connection device compatible with the connection for the appliance. The cylinder used must include a collar to protect the cylinder valve. Never connect an unregulated propane cylinder to the heater.

The knob on the LP tank must be closed. Make sure that the knob is turned clockwise to a full stop. The cylinder supply system must be arranged for vapor withdrawal. Check that the control knob on the control unit is turned off. Hold the regulator in one hand and insert the nipple into the valve outlet. Be sure the nipple is centered in the valve outlet. The coupling nut connects to the large outside threads on the valve outlet. Hand-tighten the coupling nut clockwise until it comes to a full stop. Firmly tighten by hand only.

**To Disconnect:** Fully close the tank valve by turning clockwise. Turn the coupling nut counterclockwise until the regulator assembly detaches.






- Do not store a spare LP-gas cylinder under or near this appliance;
- Never fill the cylinder beyond 80 percent full;
- Place the dust cap on the cylinder valve outlet whenever the cylinder is not in use. Only install the type of dust cap on the cylinder valve that is provided with the cylinder valve. Other type of caps or plugs may result in leakage of propane.

Unscrew the switch button, load small battery, tighten the switch button.

**WARNING:** This product contains small batteries. Swallowed small batteries can cause CHOCKING HAZARD.Seek immediate medical attention if batteries are swallowed or inhaled. Keep children away from the small batteries.



To check for a leak:


- 1. Make 2-3 oz. leak check solution (one part liquid dishwashing detergent and three parts water).
- 2. Apply several drops of solution where regulator connects to cylinder and to all hose and valve connections
- 3. Make sure all patio heater and light valves are OFF.
- 4. Turn cylinder valve ON.

# If bubbles appear at any connection, there is a leak.

- 1. Turn cylinder valve OFF.
- 2. If leak is at regulator/cylinder valve connection: Disconnect, reconnect, and perform another leak check. Apply the soapy solution to all hose and valve connections. If you continue to see bubbles after several attempts, cylinder valve is defective and should be returned to cylinder's place of purchase.
- 3. If leak is at hose/regulator connection: This part is defective and you should contact the customer service department for replacement.

### WARNING

- Perform all leak tests outdoors.
- Extinguish all open flames.
- NEVER leak test when smoking.
- Do not use the heater until all connections have been leak tested and do not leak.



If NO bubbles appear at any connection, the connections are secure.

**NOTE:** Whenever gas connections are loosened or removed, you must perform a complete leak test.

# DANGER

- CARBON MONOXIDE HAZARD
- For outdoor use only. Never use inside house, or other unventilated or enclosed areas. This heater consumes air (oxygen). Do not use in unventilated or enclosed areas to avoid endangering your life.

**Caution:** Do not attempt to operate until you have read and understand all General Safety Information in this manual and all assembly is complete and leak checks have been performed.

#### **Before Turning Gas Supply ON:**

- 1. Your heater was designed and approved for outdoor use only. Do NOT use it inside a building, garage, or any other enclosed area.
- 2. Make sure surrounding areas are free of combustible materials, gasoline, and other flammable vapors or liquids.
- 3. Ensure that there is no obstruction to air ventilation. Be sure all gas connections are tight and there are no leaks.
- 4. Be sure the cylinder cover is clear of debris. Be sure any component removed during assembly or servicing is replaced and fastened prior to starting.

#### **Before Lighting:**

- 1. Heater should be thoroughly inspected before each use, and by a qualified service person at least annually. If relighting a hot heater, always wait at least 5 minutes.
- 2. Inspect the hose assembly for evidence of excessive abrasion, cuts, or wear. Suspected areas should be leak tested. If the hose leaks, it must be replaced prior to operation. Only use the replacement hose assembly specified by manufacturer.
- 3. The pressure regulator and hose assembly supplied with the appliance must be used. Replacement pressure regulators and hose assemblies must be those specified by the appliance manufacturer.

#### Lighting:

- 1. Turn on the valve on the gas cylinder.
- 2. Press and turn the control knob to HIGH (maximum) position (anti-clockwise 90°). (Figure 1)
- 3. Holding down the control knob, press the igniter button several times until the main flame is ignited. Release the control knob 10 seconds after the ignition.
- 4. Turn the control knob to LOW (minimum) and leave it there for 5 minutes or more before turning the knob to the desired temperature setting. (Figure 2)
- 5. If the burner flame goes out, turn off the heater and wait at least 5 minutes or more to let the gas dissipate before re-lighting to avoid gas explosion. Repeat steps 2 to 4.




Figure 1





Figure 2


**Note:** Improper operation, can cause injury or property damage. If pilot fails to remain lit, all valves should be closed and a waiting period of at least 5 minutes should pass before attempting to light.

If you experience any ignition problem please consult "Troubleshooting" on page 17.

**Caution:** Avoid inhaling fumes emitted from the heater's first use. Smoke and odor from the burning of oils used in manufacturing will appear. Both smoke and odor will dissipate after approximately 30 minutes. The heater should NOT produce thick black smoke.

**Note:** The burner may be noisy when initially turned on. Turn the knob to the level of heat desired.





# **MARNING**

#### FOR YOUR SAFETY

Be careful when attempting to manually ignite this heater. Holding in the control knob for more than 10 seconds before igniting the gas will cause a ball of flame upon ignition.

#### When Heater is ON:

Emitter screen will become bright red due to intense heat. The color is more visible at night. Burner will display tongues of blue and yellow flame. These flames should not be yellow or produce thick black smoke, indicating an obstruction of airflow through the burners. The flame should be blue with straight yellow tops. If excessive yellow flame is detected, turn off heater and consult "Troubleshooting" on page 17.

#### Re-lighting:

- 1. Turn control knob to OFF.
- 2. Repeat the "Lighting" steps on prior page.

# WARNING

FOR YOUR SAFETY

Heater will be hot after use. Handle with extreme care.

#### **Shut Down:**

Turn cylinder valve clockwise to OFF and disconnect regulator when heater is not in use.

**Note:** After use, some discoloration of the emitter screen is normal.

#### **OPERATION CHECKLIST**

Perform this check before each use.

#### **Before Operating:**

| ☐ I am familiar with entire owner's manual and understand all precautions noted. |
|--|
| ☐ All components are properly assembled, intact and operable.                    |
| □ No alterations have been made.   |
| ☐ All gas connections are secure and do not leak.                                |
| ☐ Wind velocity is below 10 mph.   |
| ☐ Unit will operate at reduced efficiency below 40°F.                            |
| ☐ Heater is outdoors (outside any enclosure).                                    |
| ☐ There is adequate fresh air ventilation.                                       |

#### OPERATION INSTRUCTIONS

| ☐ Heater is away from gasoline or other flammable liquids or vapors.   |
|--|
| ☐ Heater is away from windows, air intake openings, sprinklers and other water sources.  |
| ☐ Heater is at least 24 in. on top and at least 36 in. on sides from combustible materials.  |
| ☐ Heater is on a hard and level surface.   |
| ☐ There are no signs of spider or insect nests.  |
| ☐ All burner passages are clear.   |
| ☐ All air circulation passages are clear.  |
| □ Children and adults should be alerted to the hazards of high surface temperatures and  |
| should stay away to avoid burns or clothing ignition.  |
| ☐ Young children should be carefully supervised when they are in the area of the fire pit.  Clothing or other protective material should not be hung from the fire pit, or placed on or near the fire pit. |
| ☐ Any guard or other protective device removed for servicing the fire pit must be replaced prior to operating the fire pit.  |
| ☐ Installation and repair should be done by a qualified service person. The fire pit should be inspected before use and at least annually by a qualified service person.                                   |
| ☐ More frequent cleaning may be required as necessary. It is imperative that control   |
| compartment, burner and circulating air passageways of the fire pit be kept clean.   |

#### **After Operation**

- 1. Gas control is in OFF position.
- 2. Gas tank valve is OFF.
- 3. Disconnect gas line.

#### CARE AND MAINTENANCE

### **M** WARNING

#### FOR YOUR SAFETY:

- Do NOT touch or move heater for at least 45 minutes after use.
- Reflector is hot to the touch.
- · Allow reflector to cool before touching.

To enjoy years of outstanding performance from your heater, make sure you perform the following maintenance activities on a regular basis:

Keep exterior surfaces clean.

- 1. Use warm soapy water for cleaning. Never use flammable or corrosive cleaning agents.
- 2. While cleaning your unit, be sure to keep the area around the burner and pilot assembly dry at all times. Do not submerge the control valve assembly. If the gas control is submerged in water, do NOT use it. It must be replaced.
- a. Keep the appliance area clear and free from combustible materials, gasoline and other flammable vapors and liquids.
- b. Do not obstruct the flow of combustion and ventilation air.
- c. Keep the ventilation opening(s) of the cylinder enclosure free and clear from debris.
- 3. Air flow must be unobstructed. Keep controls, burner, and circulating air passageways clean. Signs of possible blockage include:

#### **CARE AND MAINTENANCE**

- Gas odor with extreme yellow tipping of flame.
- Heater does NOT reach the desired temperature.
- Heater glow is excessively uneven.
- Heater makes popping noises.
- Spiders and insects can nest in burner or orifices. This dangerous condition can damage heater and render it unsafe for use. Clean burner holes by using a heavy-duty pipe cleaner. Compressed air may help clear away smaller particles.
- Carbon deposits may create a fire hazard. Clean dome and burner screen with warm soapy water if any carbon deposits develop.

Note: In a salt-air environment (such as near an ocean), corrosion occurs more quickly than normal. Frequently check for corroded areas and repair them promptly.

#### TIP:

Use high-quality automobile wax to help maintain the appearance of your heater. Apply to exterior surfaces from the pole down. Do not apply to emitter screen or domes.

#### **Storage**

Between uses:

- Turn Control Knob OFF.
- Disconnect LP source.
- Store heater upright in an area sheltered from direct contact with inclement weather (such as rain, sleet, hail, snow, dust and debris).
- If desired, cover heater to protect exterior surfaces and to help prevent build-up in air passages. *Note: Wait until heater is cool before covering.*

#### During periods of extended inactivity or when transporting:

- Turn Control Knob OFF.
- Disconnect LP source and move to a secure, well-ventilated location outdoors.
- Store heater upright in an area sheltered from direct contact with inclement weather (such as rain, sleet, hail, snow, dust and debris).
- If desired, cover heater to protect exterior surfaces and to help prevent build-up in air passages. Never leave LP cylinder exposed to direct sunlight or excessive heat.

Note: Wait until heater is cool before covering.

#### Service


Only a qualified service person should repair gas passages and associated components.

Caution: Always allow heater to cool before attempting service.



#### **TROUBLESHOOTING**

| PROBLEM  | POSSIBLE CAUSE  | CORRECTIVE ACTION  |  |
|--|---|--|--|
|  | Propane cylinder is frosted over  | Wait until the propane cylinder warms up and becomes unfrosted |  |
| Burner won't light                             | 2. Blockage in orifice  | 2. Clear blockage  |  |
|  | 3. Control knob is not in ON position                                   | 3. Turn control knob to ON                                     |  |
|  | 1. Gas pressure is low  | Turn cylinder valve OFF and replace cylinder                   |  |
| Burner flame is low                            | 2. Outdoor temperature is less than 40°F and tank is less than 1/4 full | 2. Use a full cylinder   |  |
|  | 3. Control knob fully ON  | Check burner and orifices for                                  |  |
|  | 4. Spiders and insects nest in burner or orifices                       | blockage 4. Clean burner and orifices                          |  |
| Thick black smoke                              | Blockage in burner  | Remove blockage and clean burner inside and outside            |  |
| Gas odor with extreme yellow tipping of flame. | Spiders and insects nest in burner or orifices                          | Clean burner and orifices                                      |  |
| Heater glow is excessively uneven.             | Spiders and insects nest in burner or orifices                          | Clean burner and orifices                                      |  |
| Heater makes popping noises.                   | Spiders and insects nest in burner or orifices                          | Clean burner and orifices                                      |  |
| Carbon build-up                                | Dirt or film on reflector and burner screen                             | Clean reflector and burner screen                              |  |



| PART | DESCRIPTION           | QUANTITY |
|------|-----------------------|----------|
| Α    | Reflector Panel       | 1        |
| В    | Head Assembly         | 1        |
| С    | Cylinder Housing      | 1        |
| D    | Door (preassembled)   | 1        |
| Е    | Post                  | 1        |
| F    | Gas Hose              | 1        |
| G    | Regulator             | 1        |
| Н    | Bucket (preassembled) | 1        |
| Ī    | Wheel Kit             | 2        |
| J    | Base                  | 1        |

#### **Printed in China**