

My ProHeat 2X® Revolution® Pet Pro Carpet Cleaner has no power | Support

There are 2 switches on the machine - power button on the left, cleaning mode on the right



- Unplug machine
- Run hand along entire length of power cord, it should be smooth
- Check plug for damage
 - If either the cord (not smooth or exposed wires) or plug (prongs) are damaged, contact us
- Check to see if outlet is working:
 - Test this by plugging in a cell phone charger or small appliance
 - If no power to outlet, test a different outlet in a separate room
 - Reset circuit breaker if needed
- If machine still has no power contact us
-