

Bissell®




CLEANVIEW™ ESSENTIAL

Model 20095

What's in the Box?	3
Assembly	3
Cleaning Formulas	4
Filling the 2-in-1 Water Tank	5
Cleaning Your Carpet	6
Using the Ready Tools	7
Cleaning Your Hard Floors	8
Emptying the 2-in-1 Water Tank	9
After-Cleaning Care	9
Storing Your Machine	11
Troubleshooting	11
Guarantee	12

Product Overview

- | | |
|-----------------------------|---|
| 1. Spray Trigger | 8. Removable Nozzle |
| 2. Quick Release Cable Wrap | 9. DirtLifter PowerBrush |
| 3. Upper Handle | 10. Belt Access Door (underside of machine) |
| 4. Carry Handle | 11. EdgeSweep Brushes |
| 5. Tank Carry Handle | |
| 6. 2-in-1 Water Tank | |
| 7. Ready Tools Dial | |



Go online for a comprehensive walkthrough of your new purchase!

This guide has everything you need to get ready for first use, including setting up, using and maintaining your machine, but online you'll find additional resources like tips and troubleshooting, videos, product registration, parts, and more. Go to **support.BISSELL.com**.

IMPORTANT SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USING YOUR APPLIANCE.

When using an electrical appliance, basic precautions should be observed, including the following:



WARNING

TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR INJURY:

- » This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Cleaning and user maintenance shall not be made by children without supervision.
- » Children should be supervised to ensure that they do not play with the appliance.
- » Unplug from electrical socket when not in use, before cleaning, maintaining, or servicing the appliance, and if your appliance has an accessory tool with a moving brush, before connecting or disconnecting the tool.
- » Do not immerse in water or liquid.
- » Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts of the appliance and its accessories.
- » Do not immerse. Use only on surfaces moistened by the cleaning process. Use only BISSELL® cleaning products intended for use with this machine.
- » Use only the type and amount of liquids specified under the operations section of this guide.
- » Use only on carpet moistened by the cleaning process.
- » Liquid must not be directed towards equipment containing electrical components.
 - » Always connect to a properly earthed electrical socket. Do not modify earthed plug.
 - » Always install float before any wet pick-up operation.
 - » Plastic film can be dangerous. To avoid danger of suffocation, keep away from children.
 - » Use only as described in this user guide.
 - » Use only manufacturer's recommended attachments.
 - » If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water; do not attempt to operate it and have it repaired at an authorised service center.
 - » Do not put any object into openings.
 - » Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
 - » Use extra care when cleaning on stairs.
 - » Do not use to pick up flammable or combustible liquids, such as petroleum, or use in areas where they may be present.
 - » Do not pick up toxic material (chlorine bleach, ammonia, drain cleaner, etc.).
 - » Do not use appliance in an enclosed space filled with vapours given off by oil-based paint, paint thinner, some moth-proofing substances, flammable dust, or other explosive or toxic vapours.
 - » Do not pick up hard or sharp objects such as glass, nails, screws, coins, etc.
 - » Do not pick up anything that is burning or smoking, such as cigarettes, matches or hot ashes.
 - » Do not use without filters in place.
 - » Use indoors only.

SAVE THESE INSTRUCTIONS

ORIGINAL INSTRUCTIONS.

FOR OPERATION ON A 220-240 VOLT A.C. 50-60 HZ POWER SUPPLY ONLY.










THIS MODEL IS FOR HOUSEHOLD USE ONLY.

IMPORTANT INFORMATION

- » Keep appliance on a level surface.
- » If your appliance has a motorised Brush Roll, do not leave machine running in the same spot without the handle fully upright.
- » To reduce the risk of a leaking condition, do not store unit where freezing may occur. Damage to internal components may result.

What's in the Box?

Standard accessories may vary by model. To identify what should be included with your purchase, please refer to the "Carton Contents" list located on the carton top flap.

				
Base	Handle	Screws	Tool Holders	Bare Floor Tool
				
Tough Stain Tool	2-in-1 Crevice Tool	Deep Stain Tool	HydroRinse™ Tool	


Assembly

▶ Go to support.BISSELL.com for assembly videos.


Required for Assembly




Phillips-head Screwdriver




1. Slide Upper Handle onto lower base and secure with two long screws (taped to Upper Handle) into marked holes.




2. Attach upper hose/cable rack to the back of the handle by inserting hook into the slot and pressing up until it's seated flush with the back of the machine. Use 1 short screw to secure the bottom of the rack to the machine.




3. Attach lower hose/cable rack by inserting the hook into the slot and pressing up until it's seated flush with the back of the machine. Use 2 short screws to secure the bottom hose/cable rack.



4. Wrap hose around both hose/cable racks. Secure it by inserting the trigger hose grip into opening on the grip holder on the upper hose/cable rack.



5. Wrap cable around lower and upper hose/cable racks. Secure plug to cable with clip on plug.



6. Attach included tools to the appropriate storage locations on the machine.

Cleaning Formulas

Find more formulas at global.BISSELL.com.

Keep plenty of BISSELL® formulas on hand so you can clean whenever it fits your schedule. Always use genuine BISSELL formulas in your machine. Other formulas may harm the machine and void the guarantee. Do not use Wash & Shine Hard Floor Formula on area rugs or carpet.

Carpet Cleaning Formulas

Wash & Protect			Wash & Refresh
			
Pro Stain & Odour Professional strength to remove extra tough stains and odours.	Pet Stain & Odour Removes tough pet stains and odours.	Stain & Odour Removes tough stains and odours.	Ambipur Blossom & Breeze Powerful cleaning with a refreshing spring scent.

Wash & Remove	Wash & Shine	
		
Pro Pet Urine Eliminator + Oxy Permanently removes stains and odors at the source with the power of Oxy.	Allergen Helps remove pet dander, pollen and dust mite waste allergens.	Hard Floor Cleaner Removes tough dirt & grime and leaves a natural shine. Do not use on area rugs or carpet.

Pretreat

Pretreat spots and stains to improve carpet cleaning performance.

	
Stain Pretreat Loosens set-in stains & odours before carpet washing.	Pet Stain Pretreat Loosens tough pet stains & odours before carpet washing.

Boost

Add Boost carpet cleaning formula enhancers to any formula to increase its effectiveness.


Oxy Boost Add to formula for permanent stain removal.


Certain trademarks used under license from The Procter & Gamble Company or its affiliates.

⚠ WARNING To reduce the risk of fire and electric shock due to internal component damage, use only BISSELL formula intended for use with this machine. Use of cleaning formulas that contain eucalyptus, lemon or pine oil may damage this appliance and void the guarantee. Chemical spot cleaners or solvent-based soil removers should not be used. These products may react with the plastic materials used in your carpet washer causing cracking or pitting.


Filling the 2-in-1 Water Tank

▶ More of a visual person? We've got video instructions for this step at support.BISSELL.com.


Note: Fill with warm (140°F/60°C MAX) tap water and add the appropriate BISSELL® formula. Do not use boiling water. Do not heat water or tank in microwave.




1. Use Tank Carry Handle to remove tank from the machine and bring it to the sink.



2. Pull up on the bottom edge of the latch on the tank to remove the lid.



3. Pull up on bladder fill cover that says "Fill Here".




4. Fill tank with warm (60°C/140°F MAX) tap water to the water fill line. Do not boil or microwave water as it can destroy the tank.




5. Fill the provided measuring cup with formula to the fill line and pour into the bladder.


Optional: Add 60ml of OXY Boost per 3.7L of water and carpet cleaning formula solution. For optimal results, use 74ml (1 capful) per 3.7L of water and carpet cleaning formula solution. The CleanView™ Essential has a 3.7-L Tank.



6. Push down on bladder fill cover to close.




7. Replace the tank lid and latch.




8. Place tank into machine base and seat firmly into place.

Cleaning Your Carpet


Visit support.BISSELL.com for more carpet cleaning tips.




1. Plug into a proper outlet.




2. Set Ready Tools Dial to FLOOR CLEANING setting.




3. Use the red power pedal on the back of the machine to turn it ON.




4. Push the gray pedal to recline the machine.



5. Press the Spray Trigger while making one slow forward and one slow backward pass. Do not overwet.



6. Release trigger and make one slow forward and backward pass over same area.



7. Repeat cleaning passes until solution being suctioned up appears clean. Continue passes without pressing Spray Trigger until you can't see any more water being suctioned up. Repeated passes will help speed up dry time.

ATTENTION


- » Take care not to run over loose objects or edges of area rugs. Stalling the brush may result in premature belt failure.
- » Some Berber carpets have a tendency to fuzz with wear. Repeated strokes in the same area with an ordinary vacuum or carpet washer may aggravate this condition.

Using the Ready Tools


🔧 Your carpet and upholstery washer comes equipped with a hose and at least one cleaning tool for cleaning stairs, upholstery and more. Find more tools at **global.BISSELL.com**.

Tips


- » Check for colourfastness in an inconspicuous place before cleaning larger area.
- » If possible, check upholstery stuffing. Coloured stuffing may bleed through fabric when wet.
- » Vacuum thoroughly to pick up loose debris and pet hair.
- » Check manufacturer's tag before cleaning. Do not use on velvet or silk. If manufacturer's tag is missing or not coded, check with your furniture dealer.




1. Set Ready Tools Dial to **TOOLS** setting. This will allow spray and suction from hose.




2. Attach cleaning tool of your choice to end of hose.



3. Hold tool about 2.5 cm above soiled surface. Press Spray Trigger to apply cleaning solution. Release trigger, apply downward pressure, and pull toward you to suction up dirt and cleaning solution. Do not overwet.



4. When finished cleaning, remove and rinse tool(s) and hose in clean, running water.




5. Before wrapping the hose, lift and stretch the hose to make sure water is cleared. Wrap hose around rack.


Cleaning Your Hard Floors

👉 To see how else you can use your machine to clean your home, visit [support.BISSELL.com](https://support.bissell.com).


The Bare Floor Tool easily attaches to the bottom of your machine for use on hard floor surfaces. Safe for use on virtually all sealed hard floor surfaces including sealed hardwood, linoleum, vinyl, ceramic tile, granite, and marble.




1. Lay the machine flat on the ground to access the bottom of the foot.



2. Attach the hooks on the Bare Floor Tool to machine base and rotate the Bare Floor Tool to click to the front of the cleaning nozzle.




3. Fill the 2-in-1 Water Tank with 44ml of Wash & Shine Formula for each Liter of water added. The CleanView™ Essential has a 3.7-L Tank.




4. Repeat cleaning passes until solution being suctioned up appears clean. Continue passes without pressing Spray Trigger until you can't see any more water being suctioned up. Repeated passes will help speed up dry time.

Emptying the 2-in-1 Water Tank


▶ More of a video person? We've got you covered. Find these steps, and other how-to videos, at support.BISSELL.com.




1. Turn machine OFF and remove the 2-in-1 Water Tank from the machine. Carry tank to a sink or outside to dispose of dirty water.




2. Pull up on the bottom edge of the latch on the tank to remove the lid.




3. Empty dirty water from back corner of tank.



4. Rinse the tank with running, warm (60°C/140°F MAX) tap water, taking care to clean underneath and around heavy-duty bladder.



5. After each use, remove any debris trapped in red lint screen on base of machine while tank is still removed.



6. Return 2-in-1 Water Tank to machine.

After-Cleaning Care

▶ For a full list of machine maintenance tips and tricks, visit support.BISSELL.com.

Cleaning with the HydroRinse™ Tool



1. Attach the HyrdoRinse Tool to the hose. Turn the Ready Tools Dial to TOOLS and turn the machine ON.




2. Hold the hose and tool in an upright position. Hold down the trigger to rinse the hose for 30 seconds.


⚠ WARNING To reduce the risk of electric shock, push power pedal OFF and disconnect plug from electrical outlet before performing maintenance or troubleshooting checks.

After-Cleaning Care (continued)


Cleaning the Removable Nozzle



1. Grab the sides of the top of the nozzle and pull forward.




2. Rinse nozzle under running water.




3. When finished, replace nozzle by slightly raising front of machine to line up slots on each side of the base with hooks the nozzle. Push forward to click nozzle into place.

Cleaning the Ready Tools Dial


If Ready Tools Dial is hard to turn, the diverter assembly that holds it may need to be cleaned.




1. Remove the front nozzle.




2. Use a Phillips-head screwdriver to remove the screws that hold the assembly in place. Set them aside.




3. Remove assembly.



4. Hold assembly under running water. Make sure water flows through and around the dial. Turn the dial about 10 times each way to clear debris.



5. Replace assembly and screw.



6. Replace the front nozzle.

⚠ WARNING To reduce the risk of electric shock, push power pedal OFF and disconnect plug from electrical outlet before performing maintenance or troubleshooting checks.

Storing Your Machine

🔧 We have additional machine maintenance tips for you at support.BISSELL.com.

Keep machine in a protected, dry area, like a closet or basement. Because it uses water, this machine should not be kept where there's a danger of freezing. Freezing will damage internal components and void the guarantee.

Troubleshooting

🔧 Below are some of the issues you may run into. If you don't see the issue you're experiencing below, visit global.BISSELL.com.

Problem	Possible Cause	Remedies
Reduced spray OR no spray	Bladder may be empty.	Push power pedal OFF; refill bladder with clean, warm (60°F/140°C MAX) tap water and formula.
	2-in-1 Water Tank may not be seated properly.	Push power pedal OFF; remove and reseal tank.
	Pump may have lost prime.	Push power pedal OFF; after 1 minute turn ON and press Spray Trigger.
	Pump belt may be broken.	Push power pedal OFF and unplug from outlet. Visit support.BISSELL.com for belt replacement instructions.
DirtLifter PowerBrush does not turn	Brush belt or pump belt is off or broken.	Push power pedal off and unplug from outlet. Visit support.BISSELL.com for belt replacement instructions.
Machine not picking up solution	Ready Tools Dial may be on wrong setting for cleaning job.	Set dial to either FLOOR CLEANING or TOOLS setting.
	Poor tool position (handheld attachments only).	Adjust angle; apply more downward pressure.
	Removable Nozzle may not be properly attached.	Make sure nozzle is on correctly by slightly raising front of machine to line up slots on each side of base of machine with hooks on each side of nozzle. Attach at base first and then click nozzle into place. Refer to image 6 on page 10.
	2-in-1 Water Tank lid is not properly installed.	Reinstall lid.
	2-in-1 Water Tank is not properly seated.	Tank must be firmly seated to function; remove and reseal.
	2-in-1 Water Tank has picked up maximum dirty water.	Empty 2-in-1 Water Tank and refill.
	The lint screen may be clogged.	Clean out lint screen.

⚠️ WARNING To reduce the risk of electric shock, turn power OFF and disconnect plug from electrical outlet before performing maintenance or troubleshooting checks.

Guarantee

This guarantee gives you specific legal rights, in addition to rights you may have under the *Australian Consumer Law*. If you need additional instruction regarding this guarantee or have questions regarding what it may cover, please contact your local BISSELL® Consumer Care on the details set out below.

Limited 2 Year Guarantee (from the date of purchase by original purchaser)

Subject to the *CONDITIONS identified below, BISSELL will repair or replace (with new, refurbished, lightly used, or remanufactured components or products), at BISSELL's option, free of charge, any defective or malfunctioning part due to manufacturer defect. This guarantee applies to product used for personal purposes, and not commercial or rental service. This guarantee does not apply to fans or routine maintenance or consumable components such as filters, belts, brush rolls, etc., damage or malfunction caused by negligence, abuse, neglect, unauthorized repair, or any other use not in accordance with the user guide. BISSELL recommends that the original packaging be kept for the duration of the guarantee period in case such need arises within the guarantee period that the item needs re-packing and transportation. It may be necessary to obtain some of your personal information, such as a mailing address, to fulfill terms of this guarantee. Any personal data will be handled pursuant to BISSELL's Privacy Policy, which can be found at BISSELL.com.

*Conditions of Guarantee

Subject to whether such loss is reasonably foreseeable, BISSELL and its in-country distributors are not liable for incidental or consequential damages of any nature associated with the use of this product.

For Australian Consumers Only: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

This guarantee is in addition to other rights or remedies under law. Nothing in this guarantee excludes, limits or modifies any liability of BISSELL which is imposed by law, or limits or modifies any remedy available to the consumer which is granted by law. To make a claim under this guarantee contact BISSELL Australia PTY LTD (details above). Contact BISSELL prior to returning any goods. Where agreed, BISSELL will reimburse reasonable postage / handling costs (if any) for returning goods to BISSELL. To claim expenses incurred in making a claim under this guarantee please provide BISSELL with a copy of the receipt of the expenses by email or post.

Consumer Care

Australia

Telephone: 1300 247 735

Website: www.BISSELL.com.au

New Zealand

Telephone: 0800 247 735

Website: www.BISSELL.co.nz

But wait, there's more!

Join us online for a complete guide to your new product, including troubleshooting, parts and more.

Go to BISSELL.com.



INFO



VIDEOS



PARTS



©2020 BISSELL Inc. All rights reserved.
Printed in China. Part Number 1623238 01/20