


# PROFIBUS and PROFINET for Digital Dosing

CIM 150 PROFIBUS DP  
CIM 500 Ethernet for PROFINET IO

Functional profile and user manual



**Original functional profile and user manual.**

This functional profile describes Grundfos PROFI-FIBUS and PROFINET for DDA digital dosing pumps.

**CONTENTS**

	Page
<b>1. General information</b>	<b>2</b>
1.1 Hazard statements	2
1.2 Notes	2
<b>2. Introduction</b>	<b>3</b>
2.1 About this functional profile	3
2.2 PROFIBUS DP-V0	3
2.3 PROFIBUS DP-V1	3
2.4 Assumptions	3
2.5 Definitions and abbreviations	3
<b>3. System description</b>	<b>4</b>
<b>4. Specifications</b>	<b>5</b>
4.1 CIM module	5
4.2 CIM 150 PROFIBUS DP	5
4.3 CIM 500 PROFINET IO	5
<b>5. PROFIBUS DP, CIM 150 setup</b>	<b>6</b>
5.1 PROFIBUS bus topology	6
5.2 CIM 150 PROFIBUS module	6
5.3 Connecting the PROFIBUS	6
5.4 Setting the PROFIBUS address	7
5.5 Termination resistors	7
5.6 Status LEDs	7
5.7 Communication watchdog	7
5.8 Reaction to PLC "Stop button"	7
<b>6. PROFINET IO, CIM 500 setup</b>	<b>8</b>
6.1 Connecting the ethernet cable	8
6.2 Setting the Industrial Ethernet protocol	8
6.3 Setting up the IP addresses	8
6.4 Establish connection to the webserver	9
6.5 Status LEDs	9
6.6 DATA and LINK LEDs	9
<b>7. Detailed description of data modules</b>	<b>10</b>
7.1 Data types	10
7.2 Control module (ControlModule, module 1)	10
7.3 Dosing settings	13
7.4 Other settings	13
7.5 Bus settings compared to pump HMI settings	14
7.6 Status module (StatusModule, module 11)	14
7.7 Measurement data modules	17
7.8 Alarms and warning	19
7.9 Device identification (DeviceIdentification, module 40)	20
<b>8. Product simulation</b>	<b>21</b>
8.1 CIM 150 product simulation	21
8.2 CIM 500 Product Simulation	21
<b>9. Fault finding</b>	<b>22</b>
9.1 CIM 150	22
9.2 CIM 500	22



Read this document before installing the product. Installation and operation must comply with local regulations and accepted codes of good practice.

**1. General information****1.1 Hazard statements**

The symbols and hazard statements below may appear in Grundfos installation and operating instructions, safety instructions and service instructions.

**DANGER**

Indicates a hazardous situation which, if not avoided, will result in death or serious personal injury.

**WARNING**

Indicates a hazardous situation which, if not avoided, could result in death or serious personal injury.

**CAUTION**

Indicates a hazardous situation which, if not avoided, could result in minor or moderate personal injury.

The hazard statements are structured in the following way:

**SIGNAL WORD****Description of hazard**

Consequence of ignoring the warning.  
- Action to avoid the hazard.

**1.2 Notes**

The symbols and notes below may appear in Grundfos installation and operating instructions, safety instructions and service instructions.



Observe these instructions for explosion-proof products.



A blue or grey circle with a white graphical symbol indicates that an action must be taken.



A red or grey circle with a diagonal bar, possibly with a black graphical symbol, indicates that an action must not be taken or must be stopped.



If these instructions are not observed, it may result in malfunction or damage to the equipment.



Tips and advice that make the work easier.

## 2. Introduction

### 2.1 About this functional profile

This functional profile describes the following modules/units:

- CIM 150 PROFIBUS DP
- CIM 500 ethernet for PROFINET IO.

They are for PROFIBUS DP and PROFINET IO communication with the Smart Digital Dosing pump, type DDA, referred to as 'DDA pump' in this document.

Grundfos cannot be held responsible for any problems caused directly or indirectly by using information in this functional profile.

### 2.2 PROFIBUS DP-V0

The PROFIBUS DP interface conforms to the PROFIBUS DP-V0 standard for cyclic data transmission.

The option of setting the PROFIBUS DP address via bus is not supported as CIM 150/500 has two switches for setting the address.

### 2.3 PROFIBUS DP-V1

Only the diagnostic part and the extra three bytes of parameterisation data are supported. Acyclic data transmission is not supported.

### 2.4 Assumptions

This functional profile assumes that the reader is familiar with the commissioning and programming of PROFIBUS and PROFINET devices.

### 2.5 Definitions and abbreviations

ARP	Address Resolution Protocol. Translates IP addresses into MAC addresses.
Auto-MDIX	Ensures that both crossover cable types and non-crossover cable types can be used.
CAT5	Ethernet cable type with four twisted pairs of wires.
CAT5e	Enhanced CAT5 cable with better performance.
CAT6	Ethernet cable compatible with CAT5 and CAT5e and with very high performance.
CIM	Communication Interface Module.
CRC	Cyclic Redundancy Check. A data error detection method.
DHCP	Dynamic Host Configuration Protocol. Used to configure network devices so that they can communicate on an IP network.
DNS	Domain Name System. Used to resolve host names to IP addresses.
Enumeration	List of values.
GENibus	Proprietary Grundfos fieldbus standard.
GENipro	Proprietary Grundfos fieldbus protocol.
Grundfos GO	A Grundfos handheld remote control device for controlling Grundfos products via infrared or radio. Based on smart phone technology.
H	Head (pressure).
HTTP	Hyper Text Transfer Protocol. The protocol commonly used to navigate the world wide web.
IANA	Internet Assigned Numbers Authority.
IP	Internet Protocol.
LED	Light-emitting Diode.
Local mode	The DDA pump uses the setpoint and operating mode set with a handheld remote control (R100 or Grundfos GO Remote) or by the use of buttons on the pump.
MAC	Media Access Control. Unique network address for a piece of hardware.


Ping	Packet InterNet Groper. A software utility that tests the connectivity between two TCP/IP hosts.
Q	Flow rate.
Remote mode	The DDA pump uses the setpoint and operating mode set from the fieldbus.
SELV	Separated or Safety Extra-Low Voltage.
SELV-E	Separated or Safety Extra-Low Voltage with earth connection.
SMA	SubMiniature version A. Coaxial radio signal cable connection standard.
SMTP	Simple Mail Transfer Protocol.
SNTP	Simple Network Time Protocol. Used for clocks synchronization between computer systems.
TCP	Transmission Control Protocol. Protocol for Internet communication and Industrial Ethernet communication.
TCP/IP	Transmission Control Protocol/Internet Protocol. Protocol for Internet communication.
Transmission speed	Bits transferred per second, bits/s.
URL	Uniform Resource Locator. The address used to connect to a server.
UTC	Coordinated Universal Time. The primary time standard by which the world regulates clocks and time.
UTF-8	Unicode Transformation Format. Character encoding.
DDA	Digital Dosing Advanced.
HMI	Human Machine Interface. Display and buttons on the DDA pump.
PLC	Programmable Logic Controller.

### 3. System description

The system diagram provide an overview of the two different technologies and how to connect the CIM module to the Grundfos DDA E-box that you connect to a PROFIBUS DP or PROFINET IO network.

CIM 150/500 is a communication module installed internally in the Grundfos DDA E-box using a 10-pin connection. In this setup, the E-box supplies power to CIM. See fig. 1.

For mounting of the CIM module, see the installation and operating instructions for the DDA E-box.



**Fig. 1** DDA pump with E-box connected to a daisy chained PROFIBUS/PROFINET network

## 4. Specifications

### 4.1 CIM module

General data	Description	Comments
Ambient humidity	30-95 %	Relative, non-condensing.
Operating temperature	-20 °C to +45 °C	
Storage temperature	-25 °C to +70 °C	
GENIbus visual diagnostics	LED2	Will be in one of these states: Off, permanently green, flashing red, permanently red. See section <a href="#">5.6 Status LEDs</a> for PROFIBUS DP and section <a href="#">6.5 Status LEDs</a> for PROFINET IO.

### 4.2 CIM 150 PROFIBUS DP

The table below provides an overview of the specifications for Grundfos CIM 150. For further details, refer to the specific sections of this functional profile.

PROFIBUS DP specifications	Description	Comments
PROFIBUS implementation class	DP-V0	Intelligent pump profile.
PROFIBUS connector	Screw-type terminal	A, B, DGND, VP (+5 V).
PROFIBUS connection type	RS-485, two-wire	Conductors: A, B.
Maximum cable length	100 metres at 12 Mbits/s	Corresponds to 328 feet. See section <a href="#">5.3.1 Data transmission rates and cable length</a> .
Slave address	1-126	For DDA dosing pumps the address is selected on the pump display in the Settings menu. Address 126 is reserved for special purposes. See section <a href="#">5.4 Setting the PROFIBUS address</a> .
Line termination	On or off	Set via DIP switches SW1 and SW2. See section <a href="#">5.5 Termination resistors</a> . Auto detected
Recommended cable cross-section	0.20 - 0.25 mm <sup>2</sup>	AWG24 or AWG23
Supported transmission speed	9.6 Kbits/s to 12 Mbits/s	Auto detected.
PROFIBUS visual diagnostics	LED1	Off, permanently green, flashing red, permanently red. See section <a href="#">5.6 Status LEDs</a> .
Maximum number of PROFIBUS devices at a physical network segment	32	Up to 125 devices if repeaters are used (physically segmented network).

### 4.3 CIM 500 PROFINET IO

The table below provides an overview of the specifications for the Grundfos CIM 500 ethernet for PROFINET IO. For further details, refer to the specific sections of this functional profile.

PROFINET IO specifications	Description	Comments
Application layer	DHCP, HTTP, Ping, FTP, SMTP, SNTP, PROFINET IO	Rotary switch in position 0.
Transport layer	TCP	
Internet layer	Internet protocol V4 (IPv4)	
Link layer	ARP, Media Access Control (ethernet)	
Ethernet cable	Screened/unscreend, twisted-pair cables, CAT5, CAT5e or CAT6	Supports auto cable-crossover detecting (Auto-MDIX).
Maximum cable length	100 metres	Corresponds to 328 feet.
Transmission speed	10 Mbits/s, 100 Mbits/s	Auto-detected.
Industrial Ethernet protocols	PROFINET IO, Modbus TCP	Selected with rotary switch, section <a href="#">6.2 Setting the Industrial Ethernet protocol</a> .

## 5. PROFIBUS DP, CIM 150 setup

### 5.1 PROFIBUS bus topology

The PROFIBUS-preferred bus topology is daisy chaining as illustrated in fig. 2. The end devices of a physical bus segment must be terminated (LT = Line Termination). Each device must have a unique physical address [1-126]. Up to 32 PROFIBUS devices can be connected to a bus segment, and by using a repeater another 32 devices can be connected. This can be repeated until the maximum number of addresses are used. Make sure that each device is connected to a proper earth potential.




Fig. 2 Example of PROFIBUS bus segment with line termination

### 5.2 CIM 150 PROFIBUS module




Fig. 3 CIM 150 PROFIBUS module

Pos.	Designation	Description
1	B (Rx/D/TxD-P)	PROFIBUS terminal B (positive data signal)
2	A (Rx/D/TxD-N)	PROFIBUS terminal A (negative data signal)
3	DGND	PROFIBUS terminal DGND (only for external termination)
4	VP	+5 VDC (only for external termination)
5	SW1/SW2	On and off switches for termination resistors
6	LED1	Red and green status LED for PROFIBUS communication
7	LED2	Red and green status LED for GENIbus communication between the CIM 150 and the DDA pump
8	SW3	Not used for DDA
9	SW4	Not used for DDA



The power supply (pos. 4, fig. 3) must only be used for external termination.

## 5.3 Connecting the PROFIBUS

### 5.3.1 Data transmission rates and cable length

We recommend using a cable according to IEC 61158.

#### Example

Siemens, 6XV1 830-0EH10.

Cable length

Kbits/s	Maximum cable length
	[m/ft]
9.6	1200/4000
19.2	1200/4000
45.45	1200/4000
93.75	1000/3300
187.5	1000/3300
500	400/1300
1500	200/660
3000	100/330
6000	100/330
12000	100/330

#### Fitting the cable

See fig. 4.

1. Connect the red conductor(s) to terminal B (pos. 1).
2. Connect the green conductor(s) to terminal A (pos. 2).
3. Connect the cable screens to earth via the earth clamp (pos. 3).



For maximum safety and reliability, connect the cable screen to earth via the earth clamp, and make sure that all CIU 150 units are properly earthed via the mains supply earth-wire.




Fig. 4 Connecting the PROFIBUS

Pos.	Description
1	PROFIBUS terminal B
2	PROFIBUS terminal A
3	Earth clamp
4	+5 VDC
5	DGND

## 5.4 Setting the PROFIBUS address

Select the PROFIBUS address via the menu system in the pump display.



Set the PROFIBUS address decimally from 1 to 126. The address 126 is normally used for special purposes and should not be used.

A restart of CIM 150 has to be performed for a PROFIBUS address change to take effect.

For complete overview of the PROFIBUS addresses, see section .

## 5.5 Termination resistors

The termination resistors are fitted on the CIM 150 PROFIBUS module. See fig. 5.




Fig. 5 Internal termination resistors

CIM 150 has a DIP switch with two switches, SW1 and SW2, for cutting the termination resistors in and out. Figure 6 shows the DIP switches in cut-out state.




Fig. 6 Cutting termination resistors in and out

### DIP switch settings

Status	SW1	SW2
Cut in	ON	ON
Cut out	OFF	OFF
Undefined state	ON	OFF
	OFF	ON



To ensure stable and reliable communication, it is important that only the termination resistors of the first and last units in the PROFIBUS network are cut in.

## 5.6 Status LEDs

The CIM 150 PROFIBUS module has two LEDs. See fig. 3.

- Red and green status LED1 for PROFIBUS communication.
- Red and green status LED2 for GENIbus communication between CIM 150 and the connected DDA pump.

### LED1

Status	Description
Off.	CIM 150 has been switched off.
Permanently green.	CIM 150 is ready for PROFIBUS data transmission (Data Exchange State).
Permanently red.	CIM 150 module fault. CIM 150 does not support the connected DDA pump.
Flashing red.	Wrong or missing PROFIBUS configuration or no contact to the PROFIBUS master.

### LED2

Status	Description
Off.	CIM 150 is switched off.
Permanently green.	GENIbus communication between CIM 150 and the DDA pump is OK.
Permanently red.	CIM 150 does not support the connected DDA pump.
Flashing red.	No GENIbus communication between the CIM 150 and the DDA pump.



During startup, there may be a delay of up to 5 seconds before the LED2 status is updated.

## 5.7 Communication watchdog

The state of the PROFIBUS communication watchdog can be changed with a PROFIBUS commissioning tool, for example Siemens Simatic Manager. If the watchdog is enabled, all bits in the ControlModule (see section 7.2 [Control module \(ControlModule, module 1\)](#)) are automatically set to "0" if the PROFIBUS communication is broken.

As a result, the DDA pump will be set to local mode and then be operating according to the local operating mode, local setpoint and local control mode.

## 5.8 Reaction to PLC "Stop button"

If the PLC is stopped by the operator, all output registers will be set to "0".

As a result, the control bit RemoteAccessReq will be cleared, and the DDA pump will be set to local mode and then be operating according to the local operating mode, local setpoint and local control mode.

TM04 1961 1508

TM04 1703 0908

## 6. PROFINET IO, CIM 500 setup

### 6.1 Connecting the ethernet cable



**CAUTION**

**Electric shock**


Minor or moderate personal injury  
 - Connect CIM 500 only to SELV or SELV-E circuits.

Use RJ45 plugs and ethernet cable. Connect the cable shield to protective earth at both ends.




It is important to connect cable shield to earth through earth clamp or to connect cable shield to earth in the connector.

CIM 500 is designed for flexible network installation; the built-in two port switch makes it possible to daisy chain from product to product without the need of additional ethernet switches. The last product in the chain is only connected to one of the ethernet ports. Each ethernet port has its own MAC address.



TM05 6435 4711

Fig. 7 Example of Industrial Ethernet network




TM05 7431 1013

Fig. 8 Example of ethernet connection (CIM 500)

Pos.	Description	Designation
1	Industrial Ethernet RJ45 connector 1	ETH1
2	Industrial Ethernet RJ45 connector 2	ETH2
3	Rotary switch for protocol selection	SW1
4	Data activity LED for connector 1	DATA1
5	Link LED for connector 1	LINK1
6	Data activity LED for connector 2	DATA2
7	Link LED for connector 2.	LINK2
8	Green and red status LED for ethernet communication.	LED1
9	Green and red status LED for internal communication between module and pump.	LED2

### 6.2 Setting the Industrial Ethernet protocol

The CIM 500 ethernet module has a rotary switch for selection of the Industrial Ethernet protocol. See fig. 9.



TM05 7481 1013

Fig. 9 Selecting the Industrial Ethernet protocol

Pos.	Description
0	PROFINET IO (Default from factory)
1	Modbus TCP
2..E	Reserved, LED1 will be permanently red to indicate an invalid configuration
F	Reset to factory default Note: The rotary switch has to be set in this position for 20 seconds before CIM 500 resets to factory default. During this period LED1 will be flashing red and green at the same time to indicate that a reset will occur.



Every change of the rotary switch, when the module is powered on, will cause the module to restart.

### 6.3 Setting up the IP addresses

The CIM 500 ethernet module is by default set to a fixed IP address. It is possible to change the IP address settings from the built-in webserver.

Default IP settings used by the webserver	IP address: 192.168.1.100 Subnet mask: 255.255.255.0 Gateway: 192.168.1.1
IP settings for Modbus TCP	Must be set via the webserver
Device name and IP settings for PROFINET IO	Static configuration from webserver or configuration from PROFINET IO configuration tool.



## 6.4 Establish connection to the webserver

You can configure the CIM 500 module using the built-in webserver. To establish connection from a PC to CIM 500, the following steps are required:

- Connect the PC and the CIM 500 module using an ethernet cable
- Configure the PC ethernet port to the same subnetwork as CIM 500, for example 192.168.1.101, and the subnet mask to 255.255.255.0. See section [A.2 Web server configuration](#) on page 26.
- Open a standard Internet browser and type 192.168.1.100 in the URL field.
- Log in to the webserver using:

Username	Default: admin
Password	Default: Grundfos



Username and password may have been changed from their factory default values.



Fig. 10 CIM 500 connected to PC

TM05 6436 4712



You can use both ETH1 and ETH2 to establish a connection to the webserver.



You can access the webserver while the selected Industrial Ethernet protocol is active.

## 6.5 Status LEDs

The CIM 500 ethernet module has two status LEDs, LED1 and LED2.

See fig. 8.

- Red and green status LED1 for ethernet communication
- Red and green status LED2 for internal communication between CIM 500 and the Grundfos product.

### LED1

Status	Description
Off	CIM 500 is switched off.
Flashing green	Wink function. LED will flash 10 times when activated from master.
Permanently green	CIM 500 is ready for data transmission (data exchange state).
Flashing red (3 Hz, duty cycle 50 %)	Wrong or missing PROFINET IO configuration. See section <a href="#">9.2.1 LED status</a> .
Pulsing red (0.3 Hz, duty cycle 10 %)	Configured, but connection to master lost. See section <a href="#">9.2.1 LED status</a> .
Permanently red	Product not supported. See section <a href="#">9.2.1 LED status</a> .
Permanently red and green	Error in the firmware download. See section <a href="#">9.2.1 LED status</a> .
Flashing red and green	After 20 seconds in this state, the CIM 500 factory settings are restored and the device is restarted.

### LED2

Status	Description
Off	CIM 500 is switched off.
Flashing red	No internal communication between the CIM 500 and the Grundfos product.
Permanently red	CIM 500 does not support the Grundfos product connected.
Permanently green	Internal communication between CIM 500 and the Grundfos product is OK.
Permanently red and green	Memory fault.



During startup, there is a delay of up to 5 seconds before LED1 and LED2 status is updated.

## 6.6 DATA and LINK LEDs

The CIM 500 ethernet module has two connectivity LEDs related to each RJ45 connector. See fig. 8.

### DATA1 and DATA2

These yellow LEDs indicate data traffic activity.

Status	Description
Yellow off	No data communication on the RJ45 connector.
Yellow flashing	Data communication ongoing on the RJ45 connector.
Steady yellow	Heavy network traffic on the RJ45 connector.

### LINK1 and LINK2

These green LEDs show whether the ethernet cable is properly connected.

Status	Description
Green off	No ethernet Link on the RJ45 connector
Green on	Ethernet Link on the RJ45 connector is OK

## 7. Detailed description of data modules

### 7.1 Data types

Grundfos CIM 150/500 supports the following data types.

All data types, except for data type 10, comply with specification IEC 61158-6 standard data types for use in PROFIBUS/PROFINET profiles.

Data type	Description
1	Boolean
2	Integer 8
3	Integer 16
4	Integer 32
5	Unsigned 8
6	Unsigned 16
7	Unsigned 32
8	Floating point
9	Visible string
10	Non-standard

All multi-byte data types are transmitted with MSB (Most Significant Byte) first.

#### 7.1.1 Explanation of event trigger

##### State

Control bits with a state event trigger behave like a 'state' that is forced upon the DDA pump. CIM 150/500 will attempt to make the pump operate according to the 'requested' state in the ControlModule. Due to certain state/mode restrictions, this might not always be possible (see explanation of the bit in question). The 'actual state' of the pump can be read from the corresponding bit in StatusModule (module 11).

##### Value change

Control bits/bytes with a value-change event trigger behave like a command that is executed when the bit/byte changes its value. CIM 150/500 will attempt to make the DDA pump operate according to the 'requested' value in the ControlModule. The change will be reflected in the corresponding bit/byte in StatusModule (module 11). Bits/bytes that are controlled by a "value-change event trigger" can be controlled from both PROFIBUS/PROFINET and the pump HMI. The last value change, no matter from which source, will become active if not prevented by other conditions (see explanation of the bit/byte in question).

##### Rising edge

Control bits with a rising-edge event trigger behave like a command that is executed when a bit transition from "0" to "1" occurs. Each of them has a corresponding acknowledge bit in the StatusModule (module 11) which is set when the command is executed and cleared when the control bit is written back to "0".

### 7.2 Control module (ControlModule, module 1)

This is a PROFIBUS/PROFINET output module used for the control of the DDA pump. Its data type is 10, non-standard.

Mode/state settings			
	Bit	Name	Event trigger
Byte 1 (data type 5)	0	RemoteAccessReq	State
	1	De-aerating (100 %)	Value change
	2	AnalogMode	Value change
	3	TimerMode	Value change
	4	SlowMode	Value change
	5	Velocity	Value change
	6-7	-	-
Enable/disable function			
	Bit	Name	Event trigger
Byte 2 (data type 5)	0	AutoDeaeratingEnable	Value change
	1	FlowControlEnable	Value change
	2	ProfiWatchdogEnable	Value change
	3	AutoFlowAdaptEnable	Value change
	4	PulseMemoryEnable	Value change
	5-7	-	-
Action commands			
	Bit	Name	Event trigger
Byte 3 (data type 5)	0	ResetFault	Rising edge
	1	Pulse	Rising edge
	2	ResetVolumeCounter	Rising edge
	3	SetRTC	Rising edge
	4-7	-	-
ReqStartStop [enumeration] Triggered by value change			
	Value	Name	
Byte 4 (data type 5)	0	ReqStart	
	1	ReqStop	
	2-255	-	
OperatingMode [enumeration] Triggered by value change			
	Value	Name	
Byte 5 (data type 5)	0	Manual	
	1	Pulse	
	2	Analog	
	3	Timer	
	4	Batch	
	5-255	-	

## 7.2.1 Explanation of control bits in ControlModule

### RemoteAccessReq

Control bit used by CIM 150/500 to activate control from the bus.

- |    |  |
|----|--|
| 0: | The pump can only be controlled via the pump HMI and from its external signal inputs. With this setting, all control bits in ControlModule and writing to any output module will have no influence.                |
| 1: | CIM 150/500 can control the pump according to the settings in the ControlModule and the writing to the other output modules. The pump can also be controlled via the pump HMI and from its external signal inputs. |

### De-aerating

Control bit used to start and stop de-aerating the pump.

- |    |   |
|----|---|
| 0: | Stop de-aerating the pump.  |
| 1: | Start de-aerating the pump.<br>Equivalent to keep pressing <input type="checkbox"/> 100%. |

If the pump has been stopped via the pump HMI (symbol ), it is still possible to start and stop de-aerating the pump from the bus.

If de-aerating of the pump has been started from the bus, it can be stopped by pressing  100% or  on the pump.

### AnalogMode

Control bit used to select type of analog input signal.

- |    |          |
|----|----------|
| 0: | 0-20 mA. |
| 1: | 4-20 mA. |

Toggleing this bit has no effect unless the pump is in operating mode "Analog". The actual state (readable from StatusModule) will be reset to 4-20 mA whenever another operating mode is selected.

### TimerMode

Control bit used to select timer mode.

- |    |   |
|----|---|
| 0: | Cycle timer mode.<br>The pump repeats a cyclical dosing of the batch volume which can be programmed from PROFIBUS/PROFINET with data modules SetBatchDosingVolume and SetBatchDosingTime. |
| 1: | Week timer mode.<br>Up to 16 time-controlled dosing procedures are defined for a week. These procedures have to be programmed via the pump HMI.   |

### SlowMode

Control bit used to slow down the suction stroke velocity.

- |    |   |
|----|---|
| 0: | SlowMode disabled.<br>No slow-down of suction stroke velocity.  |
| 1: | SlowMode enabled.<br>Slows down the suction stroke velocity to the velocity selected with control bit velocity. |

### Velocity

Control bit used to select SlowMode suction stroke velocity.

- |    |                                |
|----|--------------------------------|
| 0: | Select SlowMode velocity 50 %. |
| 1: | Select SlowMode velocity 25 %. |

Toggleing this bit has no effect unless the pump operates in SlowMode. Suction stroke will be reset to 50 % velocity whenever SlowMode is disabled.

### AutoDeaeratingEnable

- |    |   |
|----|---|
| 0: | Automatic pump de-aeration disabled.<br>Automatic pump de-aeration enabled. |
| 1: | The pump is automatically de-aerated (degassed) at regular intervals.       |

Data module 34 DigitalOutputs, bit 2, will signal whenever automatic pump de-aeration is active.

### FlowControlEnable

When the FlowControl function is enabled, various faults and deviations related to the dosing process will be detected and indicated.

- |    |                                |
|----|--------------------------------|
| 0: | FlowControl function disabled. |
| 1: | FlowControl function enabled.  |

The enabling/disabling of FlowControl means the enabling/disabling of all alarms/warnings that are associated with flow measurement. See section [7.7 Measurement data modules](#).

If the FlowControl function is disabled, the AutoFlowAdapt function (see control bits AutoFlowAdaptEnable) cannot be enabled.

### ProfiWatchdogEnable

The PROFIBUS/PROFINET software watchdog is used to monitor the PROFIBUS/PROFINET connection. If the connection is broken, the DDA pump will stop dosing and indicate a bus communication fault. See section [7.8 Alarms and warning](#).

- |    |   |
|----|---|
| 0: | PROFIBUS/PROFINET software watchdog disabled. |
| 1: | PROFIBUS/PROFINET software watchdog enabled.  |

When "Bus control" is selected via the pump HMI, the PROFIBUS/PROFINET watchdog is automatically enabled every time the pump is powered on. If the bus communication is somehow interrupted (no communication with a PROFIBUS/PROFINET master), this will be detected and the DDA pump will stop with an alarm indicating "bus error" (event code 15).

Enabling of PROFIBUS/PROFINET will at the same time automatically enable the monitoring of the cable connection from the E-box to the DDA pump (event code 152).

After power-on, the PROFIBUS/PROFINET master can at any time control the enabling and disabling of the PROFIBUS/PROFINET software watchdog. The monitoring of the E-box cable connection will follow this choice.

When "Bus control" is disabled via the pump HMI, the PROFIBUS/PROFINET software watchdog is also automatically disabled and so is the monitoring of the E-box connection.

**AutoFlowAdaptEnable**

The AutoFlowAdapt function detects changes in various parameters and responds accordingly to keep the flow constant. Dosing accuracy is increased when this function is enabled.

0:	AutoFlowAdapt function disabled.
1:	AutoFlowAdapt function enabled.

The AutoFlowAdapt function can only be enabled if the FlowControl function is also enabled.

**PulseMemoryEnable**

The Pulse memory function can be used in operating mode "Pulse". When it is enabled, up to 65000 unprocessed pulses can be saved for subsequent processing.

0:	Pulse memory function disabled.
1:	Pulse memory function enabled.

**ResetFault**

When this control bit is toggled 0 → 1, the pump will attempt to reset pending alarms and warnings and to restart the pump if it was stopped due to an alarm.

**Pulse**

When this control bit is toggled 0 → 1, a pulse signal is sent to the pump. This can be used in operating modes "Pulse" and "Batch" and is equivalent to a pulse signal from the signal inputs.

**ResetVolumeCounter**



When this control bit is toggled 0 → 1, VolumeTripCounter (module 30) is reset to "0".

**SetRTC**

When this control bit is toggled 0 → 1, the internal real-time clock (RTC) in the DDA pump will be updated. The values must have been previously written to SetDataTime (module 9).

**7.2.2 Explanation of control mode**

Control enumeration for remote start/stop of the pump.

Value	Name
0	<p><b>ReqStart</b> If the pump is ready to be controlled from PROFIBUS/PROFINET (StatusModule:ActRemoteAccess = "1"), this value will start the pump and it will start dosing according to the selected operating mode. If the pump is stopped via the pump HMI, it will restart when  is pressed.</p>
1	<p><b>ReqStop</b> If the pump is ready to be controlled from PROFIBUS/PROFINET (StatusModule:ActRemoteAccess = "1"), this value will stop the pump and the pump HMI will show . If the pump is stopped from the bus, it cannot be started via the pump HMI (unless "Bus control" is deselected). ReqStop cannot stop the pump when it is de-aerating.</p>

**7.2.3 Explanation of operating mode**

Control enumeration for selection of operating mode.

Value	Name
0	<p><b>Manual</b> In this operating mode, the pump permanently doses the dosing flow set via SetpointManual (module 2) or the pump HMI.</p>
1	<p><b>Pulse</b> In this operating mode, the pump doses the volume set via SetPulseVolume (module 3) or the pump HMI for each incoming pulse. Reception of the Pulse command from PROFIBUS/PROFINET has the same effect as an incoming contact pulse signal. If the pump receives more pulses than it can process at the maximum dosing flow, excess pulses will be ignored if the Memory function (PulseMemoryEnable bit) is not enabled.</p>
2	<p><b>Analog</b> In this operating mode, the pump doses according to the external analog signal. It can operate according to a 4-20 mA or 0-20 mA signal selected via the AnalogMode bit or the pump HMI. If the input value in Analog mode 4-20 mA falls below 2 mA, an alarm is displayed and the pump stops. The relation between analog signal and dosing value is called analog scaling and must be set via the pump HMI.</p>
3	<p><b>Timer</b> The time the dosing should take place is controlled by a cyclic timer or by week timers. The selection is done via the TimerMode bit or the pump HMI. Some other parameters are related to timer dosing. They can only be programmed via the pump HMI.</p>
4	<p><b>Batch</b> In this operating mode, the pump doses the volume set via SetBatchDosingVolume (module 4) over a time period of SetBatchDosingTime (module 5) for each incoming pulse (or PROFIBUS/PROFINET Pulse command). The remaining batch volume during dosing can be read from RemainingDosingVolume (module 28).</p>

### 7.3 Dosing settings

Module	Name	Data type	Unit	Description
2	SetSetpointManual	8	l/h	Setting of the setpoint used in operating mode "Manual". Can also be set via the pump HMI. The present value can always be read from ActSetpointManual (module 12).
3	SetPulseVolume	8	l	Setting of the pulse volume used in operating mode "Pulse". Can also be set via the pump HMI. The present value can always be read from ActPulseVolume (module 13).
4	SetBatchDosingVolume	8	l	Setting of the batch dosing volume used in operating mode "Batch". Can also be set via the pump HMI. The present value can always be read from ActBatchDosingVolume (module 14).
5	SetBatchDosingTime	7	0.1 s	Setting of the batch dosing time used in operating mode "Batch". Can also be set via the pump HMI. The present value can always be read from ActBatchDosingTime (module 15).
6	SetPressureMax	8	bar	Setting of the (relative) pressure alarm limit. Can also be set via the pump HMI. The present value can always be read from ActPressureMax (module 16).

### 7.4 Other settings

Module	Name	Data type	Unit	Description
7	SetOutputRelays	5	Bits	Used to enable and disable the output relays 1 and 2. A relay has to be set to "Bus control" via the pump HMI if it should be controllable from the bus via the SetOutputRelays module. Via the pump HMI, the relays can also be individually configured to be of type NO or NC.  Bit 0:Relay 1 control: 0: Not active 1: Active. Bit 1:Relay 2 control: 0: Not active 1: Active.  The present status of the output relays can always be read from OutputRelays (module 34).
8	SetAnalogOutput	8	A	Used to control the analog output signal. The type of signal (4-20 mA or 0-20 mA) follows the setting of the AnalogMode bit. The analog output has to be set to "Bus control" via the pump HMI if it should be controllable from the bus. The present value of the analog output signal can always be read from AnalogOutput (module 32).
9	SetDateTime	10	BCD string	Used to set the internal real-time clock (RTC).  Byte 1: Year (from year 2000) Byte 2: Month [1-12] Byte 3: Day [1-31] Byte 4: Hour [0-23] Byte 5: Minute [0-59] Byte 6: Second [0-59].  Each byte is a binary-coded decimal (BCD) value.  Example 15:38:00, April 24 2011, is coded with hexadecimal numbers as: Year = 11h, Month = 04h, Day = 24h, Hour = 15h, Minute = 38h, Second = 00h.  Can also be set via the pump HMI.  The present value of the real-time clock can always be read from DateTime (module 21).

## 7.5 Bus settings compared to pump HMI settings

Name	Selectable from HMI	Setting preserved during power-off
<b>Mode/state settings</b>		
RemoteAccessReq	No	Yes*
De-aerating (100 %)	Yes	Yes/No*
AnalogMode	Yes	Yes
TimerMode	Yes	Yes
SlowMode	Yes	Yes
Velocity	Yes	Yes
<b>Enable/disable function</b>		
AutoDeaeratingEnable	Yes	Yes
FlowControlEnable	Yes	Yes
ProfiWatchdogEnable	Yes**	Yes
AutoFlowAdaptEnable	Yes	Yes
PulseMemoryEnable	Yes	Yes
<b>Action commands</b>		
ResetFault	Yes	-
Pulse	No	-
ResetVolumeCounter	Yes	-
SetRTC	Yes	-
<b>Operation control</b>		
ReqStart	Yes	Yes
ReqStop	Yes	No
OperatingMode	Yes	Yes
<b>Dosing settings</b>		
SetpointManual	Yes	Yes
SetPulseVolume	Yes	Yes
SetBatchDosingVolume	Yes	Yes
SetBatchDosingTime	Yes	Yes
SetFlowControlPressMax	Yes	Yes
<b>Output signal control</b>		
SetOutputRelay (value)	No	Yes
SetAnalogOutput (value)	No	Yes
SetDateTime	Yes	Yes

\* Will only be preserved if the CIM module is not powered off.

\*\* De-aerating will be preserved if commanded from bus.

\*\*\* Selecting and deselecting "Bus control" will implicitly enable and disable the PROFIBUS/PROFINET watchdog and the monitoring of the E-box connection to the DDA pump.

## 7.6 Status module (StatusModule, module 11)

This is a PROFIBUS/PROFINET input module used for the status of the DDA pump settings. Its data type is 10, non-standard. The actual status of all the pump modes and states are reflected, no matter if it is a result of a pump HMI setting or a setting written from PROFIBUS/PROFINET via ControlModule (module 1).

<b>Actual mode/state settings [bits]</b>	
Bit	Name
0	ActRemoteAccess
1	ActDeaerating (100 %)
2	ActAnalogMode
3	ActTimerMode
4	ActSlowMode
5	ActVelocity
6-7	-
<b>Actual enable/disable function [bits]</b>	
Bit	Name
0	ActAutoDeaeratingEnable
1	ActFlowControlEnable
2	ActProfiWatchdogEnable
3	ActAutoFlowAdaptEnable
4	ActPulseMemoryEnable
5-7	-
<b>Action command acknowledgement [bits]</b>	
Bit	Name
0	ResetFaultAck
1	PulseAck
2	ResetVolumeCounterAck
3	SetRTCAck
4-7	-
<b>Miscellaneous status [bits]</b>	
Bit	Name
0	Dosing (running)
1	Warning
2	Fault
3	BusControlLocallyEnabled
4-7	-
<b>ActualStartStop [enumeration]</b>	
Value	Name
0	Started
1	Stopped
2	Calibrating
3	Service
4-255	-
<b>ActualOperatingMode [enumeration]</b>	
Value	Name
0	Manual
1	Pulse
2	Analog
3	Timer
4	Batch
5-255	-

Byte 1  
(data type 5)

Byte 2  
(data type 5)

Byte 3  
(data type 5)

Byte 4  
(data type 5)


Byte 5  
(data type 5)

Byte 6  
(data type 5)

### 7.6.1 Explanation of status bits

#### ActRemoteAccess

Status bit indicating whether the pump is in a state where it is controllable from the bus.

- 
- 0: The pump can only be controlled from its HMI and its external signal inputs. In this state, all control bits in ControlModule and writing to any output module will have no influence.
- 
- 1: In this state, the pump can be controlled by the bit settings in the ControlModule (as well as from the pump HMI and external signal inputs) and the writing to the other output modules. To enter this state, the ControlModule bit 0 must be set and the pump must be started via the pump HMI by pressing .
- 

#### ActDeaerating

Status bit indicating whether the pump is de-aerating or not.

- 
- 0: The pump is not de-aerating.
- 
- 1: The pump is de-aerating.
- 

#### ActAnalogMode

Status bit indicating the selected type of the analog input signal.

- 
- 0: 0-20 mA.
- 
- 4-20 mA.
- 
- 1: This will always be the reading if the operating mode is not "Analog".
- 

#### ActTimerMode

Status bit indicating the selected timer mode.

- 
- 0: Cycle timer mode.
- 
- 1: Week timer mode.
- 

#### ActSlowMode

Status bit indicating whether SlowMode has been enabled.

- 
- 0: SlowMode disabled.  
No slow-down of suction stroke velocity.
- 
- SlowMode enabled.
- 
- 1: Slows down the suction stroke velocity to the velocity selected with control bit Velocity.
- 

#### Velocity

Status bit indicating the selected SlowMode suction stroke velocity.

- 
- 0: Selected SlowMode velocity 50 %.  
This will always be the reading if SlowMode is disabled.
- 
- 1: Selected SlowMode velocity 25 %.
- 

#### ActAutoDeaeratingEnable

Status bit indicating whether automatic pump de-aeration has been enabled.

- 
- 0: Automatic pump de-aeration disabled.  
Automatic pump de-aeration enabled.
- 
- 1: DigitalOutputs (module 34), bit 2, will signal whenever the automatic pump de-aeration is active.
- 

#### ActFlowControlEnable

Status bit indicating whether the FlowControl function has been enabled.

- 
- 0: FlowControl function disabled.
- 
- 1: FlowControl function enabled.
- 

#### ActProfiWatchdogEnable

Status bit indicating whether the PROFIBUS/PROFINET software watchdog has been enabled.

- 
- 0: PROFIBUS/PROFINET software watchdog disabled.
- 
- 1: PROFIBUS/PROFINET software watchdog enabled.
- 

The PROFIBUS/PROFINET software watchdog is automatically enabled/disabled when "Bus control" is selected/deselected via the pump HMI. The software watchdog can be enabled/disabled independently via the bus.

#### ActAutoFlowAdaptEnable

Status bit indicating whether the AutoFlowAdapt function has been enabled.

- 
- AutoFlowAdapt function disabled.
- 
- 0: This will always be the reading if the FlowControl function is disabled.
- 
- 1: AutoFlowAdapt function enabled.
- 

#### ActPulseMemoryEnable

Status bit indicating whether the Pulse memory function is enabled.

- 
- 0: Pulse memory function disabled.
- 
- 1: Pulse memory function enabled.
- 

#### Dosing (running)

Status bit indicating whether the DDA pump is dosing (running) at the moment.

- 
- 0: The pump is not dosing at the moment.
- 
- 1: The pump is dosing at the moment.
- 

#### Warning

Warning status bit.

- 
- 0: No warning is present.  
A warning is present.
- 
- 1: The pump can however continue its precise dosing for the time being, but we recommend to have it serviced.
- 

For further details about possible warnings and faults as well as the pump behaviour in these situations, see section [7.8 Alarms and warning](#).

#### Fault

Fault status bit. The pump will stop dosing as long as the fault is present.

- 
- 0: No fault is present.
- 
- 1: A fault is present, and the pump will remain stopped until the fault has been corrected.
- 

For further details about possible warnings and faults as well as the pump behaviour in these situations, see section [7.8 Alarms and warning](#).

#### BusControlLocallyEnabled

Status bit indicating whether "Bus control" has been enabled in the Settings menu on the pump HMI.

- 
- Bus control has not been enabled via the pump HMI.
- 
- 0: Setting of the RemoteAccess bit in ControlModule has no effect.
- 
- 1: Bus control has been enabled via the pump HMI.
-

### 7.6.2 Explanation of command acknowledge bits

If the ActRemoteAccess bit is not set, PROFIBUS/PROFINET commands (and writings in general) will be prohibited and none of the acknowledge bits will ever be set. Command acknowledge bits can thus be used to check whether a command from ControlModule was sent or not.

#### ResetFaultAck

Acknowledge bit belonging to the ResetFault control bit. It will be set when the control bit is set and the command has been executed. It will be cleared when the control bit is cleared.

#### PulseAck

Acknowledge bit belonging to the Pulse control bit. It will be set when the control bit is set and the command has been executed. It will be cleared when the control bit is cleared.

#### ResetVolumeCounterAck



Acknowledge bit belonging to the ResetVolumeCounter control bit. It will be set when the control bit is set and the command has been executed. It will be cleared when the control bit is cleared.

#### SetRTCAck

Acknowledge bit belonging to the SetRTC control bit. It will be set when the control bit is set and the command has been executed. It will be cleared when the control bit is cleared.

### Explanation of ActualStartStop

Status enumeration for reading whether the pump is started, stopped, calibrating or in service mode:

Value	Name
	<p><b>Started</b></p> <p>This has the following meaning for the different operating modes:</p> <ul style="list-style-type: none"> <li>"Manual": The pump will be dosing according to ActualSetpointManual (module 12).</li> <li>"Analog": The pump will be dosing according to the analog input signal and the analog scaling.</li> <li>"Pulse": The pump will be dosing according to the reception of pulses and the value of ActualPulseVolume (module 13).</li> <li>"Batch": The pump will be dosing according to the reception of pulses and the values of ActualBatchDosingVolume (module 14) and ActualBatchDosingTime (module 15).</li> <li>"Timer": The pump will be dosing according to the timer functions using the batch dosing settings.</li> </ul>
0	
	<p><b>Stopped</b></p> <p>The pump has been stopped by one of the control sources. The state of the control sources can be read from ControlSourceStates (module 17).</p>
1	
	<p><b>Calibrating</b></p> <p>The pump is calibrating the dosing accuracy. This is only possible via the pump HMI by selecting Calibration in the Setup menu.</p>
2	
	<p><b>Service</b></p> <p>The pump has stopped and has been brought into Service mode. This is only possible via the pump HMI and can be done by pressing  and  simultaneously.</p>
3	

### 7.6.3 Explanation of ActualOperatingMode

Status enumeration for reading of the actual operating mode. For an explanation of these modes and the belonging enumeration, see section [7.2.3 Explanation of operating mode](#).



## 7.7 Measurement data modules

Module	Name	Data type	Unit	Description
12	ActualSetpointManual	8	l/h	The actual setpoint used in operating mode "Manual". Can be set via SetpointManual (module 2) or via the pump HMI.
13	ActualPulseVolume	8	l	The actual pulse volume used in operating mode "Pulse". Can be set via SetPulseVolume (module 3) or via the pump HMI.
14	ActualBatchDosingVolume	8	l	The actual batch dosing volume used in operating mode "Batch". Can be set via SetBatchDosingVolume (module 4) or via the pump HMI.
15	ActualBatchDosingTime	7	0.1 s	The actual batch dosing time used in operating mode "Batch". Can be set via SetBatchDosingTime (module 5) or via the pump HMI.
16	ActualPressureMax	8	bar	Actual value of (relative) pressure alarm limit setting. Can be set via SetPressureMax (module 6) or via the pump HMI.
17	ControlSourceStates	5	Bits	Status of start/stop control sources, "1" means "Active". They can be active simultaneously. Bit 0: Stop via pump HMI Bit 1: External stop Bit 2: Stop from bus.
18	FaultCode	5	Enum	
19	WarningCode	5	Enum	See section <a href="#">7.6 Status module (StatusModule, module 11)</a> .
20	WarningBits	6	Bits	
				Present value of the internal real-time clock (RTC). Can be set via SetDateTime (module 9) or via the pump HMI.
21	DateTime	10	BCD string	Byte 1: Year (from year 2000) Byte 2: Month [1-12] Byte 3: Day [1-31] Byte 4: Hour [0-23] Byte 5: Minute [0-59] Byte 6: Second [0-59].  Each byte is a binary-coded decimal (BCD) value.  <b>Example</b> 15:38:00, April 24 2011, is coded with hexadecimal numbers as: Year = 11h, Month = 04h, Day = 24h, Hour = 15h, Minute = 38h, Second = 00h.
22	DosingPressureMax	8	bar	Maximum dosing pressure, fixed factory-set value for this pump type.
23	DosingCapacityMax	8	l/h	Maximum dosing capacity, fixed factory-set value for this pump type.
24	DosingCapacityReference	8	l/h	The dosing capacity setpoint shown in the pump display. It represents the actual setpoint belonging to the actual operating mode and dosing state.
25	MeasuredDosingCapacity	8	l/h	Measured (actual) dosing capacity. FlowControl bit in ControlModule (module 1) must be enabled for this value to be available.
26	MeasuredPressure	8	bar	Measured absolute pressure. FlowControl bit in ControlModule must be enabled. Except for the atmospheric pressure, it corresponds to "Backpressure" reading in the display.
27	PulseInputFrequency	8	Hz	Frequency of pulse input (external pulse input signal or PROFIBUS/PROFINET Pulse command in ControlModule).
28	RemainingDosingVolume	8	l	Actual remaining volume to be dosed. Used in "Batch" mode.
29	VolumeTotal	8	l	Total volume dosed (non-resettable).
30	VolumeTripCounter	8	l	Dosed-volume trip counter (reset with ResetVolumeCounter command in ControlModule).
31	AnalogInput	8	A	Analog input signal 0-20 mA or 4-20 mA (used as setpoint in Analog mode).
32	AnalogOutput	8	A	Analog output signal. The parameter to map to the output is selected via the pump HMI. If control from PROFIBUS/PROFINET is selected, the analog output signal will be controlled from SetAnalogOutput (module 8).

Module	Name	Data type	Unit	Description
				Status of the external digital inputs.  Logical "0": The input is not active. Logical "1": The input is active.
33	DigitalInputs	5	Bits	The relay input type (NO or NC) is selected via the pump HMI.  Signals are fixed to the following: Bit 0: Low-level signal Bit 1: Empty signal Bit 2: External stop.
				Status of the two output relays.  Logical "0": The output is not active. Logical "1": The output is active.
34	OutputRelays	5	Bits	The relay output type (NO or NC) is selected via the pump HMI.  The output relay modules are defined as follows: Bit 0: Relay 1 (select signal parameter via the pump HMI). Bit 1: Relay 2 (select signal parameter via the pump HMI). Bit 2: Auto-deaerating (de-aerating valve open).  If "Bus control" has been selected as the relay signal parameter, the relay can be controlled from SetOutputRelays (module 7).
35	NumberOfPowerOns	6	-	Counts the number of times the pump has been powered on (non-resettable).
36	RunTime	7	s	Counts the time the DDA pump has been dosing (non-resettable).
37	OperatingHours	7	s	Counts the number of hours the DDA pump has been switched on. It counts both when the pump is dosing and when it is not dosing.
38	StrokeCounter	7	-	Counts the number of strokes (non-resettable).
39	TimeToNextDosing	7	s	Time before the next dosing takes place (only in timer mode).

## 7.8 Alarms and warning

Module	Name	Data type	Description
18	FaultCode	5	Code for active pump alarm. See event code in the table below.
19	WarningCode	5	Code for first active pump warning. See event code in the table below.
			All active warnings. The belonging event code in parenthesis.
			<b>Byte 1</b> Bit 0:Backpressure low (211)* Bit 1:Air bubbles (35)* Bit 2:Cavitation (208)* Bit 3:Discharge valve leakage (36)* Bit 4:Suction valve leakage (37)* Bit 5:-- reserved -- Bit 6:Service now (12) Bit 7:Service soon (33)
20	WarningBits	6	<b>Byte 2</b> Bit 0:Low level in tank (206) Bit 1:-- reserved -- Bit 2:FlowControl cable breakdown (169)* Bit 3:- Bit 4:- Bit 5:Flow deviation (17)* Bit 6:- Bit 7:-

\* Requires FlowControlEnable bit in ControlModule to be set.

In case of a pump alarm or pump warning the modules WarningCode and FaultCode will contain an event code for the cause of the problem.

The complete list of possible alarm/warning codes from a DDA pump is shown in the table below.

Alarm events will make the pump stop. Some of them require acknowledgement of the alarm before the pump can be restarted. This acknowledgement can come from the pump HMI or PROFIBUS/PROFINET by usage of the ResetFault command.

The pump can only indicate one active alarm at a time, whereas there can be many simultaneously active warnings. The complete status of warnings can be read from the WarningBits module.

Event code	Event group	Event description	Depends on FlowControl enabled	Event action	Auto-acknowledge
210	Pump head	Maximum pressure limit exceeded. ActualPressureMax (module 16).	Yes	Alarm	Yes
211	Pump head	Backpressure too low. Fixed low-pressure limit (1.5 bar).	Yes	Alarm/ Warning <sup>1)</sup>	Yes
35	Pump head	Air bubbles, gas in pump head, de-aerating problem.	Yes	Warning	Yes
208	Pump head	Cavitation.	Yes	Warning	Yes
36	Pump head	Discharge (pressure) valve leakage.	Yes	Warning	Yes
37	Pump head	Suction valve leakage.	Yes	Warning	Yes
12	Pump head	Service now (time for service exceeded).	No	Warning	No
33	Pump head	Soon time for service (general service information).	No	Warning	No
17	Pump head	Flow deviation (performance requirement not met).	Yes	Warning	Yes
51	Pump head	Blocked motor/pump.	No	Alarm	Yes
206	Tank	Low level in tank.	No	Warning	Yes
57	Tank	Empty tank (dry running).	No	Alarm	Yes
169	Input signals	Cable breakdown on FlowControl.	Yes	Warning	Yes
97	Input signals	Defective analog 4-20 mA cable.	No	Alarm	Yes
15	Communication	PROFIBUS/PROFINET communication fault (main network communication fault).	No	Alarm <sup>2)</sup>	No
152	Communication	Extension box communication fault (GENibus communication fault). Defective cable between E-box and DDA pump.	No	Alarm <sup>2)</sup>	No

<sup>1)</sup> Warning or alarm is selected in the Settings menu via the pump HMI.

<sup>2)</sup> An alarm only occurs when the ActProfiWatchdogEnable bit has been set. See sections [7.2.1 Explanation of control bits in ControlModule](#) and [7.6.1 Explanation of status bits](#).

## 7.9 Device identification (DeviceIdentification, module 40)

The data type is 10, non-standard.

Byte	Name/description																				
	<table border="1"> <thead> <tr> <th>UnitFamily [enumeration]</th> <th>UnitType [enumeration]</th> </tr> </thead> <tbody> <tr> <td>1: UPE/MAGNA circulator pump</td> <td>5: UPE, 3-phase 7: MAGNA, 1-phase 9: MAGNA, 1-phase, small 10: MAGNA3</td> </tr> <tr> <td>2: E-pump, 1-phase/3-phase, based on MGE motor or CUE frequency converter</td> <td>2: MGE, 1-phase 3: MGE, 3-phase 4: MGE, 3-phase, large 5: CUE frequency converter 6: MGE, 3-phase, model G 7: MGE, 3-phase, model H/I</td> </tr> <tr> <td>7: MP 204 motor protector</td> <td>1: MP 204</td> </tr> <tr> <td>17: Hydro Multi-E model G and earlier models</td> <td>1: With 3-phase pumps 2: With 1-phase pumps</td> </tr> <tr> <td>21: Hydro MPC/Control MPC, Hydro Multi-B</td> <td>1: Hydro MPC/Control MPC, CU 351 2: Hydro Multi-B, CU 323</td> </tr> <tr> <td>25: CR Monitor</td> <td>1: CR Monitor, CU 351</td> </tr> <tr> <td>26: Dedicated Controls</td> <td>1: Dedicated Controls, CU 361</td> </tr> <tr> <td>30: Smart Digital Dosing, DDA</td> <td>1: Smart Digital Dosing, DDA</td> </tr> <tr> <td>39: Hydro Multi-E model H and later models</td> <td>1: With 3-phase pumps 2: With 1-phase pumps</td> </tr> </tbody> </table>	UnitFamily [enumeration]	UnitType [enumeration]	1: UPE/MAGNA circulator pump	5: UPE, 3-phase 7: MAGNA, 1-phase 9: MAGNA, 1-phase, small 10: MAGNA3	2: E-pump, 1-phase/3-phase, based on MGE motor or CUE frequency converter	2: MGE, 1-phase 3: MGE, 3-phase 4: MGE, 3-phase, large 5: CUE frequency converter 6: MGE, 3-phase, model G 7: MGE, 3-phase, model H/I	7: MP 204 motor protector	1: MP 204	17: Hydro Multi-E model G and earlier models	1: With 3-phase pumps 2: With 1-phase pumps	21: Hydro MPC/Control MPC, Hydro Multi-B	1: Hydro MPC/Control MPC, CU 351 2: Hydro Multi-B, CU 323	25: CR Monitor	1: CR Monitor, CU 351	26: Dedicated Controls	1: Dedicated Controls, CU 361	30: Smart Digital Dosing, DDA	1: Smart Digital Dosing, DDA	39: Hydro Multi-E model H and later models	1: With 3-phase pumps 2: With 1-phase pumps
UnitFamily [enumeration]	UnitType [enumeration]																				
1: UPE/MAGNA circulator pump	5: UPE, 3-phase 7: MAGNA, 1-phase 9: MAGNA, 1-phase, small 10: MAGNA3																				
2: E-pump, 1-phase/3-phase, based on MGE motor or CUE frequency converter	2: MGE, 1-phase 3: MGE, 3-phase 4: MGE, 3-phase, large 5: CUE frequency converter 6: MGE, 3-phase, model G 7: MGE, 3-phase, model H/I																				
7: MP 204 motor protector	1: MP 204																				
17: Hydro Multi-E model G and earlier models	1: With 3-phase pumps 2: With 1-phase pumps																				
21: Hydro MPC/Control MPC, Hydro Multi-B	1: Hydro MPC/Control MPC, CU 351 2: Hydro Multi-B, CU 323																				
25: CR Monitor	1: CR Monitor, CU 351																				
26: Dedicated Controls	1: Dedicated Controls, CU 361																				
30: Smart Digital Dosing, DDA	1: Smart Digital Dosing, DDA																				
39: Hydro Multi-E model H and later models	1: With 3-phase pumps 2: With 1-phase pumps																				
1																					
2	UnitType [enumeration] According to description above.																				
3	UnitVersion [enumeration] Used by Grundfos.																				
4	CIMSoftwareVersion [number]																				
5	CIMSoftwareRevision [number]																				
6	CIMModel [enumeration]																				

## 8. Product simulation

The CIM module can be put in product simulation mode in which case it will generate life-like simulated values of all the PROFIBUS/PROFINET input data modules.

It will thus be possible to connect a PROFIBUS/PROFINET master to CIM 150/CIM 500 without this device being connected to a real pump in a real-life system. In an office environment, it can then be verified that communication works and data is being received and handled correctly by the PROFIBUS/PROFINET master application program (e.g. PLC program) before the equipment is installed under real-life conditions.

### 8.1 CIM 150 product simulation

Product simulation mode is entered when the hexadecimal address switch has one of the values shown in the table below:

Address setting (section <a href="#">5.4 Setting the PROFIBUS address</a> )		Simulated product
SW3	SW4	
F	0	Pump profile
F	1	Booster system profile
F	2	CR Monitor profile
F	3	MP 204 motor protector profile
F	4	Digital Dosing DDA profile
F	5	Wastewater system profile

The effective address will be 15 (0x0F).

Only input modules are simulated. The data read has dummy values and no real product functionality is simulated.

### 8.2 CIM 500 Product Simulation

Product simulation mode is entered via the webserver. See section [A.4 PROFINET IO configuration](#) on page 27.

## 9. Fault finding

### 9.1 CIM 150

You can detect faults in a CIM 150 PROFIBUS module by observing the status of the two communication LEDs. See the table below.

#### 9.1.1 LED status

Fault (LED status)	Possible cause	Remedy
1. Both LED1 and LED2 remain off when the power supply is connected.	a) CIM 150 is fitted incorrectly in the DDA pump.	Check that CIM 150 is fitted/connected correctly.
	b) CIM 150 is defective.	Replace CIM 150.
2. The LED2 for internal communication is flashing red.	a) No internal communication between CIM 150 and the DDA pump.	Check that CIM 150 is fitted correctly in the DDA pump.
3. LED2 for internal communication is permanently red.	a) CIM 150 does not support the connected DDA pump.	Contact the nearest Grundfos company.
4. The PROFIBUS LED1 is permanently red.	a) Fault in CIM 150.	Contact the nearest Grundfos company.
5. The PROFIBUS LED1 is flashing red.	a) Fault in CIM 150 PROFIBUS configuration.	<ul style="list-style-type: none"> <li>• Check in the DDA settings menu that the PROFIBUS address has a valid value [1-125]. See section <a href="#">5.4 Setting the PROFIBUS address</a>.</li> <li>• Check that the GSD file used is correct.</li> <li>• Check that the PROFIBUS cable has been fitted correctly. See section <a href="#">5.3 Connecting the PROFIBUS</a>.</li> <li>• Check that the PROFIBUS termination is correct. See section <a href="#">5.5 Termination resistors</a>.</li> </ul>

### 9.2 CIM 500

You can detect faults in the CIM 500 by observing the status of the two communication LEDs. See the table below and section [4.3 CIM 500 PROFINET IO](#).

#### 9.2.1 LED status

Fault (LED status)	Possible cause	Remedy
1. Both LED1 and LED2 remain off when the power supply is connected.	a) CIM 500 is fitted incorrectly in the Grundfos product.	Check that CIM 500 is fitted/connected correctly.
	b) CIM 500 is defective.	Replace CIM 500.
2. The PROFINET IO LED1 remains off.	a) The protocol selection switch (SW1) has been set in Modbus TCP position	Set the switch to "0".
3. LED2 for internal communication is flashing red.	a) No internal communication between CIM 500 and the Grundfos product.	Check that CIM 500 is fitted correctly in the Grundfos product.
4. LED2 for internal communication is permanently red.	a) CIM 500 does not support the Grundfos product connected.	Contact the nearest Grundfos company.
5. The PROFINET IO LED1 is permanently red.	a) Connected Grundfos product is not supported.	Contact the nearest Grundfos company.
	b) Illegal position of protocol switch (SW1)	Check that the rotary switch SW1 is set to "0".
6. The PROFINET IO LED1 is flashing red.	a) Fault in the CIM 500 PROFINET IO configuration.	<ul style="list-style-type: none"> <li>• Check that the right GSDML file is used. Check that PROFINET IO IP address configuration is correct. See section <a href="#">A.4 PROFINET IO configuration</a> on page 27.</li> <li>• Check device name in the CIM 500 and PROFINET IO master.</li> </ul>
7. The PROFINET IO LED1 is pulsing red.	a) Connection to master lost.	<ul style="list-style-type: none"> <li>• Check cables.</li> <li>• Check that the master is running.</li> </ul>
8. LED1 is permanently red and green at the same time.	a) Error in the firmware download.	Use the webserver to download the firmware again. See section <a href="#">A.2 Web server configuration</a> on page 26.
9. LED2 is permanently red and green at the same time.	a) Memory fault.	Replace CIM 500.

## 10. Grundfos alarm and warning codes

This is a complete list of alarm and warning codes for Grundfos products. For the codes supported by this product, see the alarms and warnings section.

Code	Description	Code	Description	Code	Description
1	Leakage current	36	Outlet valve leakage	71	Motor temperature 2 (Pt100, t_mo2)
2	Missing phase	37	Inlet valve leakage	72	Hardware fault, type 1
3	External fault signal	38	Vent valve defective	73	Hardware shutdown (HSD)
4	Too many restarts	39	Valve stuck or defective	74	Internal supply voltage too high
5	Regenerative braking	40	Undervoltage	75	Internal supply voltage too low
6	Mains fault	41	Undervoltage transient	76	Internal communication fault
7	Too many hardware shutdowns	42	Cut-in fault (dV/dt)	77	Communication fault, twin-head pump
8	PWM switching frequency reduced	43	-	78	Fault, speed plug
9	Phase sequence reversal	44	-	79	Functional fault, add-on module
10	Communication fault, pump	45	Voltage asymmetry	80	Hardware fault, type 2
11	Water-in-oil fault (motor oil)	46	-	81	Verification error, data area (RAM)
12	Time for service (general service information)	47	-	82	Verification error, code area (ROM, FLASH)
13	Moisture alarm, analog	48	Overload	83	Verification error, FE parameter area (EEPROM)
14	Electronic DC-link protection activated (ERP)	49	Overcurrent (i_line, i_dc, i_mo)	84	Memory access error
15	Communication fault, main system (SCADA)	50	Motor-protection function, general shutdown (MPF)	85	Verification error, BE parameter area (EEPROM)
16	Other	51	Blocked motor or pump	86	Fault (add-on) I/O module
17	Performance requirement cannot be met	52	Motor slip high	87	-
18	Commanded alarm standby (trip)	53	Stalled motor	88	Sensor fault
19	Diaphragm break (dosing pump)	54	Motor-protection function, 3 sec. limit	89	Signal fault, (feedback) sensor 1
20	Insulation resistance low	55	Motor current protection activated (MCP)	90	Signal fault, speed sensor
21	Too many starts per hour	56	Underload	91	Signal fault, temperature sensor 1
22	Moisture switch alarm, digital	57	Dry running	92	Calibration fault, (feedback) sensor
23	Smart trim gap alarm	58	Low flow	93	Signal fault, sensor 2
24	Vibration	59	No flow	94	Limit exceeded, sensor 1
25	Setup conflict	60	Low input power	95	Limit exceeded, sensor 2
26	Load continues even if the motor has been switched off	61	-	96	Setpoint signal outside range
27	External motor protector activated (for example MP 204)	62	-	97	Signal fault, setpoint input
28	Battery low	63	-	98	Signal fault, input for setpoint influence
29	Turbine operation (impellers forced backwards)	64	-	99	Signal fault, input for analog setpoint
30	Change bearings (specific service information)	65	Motor temperature 1 (t_m or t_mo or t_mo1)	100	RTC time synchronisation with cellular network occurred
31	Change varistor(s) (specific service information)	66	Temperature, control electronics (t_e)	101	-
32	Overvoltage	67	Temperature too high, internal frequency converter module (t_m)	102	Dosing pump not ready
33	Soon time for service (general service information)	68	External temperature or water temperature (t_w)	103	Emergency stop
34	No priming water	69	Thermal relay 1 in motor, for example Klixon	104	Software shutdown
35	Gas in pump head, de-aerating problem	70	Thermal relay 2 in motor, for example thermistor	105	Electronic rectifier protection activated (ERP)

Code	Description	Code	Description	Code	Description
106	Electronic inverter protection activated (EIP)	141	-	176	Signal fault, temperature sensor 3 (t_mo3)
107	-	142	-	177	Signal fault, Smart trim gap sensor
108	-	143	-	178	Signal fault, vibration sensor
109	-	144	Motor temperature 3 (Pt100, t_mo3)	179	Signal fault, bearing temperature sensor (Pt100), general or top bearing
110	Skew load, electrical asymmetry	145	Bearing temperature high (Pt100), in general or top bearing	180	Signal fault, bearing temperature sensor (Pt100), middle bearing
111	Current asymmetry	146	Bearing temperature high (Pt100), middle bearing	181	Signal fault, PTC sensor (short-circuited)
112	Cosφ too high	147	Bearing temperature high (Pt100), bottom bearing	182	Signal fault, bearing temperature sensor (Pt100), bottom bearing
113	Cosφ too low	148	Motor bearing temperature high (Pt100) in drive end (DE)	183	Signal fault, extra temperature sensor
114	Motor heater function activated (frost protection)	149	Motor bearing temperature high (Pt100) in non-drive end (NDE)	184	Signal fault, general-purpose sensor
115	Too many grinder reversals or grinder reversal attempt failed	150	Fault (add-on) pump module	185	Unknown sensor type
116	Grinder motor overtemperature	151	Fault, display (HMI)	186	Signal fault, power meter sensor
117	Intrusion (door opened)	152	Communication fault, add-on module	187	Signal fault, energy meter
118	Signal fault, hydrogen sulfide H2S sensor	153	Fault, analog output	188	Signal fault, user-defined sensor
119	Signal fault, analog input AI4	154	Communication fault, display	189	Signal fault, level sensor
120	Auxiliary winding fault (single phase motors)	155	Inrush fault	190	Limit exceeded, sensor 1 (for example alarm level in WW application)
121	Auxiliary winding current too high (single-phase motors)	156	Communication fault, internal frequency converter module	191	Limit exceeded, sensor 2 (for example high level in WW application)
122	Auxiliary winding current too low (single-phase motors)	157	Real-time clock out of order	192	Limit exceeded, sensor 3 (for example overflow level in WW application)
123	Start capacitor, low (single-phase motors)	158	Hardware circuit measurement fault	193	Limit exceeded, sensor 4 (for example low level in WW/tank filling application)
124	Run capacitor, low (single-phase motors)	159	CIM fault (Communication Interface Module)	194	Limit exceeded, sensor 5
125	Signal fault, outdoor temperature sensor	160	Cellular modem, SIM card fault	195	Limit exceeded, sensor 6
126	Signal fault, air temperature sensor	161	Sensor supply fault, 5 V	196	Operation with reduced efficiency
127	Signal fault, shunt relative pressure sensor	162	Sensor supply fault, 24 V	197	Operation with reduced pressure
128	Strainer clogged	163	Measurement fault, motor protection	198	Operation with increased power consumption
129	-	164	Signal fault, LiqTec sensor	199	Process out of range (monitoring, estimation, calculation, control)
130	-	165	Signal fault, analog input 1	200	Application alarm
131	-	166	Signal fault, analog input 2	201	External sensor input high
132	-	167	Signal fault, analog input 3	202	External sensor input low
133	-	168	Signal fault, pressure sensor	203	Alarm on all pumps
134	-	169	Signal fault, flow sensor	204	Inconsistency between sensors
135	-	170	Signal fault, water-in-oil (WIO) sensor	205	Level float switch sequence inconsistency
136	-	171	Signal fault, moisture sensor	206	Water shortage, level 1
137	-	172	Signal fault, atmospheric pressure sensor	207	Water leakage
138	-	173	Signal fault, rotor position sensor (Hall sensor)	208	Cavitation
139	-	174	Signal fault, rotor origo sensor	209	Non-return valve fault
140	-	175	Signal fault, temperature sensor 2 (t_mo2)	210	High pressure



Code	Description	Code	Description	Code	Description
211	Low pressure	226	Communication fault, I/O module	241	Motor phase failure
212	Diaphragm tank precharge pressure out of range	227	Combi event	242	Automatic motor model recognition failed
213	VFD not ready	228	Night flow max. limit exceeded	243	Motor relay has been forced (manually operated or commanded)
214	Water shortage, level 2	229	Water on floor	244	Fault, On/Off/Auto switch
215	Soft pressure buildup time-out	230	Network alarm	245	Pump continuous runtime too long
216	Pilot pump alarm	231	Ethernet: No IP address from DHCP server	246	User-defined relay has been forced (manually operated or commanded)
217	Alarm, general-purpose sensor high	232	Ethernet: Auto-disabled due to misuse	247	Power-on notice, (device or system has been switched off)
218	Alarm, general-purpose sensor low	233	Ethernet: IP address conflict	248	Fault, battery/UPS
219	Pressure relief not adequate	234	Backup pump alarm	249	User-defined event 1
220	Fault, motor contactor feedback	235	Gas detected	250	User-defined event 2
221	Fault, mixer contactor feedback	236	Pump 1 fault	251	User-defined event 3
222	Time for service, mixer	237	Pump 2 fault	252	User-defined event 4
223	Time for service, mixer	238	Pump 3 fault	253	SMS data from DDD sensor not received within time limit
224	Pump fault, due to auxiliary component or general fault	239	Pump 4 fault	254	Inconsistent data model
225	Communication fault, pump module	240	Lubricate bearings (specific service information)		

## Appendix

The appendix describes the parts of the CIM 500 web server needed for the configuration of a PROFINET IO Ethernet connection. For other CIM 500 web server features, not specifically related to PROFINET IO, see the installation and operating instructions for the CIM 500.

### A.1 How to configure an IP address on your PC

For connecting a PC to the CIM 500 via Ethernet, the PC must be set up to use a fixed (static) IP address belonging to the same subnetwork as the CIM 500.

1. Open "Control Panel".
2. Enter "Network and Sharing Center".
3. Click "Change adapter settings".
4. Right-click and select "Properties" for Ethernet adapter. Typically "Local Area Connection".
5. Select properties for "Internet Protocol Version 4 (TCP/IPv4)".
6. Select the "Alternate Configuration" tab.
7. Configure an IP address and subnet mask to be used by your PC. See fig. 1.




Fig. 1 Example from Windows XP

### A.2 Web server configuration

The built-in web server is an easy and effective way to monitor the status of the CIM 500 module and configure the available functions and Industrial Ethernet protocols. The web server also makes it possible to update the firmware of the CIM module, and store/restore settings.

#### Before configuration

- Check that the PC and CIM module are connected via an Ethernet cable.
- Check that the PC Ethernet port is set to the same network as the CIM module. For network configuration, see section [A.1 How to configure an IP address on your PC](#).

To establish a connection from a PC to CIM 500 the first time, the following steps are required:

1. Open a standard Internet browser and type 192.168.1.100 in the URL address field.
2. Log in to the web server.

### A.3 Login

Fig. 2 Login

User name	Enter user name. Default: admin.
-----------	----------------------------------

Password	Enter password. Default: Grundfos.
----------	------------------------------------

**Note**

*User name and password can be changed on the web server under "Grundfos Management"*

### A.4 PROFINET IO configuration

This web page is used to configure all the parameters relevant to the PROFINET IO protocol standard. All settings can also be configured from a standard PROFINET IO configuration tool, for instance Siemens Primary Setup Tool (PST). It is available on internet.

Fig. 3 Real Time Ethernet Protocol Configuration - PROFINET IO

Object	Description
Device Name	The PROFINET IO device name. It must be unique.
IP Address	The static IP address for CIM 500 on the PROFINET IO network.
Subnet Mask	Configure the subnet mask for the CIM 500 module on the PROFINET IO network.
Gateway	Configure the default gateway for the PROFINET IO network.
Use DHCP	The CIM 500 module can be configured to automatically obtain the IP address from a DHCP server on the network.
Grundfos product simulation	The CIM 500 can be put in product simulation mode to generate realistic simulated values of all the PROFINET IO input data modules. It will thus be possible to connect a PROFINET IO master to a CIM 500 fitted in a CIU or E-box without installing this device in a real industrial process system. In an office environment, it can then be verified that communication works and data are received and handled correctly by the PROFINET IO master application program (e.g. PLC program) before installing the device. To enable product simulation, select a product type from the drop down list. Product simulation will be terminated by a module power cycle.

TM05 6063 4412

TM05 6065 4412



**Argentina**

Bombas GRUNDFOS de Argentina S.A.  
Ruta Panamericana km. 37.500 Centro  
Industrial Garin  
1619 Garin Pcia. de B.A.  
Phone: +54-3327 414 444  
Telefax: +54-3327 45 3190

**Australia**

GRUNDFOS Pumps Pty. Ltd.  
P.O. Box 2040  
Regency Park  
South Australia 5942  
Phone: +61-8-8461-4611  
Telefax: +61-8-8340 0155

**Austria**

GRUNDFOS Pumpen Vertrieb Ges.m.b.H.  
Grundfosstraße 2  
A-5082 Grödig/Salzburg  
Tel.: +43-6246-883-0  
Telefax: +43-6246-883-30

**Belgium**

N.V. GRUNDFOS Bellux S.A.  
Boomssesteenweg 81-83  
B-2630 Aartselaar  
Tél.: +32-3-870 7300  
Télécopie: +32-3-870 7301

**Belarus**

Представительство ГРУНДФОС в  
Минске  
220125, Минск  
ул. Шафарнянская, 11, оф. 56, БЦ  
«Порт»  
Тел.: +7 (375 17) 286 39 72/73  
Факс: +7 (375 17) 286 39 71  
E-mail: minsk@grundfos.com

**Bosnia and Herzegovina**

GRUNDFOS Sarajevo  
Zmaja od Bosne 7-7A,  
BH-71000 Sarajevo  
Phone: +387 33 592 480  
Telefax: +387 33 590 465  
www.ba.grundfos.com  
e-mail: grundfos@bih.net.ba

**Brazil**

BOMBAS GRUNDFOS DO BRASIL  
Av. Humberto de Alencar Castelo Branco,  
630  
CEP 09850 - 300  
São Bernardo do Campo - SP  
Phone: +55-11 4393 5533  
Telefax: +55-11 4343 5015

**Bulgaria**

Grundfos Bulgaria EOOD  
Slatina District  
Iztochna Tangenta street no. 100  
BG - 1592 Sofia  
Tel. +359 2 49 22 200  
Fax. +359 2 49 22 201  
email: bulgaria@grundfos.bg

**Canada**

GRUNDFOS Canada Inc.  
2941 Brighton Road  
Oakville, Ontario  
L6H 6C9  
Phone: +1-905 829 9533  
Telefax: +1-905 829 9512

**China**

GRUNDFOS Pumps (Shanghai) Co. Ltd.  
10F The Hub, No. 33 Suhong Road  
Minhang District  
Shanghai 201106  
PRC  
Phone: +86 21 612 252 22  
Telefax: +86 21 612 253 33

**COLOMBIA**

GRUNDFOS Colombia S.A.S.  
Km 1.5 vía Siberia-Cota Conj. Potrero  
Chico,  
Parque Empresarial Arcos de Cota Bod.  
1A.  
Cota, Cundinamarca  
Phone: +57(1)-2913444  
Telefax: +57(1)-8764586

**Croatia**

GRUNDFOS CROATIA d.o.o.  
Buzinski prilaz 38, Buzin  
HR-10010 Zagreb  
Phone: +385 1 6595 400  
Telefax: +385 1 6595 499  
www.hr.grundfos.com

**GRUNDFOS Sales Czechia and Slovakia s.r.o.**

Čajkovského 21  
779 00 Olomouc  
Phone: +420-585-716 111

**Denmark**

GRUNDFOS DK A/S  
Martin Bachs Vej 3  
DK-8850 Bjerringbro  
Tlf.: +45-87 50 50 50  
Telefax: +45-87 50 51 51  
E-mail: info\_GDK@grundfos.com  
www.grundfos.com/DK

**Estonia**

GRUNDFOS Pumps Eesti OÜ  
Peterburi tee 92G  
11415 Tallinn  
Tel: + 372 606 1690  
Fax: + 372 606 1691

**Finland**

OY GRUNDFOS Pumpat AB  
Trukkikuja 1  
FI-01360 Vantaa  
Phone: +358-(0) 207 889 500

**France**

Pompes GRUNDFOS Distribution S.A.  
Parc d'Activités de Chesnes  
57, rue de Malacombe  
F-38290 St. Quentin Fallavier (Lyon)  
Tél.: +33-4 74 82 15 15  
Télécopie: +33-4 74 94 10 51

**Germany**

GRUNDFOS GMBH  
Schlüterstr. 33  
40699 Erkrath  
Tel.: +49-(0) 211 929 69-0  
Telefax: +49-(0) 211 929 69-3799  
e-mail: infoservice@grundfos.de  
Service in Deutschland:  
e-mail: kundendienst@grundfos.de

**Greece**

GRUNDFOS Hellas A.E.B.E.  
20th km. Athinon-Markopoulou Av.  
P.O. Box 71  
GR-19002 Peania  
Phone: +0030-210-66 83 400  
Telefax: +0030-210-66 46 273

**Hong Kong**

GRUNDFOS Pumps (Hong Kong) Ltd.  
Unit 1, Ground floor  
Siu Wai Industrial Centre  
29-33 Wing Hong Street &  
68 King Lam Street, Cheung Sha Wan  
Kowloon  
Phone: +852-27861706 / 27861741  
Telefax: +852-27858664

**Hungary**

GRUNDFOS Hungária Kft.  
Tópark u. 8  
H-2045 Törökbálint,  
Phone: +36-23 511 110  
Telefax: +36-23 511 111

**India**

GRUNDFOS Pumps India Private Limited  
118 Old Mahabalipuram Road  
Thoraiakkam  
Chennai 600 096  
Phone: +91-44 2496 6800

**Indonesia**

PT. GRUNDFOS POMPA  
Graha Intirub Lt. 2 & 3  
Jln. Cililitan Besar No.454. Makasar,  
Jakarta Timur  
ID-Jakarta 13650  
Phone: +62 21-469-51900  
Telefax: +62 21-460 6910 / 460 6901

**Ireland**

GRUNDFOS (Ireland) Ltd.  
Unit A, Merrywell Business Park  
Ballymount Road Lower  
Dublin 12  
Phone: +353-1-4089 800  
Telefax: +353-1-4089 830

**Italy**

GRUNDFOS Pompe Italia S.r.l.  
Via Gran Sasso 4  
I-20060 Truccazzano (Milano)  
Tel.: +39-02-95838112  
Telefax: +39-02-95309290 / 95838461

**Japan**

GRUNDFOS Pumps K.K.  
1-2-3, Shin-Miyakoda, Kita-ku,  
Hamamatsu  
431-2103 Japan  
Phone: +81 53 428 4760  
Telefax: +81 53 428 5005

**Korea**

GRUNDFOS Pumps Korea Ltd.  
6th Floor, Aju Building 679-5  
Yeoksam-dong, Kangnam-ku, 135-916  
Seoul, Korea  
Phone: +82-2-5317 600  
Telefax: +82-2-5633 725

**Latvia**

SIA GRUNDFOS Pumps Latvia  
Deglava biznesa centrs  
Augusta Deglava ielā 60, LV-1035, Rīga,  
Tālr.: + 371 714 9640, 7 149 641  
Fakss: + 371 914 9646

**Lithuania**

GRUNDFOS Pumps UAB  
Smolensko g. 6  
LT-03201 Vilnius  
Tel: + 370 52 395 430  
Fax: + 370 52 395 431

**Malaysia**

GRUNDFOS Pumps Sdn. Bhd.  
7 Jalan Peguam U1/25  
Glenmarie Industrial Park  
40150 Shah Alam  
Selangor  
Phone: +60-3-5569 2922  
Telefax: +60-3-5569 2866

**Mexico**

Bombas GRUNDFOS de México S.A. de  
C.V.  
Boulevard TLC No. 15  
Parque Industrial Stiva Aeropuerto  
Apodaca, N.L. 66600  
Phone: +52-81-8144 4000  
Telefax: +52-81-8144 4010

**Netherlands**

GRUNDFOS Netherlands  
Veluwezoom 35  
1326 AE Almere  
Postbus 22015  
1302 CA ALMERE  
Tel.: +31-88-478 6336  
Telefax: +31-88-478 6332  
E-mail: info\_gnl@grundfos.com

**New Zealand**

GRUNDFOS Pumps NZ Ltd.  
17 Beatrice Tinsley Crescent  
North Harbour Industrial Estate  
Albany, Auckland  
Phone: +64-9-415 3240  
Telefax: +64-9-415 3250

**Norway**

GRUNDFOS Pumper A/S  
Strømsveien 344  
Postboks 235, Leirdal  
N-1011 Oslo  
Tlf.: +47-22 90 47 00  
Telefax: +47-22 32 21 50

**Poland**

GRUNDFOS Pompy Sp. z o.o.  
ul. Klonowa 23  
Baranowo k. Poznania  
PL-62-081 Przeźmierowo  
Tel: (+48-61) 650 13 00  
Fax: (+48-61) 650 13 50

**Portugal**

Bombas GRUNDFOS Portugal, S.A.  
Rua Calvet de Magalhães, 241  
Apartado 1079  
P-2770-153 Paço de Arcos  
Tel.: +351-21-440 76 00  
Telefax: +351-21-440 76 90

**Romania**

GRUNDFOS Pompe România SRL  
Bd. Biruintei, nr 103  
Pantelimon county Ilfov  
Phone: +40 21 200 4100  
Telefax: +40 21 200 4101  
E-mail: romania@grundfos.ro

**Russia**

ООО Грундфос Россия  
ул. Школьная, 39-41  
Москва, RU-109544, Russia  
Тел. (+7) 495 564-88-00 (495) 737-30-00  
Факс (+7) 495 564 8811  
E-mail grundfos.moscow@grundfos.com

**Serbia**

Grundfos Srbija d.o.o.  
Omladinskih brigada 90b  
11070 Novi Beograd  
Phone: +381 11 2258 740  
Telefax: +381 11 2281 769  
www.rs.grundfos.com

**Singapore**

GRUNDFOS (Singapore) Pte. Ltd.  
25 Jalan Tukang  
Singapore 619264  
Phone: +65-6681 9688  
Telefax: +65-6681 9689

**Slovakia**

GRUNDFOS s.r.o.  
Prievozská 4D  
821 09 BRATISLAVA  
Phona: +421 2 5020 1426  
sk.grundfos.com

**Slovenia**

GRUNDFOS LJUBLJANA, d.o.o.  
Leskoškova 9e, 1122 Ljubljana  
Phone: +386 (0) 1 568 06 10  
Telefax: +386 (0) 1 568 06 19  
E-mail: tehnika-si@grundfos.com

**South Africa**

Grundfos (PTY) Ltd.  
16 Lascelles Drive, Meadowbrook Estate  
1609 Germiston, Johannesburg  
Tel.: (+27) 10 248 6000  
Fax: (+27) 10 248 6002  
E-mail: lgradidge@grundfos.com

**Spain**

Bombas GRUNDFOS España S.A.  
Camino de la Fuentequilla, s/n  
E-28110 Algiete (Madrid)  
Tel.: +34-91-848 8800  
Telefax: +34-91-628 0465

**Sweden**

GRUNDFOS AB  
Box 333 (Lunnagårdsgatan 6)  
431 24 Mölndal  
Tel.: +46 31 332 23 000  
Telefax: +46 31 331 94 60

**Switzerland**

GRUNDFOS Pumpen AG  
Bruggacherstrasse 10  
CH-8117 Fällanden/ZH  
Tel.: +41-44-806 8111  
Telefax: +41-44-806 8115

**Taiwan**

GRUNDFOS Pumps (Taiwan) Ltd.  
7 Floor, 219 Min-Chuan Road  
Taichung, Taiwan, R.O.C.  
Phone: +886-4-2305 0868  
Telefax: +886-4-2305 0878

**Thailand**

GRUNDFOS (Thailand) Ltd.  
92 Chaloe Phrakiat Rama 9 Road,  
Dokmai, Pravej, Bangkok 10250  
Phone: +66-2-725 8999  
Telefax: +66-2-725 8998

**Turkey**

GRUNDFOS POMPA San. ve Tic. Ltd. Sti.  
Gebze Organize Sanayi Bölgesi  
Ihsan dede Caddesi,  
2. yol 200. Sokak No. 204  
41490 Gebze/ Kocaeli  
Phone: +90 - 262-679 7979  
Telefax: +90 - 262-679 7905  
E-mail: satis@grundfos.com

**Ukraine**

Бізнес Центр Європа  
Столицне шосе, 103  
м. Київ, 03131, Україна  
Телефон: (+38 044) 237 04 00  
Факс.: (+38 044) 237 04 01  
E-mail: ukraine@grundfos.com

**United Arab Emirates**

GRUNDFOS Gulf Distribution  
P.O. Box 16768  
Jebel Ali Free Zone  
Dubai  
Phone: +971 4 8815 166  
Telefax: +971 4 8815 136

**United Kingdom**

GRUNDFOS Pumps Ltd.  
Grovebury Road  
Leighton Buzzard/Beds. LU7 4TL  
Phone: +44-1525-850000  
Telefax: +44-1525-850011

**U.S.A.**

GRUNDFOS Pumps Corporation  
9300 Loiret Blvd.  
Lenexa, Kansas 66219  
Phone: +1-913-227-3400  
Telefax: +1-913-227-3500

**Uzbekistan**

Grundfos Tashkent, Uzbekistan The Repre-  
sentative Office of Grundfos Kazakhstan in  
Uzbekistan  
38a, Oybek street, Tashkent  
Телефон: (+998) 71 150 3290 / 71 150  
3291  
Факс: (+998) 71 150 3292

Addresses Revised 15.01.2019

<b>98125976</b> 1119
----------------------

ECM: 1271284
--------------

Trademarks displayed in this material, including but not limited to Grundfos, the Grundfos logo and "be think innovate" are registered trademarks owned by The Grundfos Group. All rights reserved. © 2019 Grundfos Holding A/S, all rights reserved.