

Servomotors

Installation and operating instructions



English (GB) Installation and operating instructions

Original installation and operating instructions

CONTENTS

	Page
1. Symbols used in this document	2
2. General information	2
2.1 Service documentation	2
3. Applications	2
3.1 Appropriate, acceptable and correct usage	2
4. Safety	3
4.1 Qualification and training of personnel	3
4.2 Risks when safety instructions are not observed	3
4.3 Safety-conscious working	3
4.4 Safety instructions for the operator/ user	3
4.5 Safety instructions for maintenance, inspection and installation work	3
4.6 Unauthorised modification and manufacture of spare parts	3
4.7 Improper operating methods	3
5. Device description	4
5.1 Versions	4
5.2 Variants	4
6. Technical data	5
6.1 General data	6
6.2 Dimensional drawings	6
7. Transport and storage	7
7.1 Unpacking	7
7.2 Storage/Downtimes	7
8. Installation	7
8.1 General notes	7
8.2 Retrofitting a dosing pump with an electrical servomotor	7
8.3 Installation	9
9. Electrical connections	9
9.1 General warnings and notes on the electrical connection	9
10. Commissioning	10
10.1 Checks before commissioning	10
11. Operation	10
12. Maintenance	10
13. Disposal	10



Warning

These installation and operating instructions are also available on www.grundfos.com.

Prior to installation, read these installation and operating instructions. Installation and operation must comply with local regulations and accepted codes of good practice.

Warning

In addition to these instructions, observe all installation and operating instructions supplied with the pump.



Observe the supplier manual "TBasic_BA" for the servomotor provided with the product.

1. Symbols used in this document



Warning

If these safety instructions are not observed, it may result in personal injury.



If these safety instructions are not observed, it may result in malfunction or damage to the equipment.



Notes or instructions that make the job easier and ensure safe operation.

2. General information

If you require further information or if any problems arise, which are not described in detail in this manual, please contact the nearest Grundfos Water Treatment company.

Observe the supplier manual "TBasic_BA" for the servomotor provided with the product.

2.1 Service documentation

If you have any questions, please contact the nearest Grundfos company or service workshop.

3. Applications

3.1 Appropriate, acceptable and correct usage

Servomotors from Grundfos, series 384, are intended for automatically setting the stroke length and, thus, the dosing flow of Grundfos DMX and DMH series dosing pumps, as described in these instructions.



Warning

Only use the servomotor for the specified pump types!



No other applications are approved or permitted. Grundfos is not liable for damage resulting from incorrect use.

4. Safety

This manual contains general instructions that must be observed during installation, operation and maintenance of the servomotor. This manual must therefore be read by the installation engineer and the relevant qualified personnel/operators prior to installation and start-up, and must be available at the installation location of the servomotor at all times.

It is not only the general safety instructions given in this "Safety" section that must be observed, but also all the specific safety instructions given in other sections.

Information provided directly on the servomotor must be observed and must be maintained in a readable condition at all times.

4.1 Qualification and training of personnel

The personnel responsible for the operation, maintenance, inspection and installation must be appropriately qualified for these tasks. Areas of responsibility, levels of authority and the supervision of the personnel must be precisely defined by the operator.

If the personnel do not have the necessary knowledge, the necessary training and instruction must be given. If necessary, training can be performed by the manufacturer/supplier at the request of the operator of the servomotor. It is the responsibility of the operator to make sure that the contents of this manual are understood by the personnel.

4.2 Risks when safety instructions are not observed

Non-observance of the safety instructions may have dangerous consequences for the personnel, the environment and the device. If the safety instructions are not observed, all rights to claims for damages may be lost.

Non-observance of the safety instructions may lead to the following hazards:

- failure of important functions of the pump/system
- failure of specified methods for maintenance
- harm to humans from exposure to electrical, mechanical and chemical influences
- damage to the environment from leakage of harmful substances.

4.3 Safety-conscious working

The safety instructions in this manual, applicable national health and safety regulations and any operator internal working, operating and safety regulations must be observed.

4.4 Safety instructions for the operator/user

Hazardous hot or cold parts on the servomotor must be protected to prevent accidental contact.

Damage caused by electrical energy must be prevented (for more details, see for example the regulations of the VDE and the local electricity supply company).

4.5 Safety instructions for maintenance, inspection and installation work

The operator must ensure that all maintenance, inspection and installation work is carried out by authorised and qualified personnel, who have been adequately trained by reading this manual.

All work on the servomotor should only be carried out when the device is stopped.

All safety and protective equipment must be immediately restarted or put into operation once work is complete.

Observe the points described in the initial start-up section prior to subsequent start-up.

Warning

 Electrical connections must only be carried out by qualified personnel.

Repairs must only be carried out by authorised and qualified personnel.

Warning

When dosing dangerous media, the corresponding safety data sheets must be observed.

 Wear protective clothing (gloves and protective glasses) if required.

Before installing the servomotor, switch off the pump and disconnect it from the mains.

Caution The stroke length of a DMX pump must only be set when the pump is running.

4.6 Unauthorised modification and manufacture of spare parts

Modification or changes to the device are only permitted following agreement with the manufacturer. Original spare parts and accessories authorised by the manufacturer are safe to use.

Using other parts can result in liability for any resulting consequences.

4.7 Improper operating methods

The operational safety of the supplied device is only ensured if it is used in accordance with section

6. Technical data. The specified limit values must under no circumstances be exceeded.

5. Device description

5.1 Versions

If a servomotor is ordered together with a dosing pump, the servomotor is fitted onto the pump at the factory and subjected to a function test. Once on site, qualified specialist staff must establish the relevant electrical connection.

Servomotors can also be supplied for retrofitting on a dosing pump, together with the necessary mounting material. Such servomotors also undergo testing at the factory prior to delivery. Qualified specialist staff must fit the servomotor onto the dosing pump and establish the electrical connection.

5.2.3 Versions, servomotor product numbers and corresponding pump types

A servomotor kit includes servomotor and mounting material. A spare servomotor is delivered without mounting material.

Servomotor series	for pump type	Pump type key, control variant	Control variant	Power supply	Servo-motor kit	Spare servomotor
384-511	DMH 251-257, DMH 280-288	D3	analogue control	115-230 V, 50/60 Hz	95721977	98721200
384-511	DMH 251-257, DMH 280-288	D4	analogue control	24 VDC, 50/60 Hz	95736296	98721222
384-711	DMX 221	D3	analogue control	115-230 V, 50/60 Hz	95725108	98721200
384-711	DMX 221	D4	analogue control	24 VDC, 50/60 Hz	95736495	98721222
384-712	DMX 226L	D3	analogue control	115-230 V, 50/60 Hz	95725109	98721200
384-712	DMX 226L	D4	analogue control	24 VDC, 50/60 Hz	95736497	98721222
384-714	DMX 226L/2	D3	analogue control	115-230 V, 50/60 Hz	95736502	98721200
384-714	DMX 226L/2	D4	analogue control	24 VAC, 50/60 Hz	95736503	98721222
384-715	DMX 226M	D3	analogue control	115-230 V, 50/60 Hz	95725666	98721200
384-715	DMX 226M	D4	analogue control	24 VDC, 50/60 Hz	95736504	98721222
384-717	DMX 226M/2	D3	analogue control	115-230 V, 50/60 Hz	95736511	98721200
384-717	DMX 226M/2	D4	analogue control	24 VAC, 50/60 Hz	95736513	98721222

5.2.4 Spare servomotor, control variant: reversing potentiometer

Servomotor series	for pump type	Power supply	Control variant	Spare servomotor
384-all	DMH 251-257, DMH 280-288, DMX 221/226L+M	230 V 50/60 Hz 115 V 50/60 Hz 24 V 50/60 Hz	reversing potentiometer	98721196 98721198 98721199

DMX 226 groups

DMX 226 group M	DMX 226 group L
DMX 24-8	DMX 67-10
DMX 37-5	DMX 95-8
DMX 52-8	DMX 132-10
DMX 60-3	DMX 152-6
DMX 82-5	DMX 190-8
DMX 100-8	DMX 190-10
DMX 130-3	DMX 199-8
DMX 142-8	DMX 249-3
DMX 160-5	DMX 280-6
DMX 224-5	DMX 280-8
DMX 255-3	DMX 321-4
DMX 380-3	DMX 321-6
-	DMX 460-3.5
-	DMX 460-6
-	DMX 315-3
-	DMX 525-3
-	DMX 765-3

5.2.5 Function of a servomotor with analogue control


The microprocessor controller is integrated in the drive housing. The controller positions the drive based on a guide value (setpoint in mA signal) and compares the specified setpoint with the actual drive position (actual value). If the two values differ, the drive is moved to the position determined by the setpoint. The actual value is generated by a potentiometer integrated in the drive.

Any positions can be assigned to 4 (0) mA and 20 mA at any time. The lower and upper current limits (4 (0)/20 mA) are pre-programmed and cannot be changed. The control direction can also be reversed using a DIP switch " /inv".

5.2.6 Function of a spare servomotor with reversing potentiometer

The drive is positioned at the relevant terminals (motor control open/closed) for the corresponding direction of rotation by switching the supply voltage on/off. The reversing potentiometer returns the current position of the servomotor to the controller; the position is held when the setpoint is reached.

Observe the supplier manual for the servomotor provided with the product.

6. Technical data

TM07 5417 4019

Fig. 1 Servomotor with analogue control**Item Description**

- | | |
|---|--------------------------------------|
| 1 | Programming buttons |
| 2 | Alarm output |
| 3 | LEDs |
| 4 | DIP switch |
| 5 | Mains connection terminals |
| 6 | Analogue signal connection terminals |
| 7 | Manual adjusting switch |
| 8 | Earth terminal |

6.1 General data

Ambient and operating conditions

- Permissible ambient temperature: 0 °C to +55 °C.
- Permissible air humidity: max. relative humidity: 70 % at 40 °C, 90 % at 35 °C.

Housing

- Materials:
 - Housing: Die-cast zinc
 - Hood: Plastic
- Colour: Black
- Degree of protection in acc. with DIN EN 60529: IP65

Power supply

- 115-230 V ± 10 %, 50/60 Hz ± 5 %, 100 % on time (standard)
- 24 VDC ± 10 %, 50/60 Hz ± 5 %
- Insulation class E in acc. with EN60085

Adjustment angle

- 270 °

Power consumption

- Max. 2 VA

Actuating time

- 90 seconds (50 Hz), 75 seconds (60 Hz) for DMH pumps
- > 90 seconds for DMX 221 and DMX 226 pumps. The exact actuating time cannot be specified for DMX pumps, as it will depend on the technical properties of the pump in question.

Weight

- Approximately 2.6 kg

6.1.1 Servomotor with analogue control

Control variant

- Analogue control
- Input/output
 - 4-20 mA (standard setting)
 - 0-20 mA (switchable)

Setpoint input


- 4 (0) - 20 mA (DC)
- Load 250 Ω
- Overload protection 25 mA
- Protection against reverse polarity to -25 mA
- ESD protection, input filter
- Resolution: 12 bits

Actual value output

- Fixed limits: 0-20 mA or 4-20 mA
- Current sink: Max. load 500 Ω
- Resolution: 10 bits

6.2 Dimensional drawings

Servomotor series 384-511 to 513




TM07 6220 1120

Fig. 2 Servomotor series 384-511 to 513

Servomotor series	L1
384-511	228
384-512	215
384-513	227

Dimensions in mm

Servomotor series 384-711 to 717



TM07 6221 1120

Fig. 3 Servomotor series 384-711 to 717

Servomotor series	L1
384-711	208
384-712 - 384-714	227
384-715 - 384-717	228

Dimensions in mm

7. Transport and storage

Only transport drives in their original packaging. Do not use the protective packaging as packaging for transport.

Caution

Do not subject drives to severe vibrations.
Do not throw or drop the servomotor.

If a pump is ordered together with a servomotor, the servomotor is fitted onto the dosing pump so that it is ready for connection.

Note

7.1 Unpacking

- Retain the packaging for future storage or return, or dispose of the packaging in accordance with local regulations.
- Fit the servomotor as soon as possible after unpacking it.

7.2 Storage/Downtimes

- Store the servomotor in a well ventilated, dry room on a pallet or rack (protected from moisture). Cover it with foil to protect it from dust and dirt.
- Prevent condensation from forming (e.g. if the temperature fluctuates).

If the servomotor is to be stored for longer than 4 months, observe the following points too:

- Insert a layer of absorbent material underneath the drive's cover.

Keep the servomotor in a dry, cool place.

8. Installation

8.1 General notes

Warning

It is a basic fact that certain parts will carry a dangerous voltage whenever electrical devices are operated. Only electricians or trained persons instructed and supervised by a specialist electrician may carry out work on electrical installations or equipment and the relevant electrotechnical rules must be observed.

Warning

When undertaking installation, commissioning and testing work, all applicable safety and accident prevention regulations must always be observed.

Warning

Before you start any (installation) work of any kind on the drive, make sure that all affected machines/installations are switched off.

Note

It is essential that you read this instruction manual prior to carrying out installation and commissioning.



Warning

The servomotor may only be fitted by a qualified specialist.



If a pump is ordered together with a servomotor, the servomotor is fitted onto the dosing pump so that it is ready for connection.

8.2 Retrofitting a dosing pump with an electrical servomotor

Warning

When retrofitting a dosing pump with an electrical servomotor, you must observe the instructions and warnings contained in section 9. *Electrical connections*, section 10. *Commissioning* and section 11. *Operation*.

Scope of delivery of the electrical servomotor

Lantern, front plate, scale ring with screw, coupling (three parts) with two grub screws. Holding screws for lantern and servomotor.

Required tools

Hexagon socket wrench 2 mm, 2.5 mm, 5 mm, screwdriver

Checking the 0 % position

The servomotor is set to the 0 % position prior to delivery. However, for safety's sake this 0 % position must be checked and, if necessary, corrected.


Observe the supplier manual "TBasic_BA" for the servomotor provided with the product.

1. Connect the pump to the electrical mains.
2. Switch on the mains.
3. Turn the pump's stroke adjustment button to the 0 % position.
4. Switch off the mains.

Removing the pump's front plate

1. Remove the cap from the adjustment button.
2. For DMX: Unscrew the locking screw on the side of the adjustment button.
3. Remove the holding screw and pull the adjustment button straight out.
 - Make sure that you do not alter the 0 % position.
4. Remove the front plate.

Installation sketch for the electrical servomotor



TM07 6222 1120

Fig. 4 Installing the servomotor (using the example of a DMH pump)




Fig. 5 Coupling

Item	Description
1	Pump
2	Adjusting spindle (grooved dowel)
3	Coupling
4	Lantern
5	Screw
6	Nut and intermediate disk
7	Scale ring
8	Grub screw
9	Servomotor

Fitting the servomotor to the lantern

- Push the coupling section (3c) onto the shaft of the servomotor (9) and screw the grub screw (3d) in loosely.
- Use four nuts and intermediate disks (6) to fix the lantern onto the servomotor's grub screws.

Fitting the servomotor and lantern to the pump

- For DMX: Attach the front plate supplied.
- Fit the coupling section (3a) onto the adjusting spindle (2).
- Hold the servomotor and lantern on the pump.
- Insert the scale ring (7) and coupling section (3b) (carrier) through the side of the lantern. Push one coupling section (3b) onto the other coupling section (3a) so it is in the correct position (see fig. 4) and hold it in place with one hand.

Caution The spindle must not rotate during this process.

- Turn coupling section (3c) on the shaft so that it engages in the groove on coupling section (3b).
- Use the grub screw (3d) to fix the coupling section (3c) onto the shaft of the servomotor.
- Fit the lantern using three screws (DMX) or four screws (DMH) (5).
- Match up the 0 % position of the scale ring (7) with the marking pin on the lantern and tighten the grub screw (8).

Connecting and commissioning the servomotor

Establish the servomotor's electrical connections as described in section [9. Electrical connections](#).

Commission the pump and servomotor, observing the information contained in the instruction manual; see also section [10. Commissioning](#).

8.3 Installation



Warning

Never install a damaged drive.

- Note** Observe the installation and operating instructions for the dosing pump.

8.3.1 General notes on installation

- Remove any anti-corrosion agent (that may have been used for storage purposes) and apply grease instead.
- Check the cable entries and dummy plugs for tightness.
- Tighten the hood screws so they are all equally tight.
- Protect the drive from the effects of the weather (by means of a canopy, for example).
- Do not attach any ropes, hooks or similar directly to the drive.
- Continuously overloading and blocking the drive will damage it.
- Spark-quenching capacitors may adversely affect the drives' direction of rotation stability and result in damage.

Cable entries

- When storing, installing and commissioning the servomotor, care must be taken to ensure that the cable entries have been properly sealed. Only cables appropriate for the diameter of the cable entries must be used.

Installing the hood

- When installing the hood, you must ensure that the O-rings underneath the hood screws and the O-ring in the drive housing are properly seated.
- The connection face of the hood must not show any signs of damage.
- Tighten the hood screws equally.

Housing/Hood

- No additional bores may be drilled into the drive housing or the hood.

9. Electrical connections

9.1 General warnings and notes on the electrical connection

Observe the supplier manual "TBasic_BA" for the servomotor provided with the product.

Warning

Electrical connections may only be established by qualified staff.



Before opening housing, disconnect the servomotor from the power supply.

Observe the local safety regulations.

Protect the cable connections and plugs from corrosion and moisture.



Warning

The applicable regulations must be observed when carrying out electrical installation and commissioning work.



Warning

Protective measures must be put in place in accordance with the relevant VDE guidelines and power supply company regulations. In particular, VDE guideline 0105, "Working on live installations", must be taken into account.



Warning

All elements, such as switch cams, switches, potentiometers, relays, etc., are wired at the factory. The internal wiring must never be modified.



Warning

The terminals at the limit switches are live when the switch closes.



Warning

The following must be taken into account for explosion-protection servomotors and pumps.

Danger of explosion!

Only use high-strength cable glands appropriate for the cable size.

Attach suitable caps to unused openings.



Switch cams and limit switches are set at the factory and must not be modified.



Before connecting the mains cable, check whether the type of current, the supply voltage and the frequency stated on the type plate match the local conditions.

An incorrect supply voltage may destroy the servomotor.



To ensure electromagnetic compatibility (EMC), the signal cables must be shielded.

The screen must be connected on one side to PE (earth) or to the housing earth (earth terminal).

Lay signal and mains cables in separate cable channels.



For parallel operation: If several drives are controlled via a shared contact, e.g. if there are two servomotors on one duplex pump, every drive must be equipped with a relay for parallel operation.



Lay the mains supply lines with cross-sections that conform to the relevant VDE guidelines.

Note Use separate, shielded lines for low voltages (e.g. potentiometers, analogue signals).

Note Use screwed cable joints appropriate for the connection line.

Note The stated degree of protection can only be ensured if suitable screwed cable joints are used.



Warning

The internal wiring of the drive must never be modified.

10. Commissioning



Warning

The drive may only be commissioned if the hood and cable entries are properly closed.



Warning

Please note that the process of commissioning the drive will cause associated fittings/levers/rodding to move.



Warning

Check that all emergency equipment/functions on your machine/installation are working correctly.



Warning

Once all adjustment work has been completed, check that the drive and the fittings/levers, etc. operated by it are working correctly.



Warning

Never work with a damaged drive.



Caution When commissioning, all the installation's components must be ready for operation.



Note Follow the installation and operating instructions for the components used.

10.1 Checks before commissioning



Caution Before setting the servomotor to automatic operation, check the min./max. position and the direction of rotation.

10.1.1 Checking the direction of rotation

The servomotor is controlled by an external controller. This means that the servomotor's direction of rotation depends on the controller's cabling and settings being correct.

Note Observe the installation and operating instructions for the controller and the dosing pump.

11. Operation

Observe the supplier manual "TBasic_BA" for the servomotor provided with the product.



Warning

The terminals at the limit switches are live when the switch closes.

**Caution**

Switch cams and limit switches are set at the factory and must not be modified.



Warning

Do not touch bare wires or clamping screws.

12. Maintenance



Note The servomotor features permanent lubrication and is maintenance-free.



Warning

Switch off the entire installation before any repair work is carried out.



Disconnect the supply voltage before opening the housing.

13. Disposal

This product or parts of it must be disposed of in an environmentally sound way:

1. Use the public or private waste collection service.
2. If this is not possible, contact the nearest Grundfos company or service workshop.



The crossed-out wheelie bin symbol on a product means that it must be disposed of separately from household waste. When a product marked with this symbol reaches its end of life, take it to a collection point designated by the local waste disposal authorities. The separate collection and recycling of such products will help protect the environment and human health.

See also end-of-life information at www.grundfos.com/product-recycling.

Declaration of conformity

GB: EC/EU manufacturer's declaration

We, Grundfos, declare under our sole responsibility that the product Servomotor 384, to which the declaration below relates, is in conformity with the Council Directives listed below on the approximation of the laws of the EC/EU member states.

DE: EG-/EU-Herstellererklärung

Wir, Grundfos, erklären in alleiniger Verantwortung, dass das Produkt Servomotor 384, auf das sich diese Erklärung bezieht, mit den folgenden Richtlinien des Rates zur Angleichung der Rechtsvorschriften der EG-/EU-Mitgliedsstaaten übereinstimmt.

FR: Déclaration du fabricant CE/UE

Nous, Grundfos, déclarons sous notre seule responsabilité, que le produit Servomotor 384, auquel se réfère cette déclaration, est conforme aux Directives du Conseil concernant le rapprochement des législations des États membres CE/UE relatives aux normes énoncées ci-dessous.

HR: EC/EU Izjava proizvođača

Mi, Grundfos, izjavljujemo s punom odgovornošću da je proizvod Servomotor 384, na koja se izjava odnosi u nastavku, u skladu s direktivama Vijeća dolje navedenih o usklajivanju zakona država članica EZ-a / EU-a.

IT: Dichiarazione del produttore CE/UE

Grundfos dichiara sotto la sua esclusiva responsabilità che il prodotto Servomotor 384, al quale si riferisce questa dichiarazione, è conforme alle seguenti direttive del Consiglio riguardanti il riavvicinamento delle legislazioni degli Stati membri CE/UE.

PL: Deklaracja producenta WE/UE

My, Grundfos, oświadczamy z pełną odpowiedzialnością, że nasz produkt Servomotor 384, którego deklaracja niniejsza dotyczy, jest zgodny z następującymi dyrektywami Rady w sprawie zbliżenia przepisów prawnych państw członkowskich.

RU: Декларация производителя ЕЭС/ЕС

Мы, компания Grundfos, со всей ответственностью заявляем, что изделие Servomotor 384, к которому относится настоящая декларация, соответствует нижеприведенным директивам Совета Европейского Союза о тождественности законов стран-членов ЕЭС/ЕС.

TR: EC/AB İmalatçı beyanı

Grundfos olarak, aşağıdaki bildirim konusu olan Servomotor 384 ürünlerinin, EC/AB üye ülkelerinin direktiflerinin yaklaştırılmasıyla ilgili durumun aşağıdaki Konsey Direktifleriyle uyumu olduğunu ve bununla ilgili olarak tüm sorumluluğun bize ait olduğunu beyan ederiz.

CZ: Prohlášení výrobce EU

My firma Grundfos prohlašujeme na svou plnou odpovědnost, že výrobek Servomotor 384, na který se toto prohlášení vztahuje, je v souladu s níže uvedenými ustanoveními směrnice Rady pro sblížení právních předpisů členských států Evropského společenství.

ES: Declaración del fabricante CE/UE

Grundfos declara, bajo su exclusiva responsabilidad, que el producto Servomotor 384 al que hace referencia la siguiente declaración cumple lo establecido por las siguientes Directivas del Consejo sobre la aproximación de las legislaciones de los Estados miembros de la CE/UE.

GR: Δήλωση του κατασκευαστή ΕΚ/ΕΕ

Εμείς, η Grundfos, δηλώνουμε με αποκλειστικά δική μας ευθύνη ότι το προϊόν Servomotor 384, στο οποίο αναφέρεται η παρακάτω δήλωση, συμμορφώνεται με τις παρακάτω Οδηγίες του Συμβουλίου περί προσεγγιστικών νομοθεσιών των κρατών μελών της ΕΚ/ΕΕ.

HU: EC/EU Gyártó nyilatkozata

Mi, a Grundfos vállalat, teljes felelősséggel kijelentjük, hogy a(z) Servomotor 384 termék, amelyre az alábbi nyilatkozat vonatkozik, megfelel az Európai Közösség/Európai Unió tagállamainak jogi irányelvvel összhangban tanács alábbi előírásainak.

NL: EG/EU Verklaring van de fabrikant

Wij, Grundfos, verklaren geheel onder eigen verantwoordelijkheid dat product Servomotor 384, waarop de onderstaande verklaring betrekking heeft, in overeenstemming is met de onderstaande Richtlijnen van Raad inzake de onderlinge aanpassing van de wetgeving van de EG-/EU-lidstaten.

PT: Declaração do fabricante CE/UE

A Grundfos declara sob sua única responsabilidade que o produto Servomotor 384, ao qual diz respeito a declaração abaixo, está em conformidade com as Directivas do Conselho sobre a aproximação das legislações dos Estados Membros da CE/UE.

SE: EG/EU Tillverkardeklaration

Vi, Grundfos, försäkrar under ansvar att produkten Servomotor 384, som omfattas av nedanstående försäkrar, är i överensstämmelse med de rådsdirektiv om inbördes närmande till EG/EU-medlemsstaternas lagstiftning som listas nedan.

CN: 欧共体 / 欧盟符合性声明


我们, 格兰富, 在我们的全权责任下声明, 产品 Servomotor 384, 即该合格证所指之产品, 符合欧共体 / 欧盟使其成员国法律趋于一致的以下理事会指令。

-
- EMC Directive (2014/30/EU).
Standards used:
EN 61000-6-2:2006, EN 61000-6-3:2011,
EN 61000-3-2:2015, EN 61000-3-3:2014.
 - Low Voltage Directive (2014/35/EU).
Standard used:
EN 61010-1:2011-07.
 - RoHS Directives (2011/65/EU and 2015/863/EU).
Standard used: EN 50581:2012.

This product must not be put into service until the machinery into which it is to be incorporated has been declared in conformity with the provisions of the Machinery Directive (2006/42/EC).

This EC/EU manufacturer's declaration is only valid when published as part of the Grundfos installation and operating instructions (publication number 99559293).

Pfinztal, 1st March 2018



Ulrich Stemick
Technical Director
Grundfos Water Treatment GmbH
Reetzstr. 85, D-76327 Pfinztal, Germany

Person authorised to compile the technical file and
empowered to sign the EC/EU manufacturer's declaration.

Argentina

Bombas GRUNDFOS de Argentina S.A.
Ruta Panamericana km. 37.500 Centro
Industrial Garin
1619 - Garin Pcia. de B.A.
Phone: +54-3327 414 444
Telefax: +54-3327 45 3190

Australia

GRUNDFOS Pumps Pty. Ltd.
P.O. Box 2040
Regency Park
South Australia 5942
Phone: +61-8-8461-4611
Telefax: +61-8-8340 0155

Austria

GRUNDFOS Pumpen Vertrieb
Ges.m.b.H.
Grundfosstraße 2
A-5082 Grödig/Salzburg
Tel.: +43-6246-883-0
Telefax: +43-6246-883-30

Belgium

N.V. GRUNDFOS Bellux S.A.
Boomsesteenweg 81-83
B-2630 Aartselaar
Tél.: +32-3-870 7300
Télécopie: +32-3-870 7301

Belarus

Представительство ГРУНДФОС в
Минске 220125, Минск ул.
Шаффарнанская, 11, оф. 56, БЦ «Порт»
Тел.: +375 17 397 397 3
+375 17 397 397 4
Факс: +375 17 397 397 1
E-mail: minsk@grundfos.com

Bosnia and Herzegovina

GRUNDFOS Sarajevo
Zmaja od Bosne 7-7A,
BH-71000 Sarajevo
Phone: +387 33 592 480
Telefax: +387 33 590 465
www.ba.grundfos.com
e-mail: grundfos@bih.net.ba

Brazil

BOMBAS GRUNDFOS DO BRASIL
Av. Humberto de Alencar Castelo
Branco, 630
CEP 09850 - 300
São Bernardo do Campo - SP
Phone: +55-11 4393 5533
Telefax: +55-11 4343 5015

Bulgaria

Grundfos Bulgaria EOOD
Slatina District
Iztochna Tangenta street no. 100
BG - 1592 Sofia
Tel. +359 2 49 22 200
Fax. +359 2 49 22 201
email: bulgaria@grundfos.bg

Canada

GRUNDFOS Canada Inc.
2941 Brighton Road
Oakville, Ontario
L6H 6C9
Phone: +1-905 829 9533
Telefax: +1-905 829 9512

China

Grundfos Alldos
Dosing & Disinfection
ALLDOS (Shanghai) Water Technology
Co. Ltd.
West Unit, 1 Floor, No. 2 Building (T 4-2)
278 Jinhui Road, Jin Qiao Export
Processing Zone
Pudong New Area
Shanghai, 201206
Phone: +86 21 5055 1012
Telefax: +86 21 5032 0596
E-mail:
grundfosalldos-CN@grundfos.com

China

GRUNDFOS Pumps (Shanghai) Co. Ltd.
10F The Hub, No. 33 Suhong Road
Minhang District
Shanghai 201106
PRC
Phone: +86-21 6122 5222
Telefax: +86-21 6122 5333

COLOMBIA

GRUNDFOS Colombia S.A.S.
Km 1.5 vía Siberia-Cota Conj. Potrero
Chico,
Parque Empresarial Arcos de Cota Bod.
1A.
Cota, Cundinamarca
Phone: +57(1)-2913444
Telefax: +57(1)-8764586

Croatia

GRUNDFOS CROATIA d.o.o.
Buzinski prilaz 38, Buzin
HR-10010 Zagreb
Phone: +385 1 6595 400
Telefax: +385 1 6595 499
www.hr.grundfos.com

GRUNDFOS Sales Czechia and Slovakia s.r.o.

Čapkovského 21
779 00 Olomouc
Phone: +420-585-716 111

Denmark

GRUNDFOS DK A/S
Martin Bachs Vej 3
DK-8850 Bjerringbro
Tlf.: +45-87 50 50
Telefax: +45-87 50 51
E-mail: info_GDK@grundfos.com
www.grundfos.dk/DK

Estonia

GRUNDFOS Pumps Eesti OÜ
Peterburi tee 92G
11415 Tallinn
Tel: + 372 606 1690
Fax: + 372 606 1691

Finland

OY GRUNDFOS Pumput AB
Trukkikuja 1
FI-01360 Vantaa
Phone: +358-(0)207 889 500

France

Pompes GRUNDFOS Distribution S.A.
Parc d'Activités de Chesnes
57, rue de Malacobre
F-38290 St. Quentin Fallavier (Lyon)
Tél.: +33-4 74 82 15 15
Télécopie: +33-4 74 94 10 51

Germany

GRUNDFOS Water Treatment GmbH
Reetsstraße 85
D-76327 Pfinztal (Söllingen)
Tel.: +49 7240 61-0
Telefax: +49 7240 61-177
E-mail: gwt@grundfos.com

Germany

GRUNDFOS GMBH
Schlüterstr. 33
40699 Erkrath
Tel.: +49-(0) 211 929 69-0
Telefax: +49-(0) 211 929 69-3799
E-mail: infoservice@grundfos.de
Service in Deutschland:
E-mail: kundendienst@grundfos.de

Greece

GRUNDFOS Hellas A.E.B.E.
20th km. Athinon-Markopoulou Av.
P.O. Box 71
GR-19002 Peania
Phone: +0030-210-66 83 400
Telefax: +0030-210-66 46 273

Hong Kong

GRUNDFOS Pumps (Hong Kong) Ltd.
Unit 1, Ground floor
Siu Wai Industrial Centre
29-33 Wing Hong Street &
68 King Lam Street, Cheung Sha Wan
Kowloon
Phone: +852-27861706 / 27861741
Telefax: +852-27858664

Hungary

GRUNDFOS Hungária Kft.
Tópark u. 8
H-2045 Törökbalint,
Phone: +36-23 511 110
Telefax: +36-23 511 111

India

GRUNDFOS Pumps India Private
Limited
118 Old Mahabalipuram Road
Thoraipakkam
Chennai 600 097
Phone: +91-44 4596 6800

Indonesia

PT. GRUNDFOS POMPA
Graha Intirub Lt. 2 & 3
Jln. Ciliilitan Besar No.454. Makasar,
Jakarta Timur
ID-Jakarta 13650
Phone: +62 21-469-51900
Telefax: +62 21-460 6910 / 460 6901

Ireland

GRUNDFOS (Ireland) Ltd.
Unit A, Merrywell Business Park
Ballymount Road Lower
Dublin 12
Phone: +353-1-4089 800
Telefax: +353-1-4089 830

Italy

GRUNDFOS Pompe Italia S.r.l.
Via Gran Sasso 4
I-20060 Truccazzano (Milano)
Tel.: +39-02-95838112
Telefax: +39-02-95309290 / 95838461

Japan

GRUNDFOS Pumps K.K.
1-2-3, Shin-Miyakoda, Kita-ku
Hamamatsu
431-2103 Japan
Phone: +81 53 428 4760
Telefax: +81 53 428 5005

Korea

GRUNDFOS Pumps Korea Ltd.
6th Floor, Aju Building 679-5
Yeoksam-dong, Gangnam-ku, 135-916
Seoul, Korea
Phone: +82-2-5317 600
Telefax: +82-2-5633 725

Latvia

SIA GRUNDFOS Pumps Latvia
Deglava biznessa centrs
Augusta Deglava ielā 60, LV-1035, Riga,
Tālrs: + 371 714 9640, 7 149 641
Fakss: + 371 914 9646

Lithuania

GRUNDFOS Pumps UAB
Smolensko g. 6
LT-03201 Vilnius
Tel: + 370 52 395 430
Fax: + 370 52 395 431

Malaysia

GRUNDFOS Pumps Sdn. Bhd.
7 Jalan Peguam U1/25
Glenmarie Industrial Park
40150 Shah Alam
Selangor
Phone: +60-3-5569 2922
Telefax: +60-3-5569 2866

Mexico

Bombas GRUNDFOS de México S.A. de C.V.
Boulevard TLC No. 15
Parque Industrial Stiva Aeropuerto
Apodaca, N.L. 66600
Phone: +52-81-8144 4000
Telefax: +52-81-8144 4010

Netherlands

GRUNDFOS Netherlands
Veluwezoom 35
1326 AE Almere
Postbus 22015
1302 CA ALMERE
Tel.: +31-88-478 6336
Telefax: +31-88-478 6332
E-mail: info_gnl@grundfos.com

New Zealand

GRUNDFOS Pumps NZ Ltd.
17 Beatrice Tinsley Crescent
North Harbour Industrial Estate
Albany, Auckland
Phone: +64-9-415 3240
Telefax: +64-9-415 3250

Norway

GRUNDFOS Pumper A/S
Strømsveien 344
Postboks 235, Leirdal
N-1011 Oslo
Tlf.: +47-22 90 47 00
Telefax: +47-22 32 21 50

Poland

GRUNDFOS Pompy Sp. z o.o.
ul. Klonowa 23
Baranowo k. Poznania
PL-62-081 Przeźmierowo
Tel: (+48-61) 650 13 00
Fax: (+48-61) 650 13 50

Portugal

Bombas GRUNDFOS Portugal, S.A.
Rua Calvet de Magalhães, 241
Apartado 1079
P-2770-153 Paço de Arcos
Tel.: +351-21-440 76 00
Telefax: +351-21-440 76 90

Romania

GRUNDFOS Pompe România SRL
Bd. Biruentei, nr 103
Pantelimon county Ilfov
Phone: +40 21 200 4100
Telefax: +40 21 200 4101
E-mail: romania@grundfos.ro

Russia

ООО Грундфос Россия
ул. Школьная, 39-41
Москва, RU-109544, Russia
Тел. (+7) 495 564-88-00 (495)
737-30-00
Факс (+7) 495 564 8811
E-mail grundfos.moscow@grundfos.com

Serbia

Grundfos Srbija d.o.o.
Omladinskih brigada 90b
11070 Novi Beograd
Phone: +381 11 2258 740
Telefax: +381 11 2281 769
www.rs.grundfos.com

Singapore

GRUNDFOS (Singapore) Pte. Ltd.
25 Jalan Tukang
Singapore 619264
Phone: +65-6681 9688
Telefax: +65-6681 9689

Slovakia

GRUNDFOS s.r.o.
Prievozská 4D
821 09 BRATISLAVA
Phona: +421 2 5020 1426
sk.grundfos.com

Slovenia

GRUNDFOS LJUBLJANA, d.o.o.
Leskoškova 9e, 1122 Ljubljana
Phone: +386 (0) 1 568 06 10
Telefax: +386 (0) 1 568 0619
E-mail: tehnika-si@grundfos.com

South Africa

Grundfos (PTY) Ltd.
16 Lascelles Drive, Meadowbrook Estate
1609 Germiston, Johannesburg
Tel.: +(27) 10 248 6000
Fax: +(27) 10 248 6002
E-mail: lgradidge@grundfos.com

Spain

Bombas GRUNDFOS España S.A.
Caminio de la Fuentevilla, s/n
E-28110 Algete (Madrid)
Tel.: +34-91-848 8800
Telefax: +34-91-628 0465

Sweden

GRUNDFOS AB
Box 333 (Lunngårdsgatan 6)
431 24 Mölndal
Tel.: +46 31 332 23 000
Telefax: +46 31 331 94 60

Switzerland

GRUNDFOS Pumpen AG
Bruggacherstrasse 10
CH-8117 Fällanden/ZH
Tel.: +41-44-806 8111
Telefax: +41-44-806 8115

Taiwan

GRUNDFOS Pumps (Taiwan) Ltd.
7 Floor, 219 Min-Chuan Road
Taichung, Taiwan, R.O.C.
Phone: +886-4-2305 0868
Telefax: +886-4-2305 0878

Thailand

GRUNDFOS (Thailand) Ltd.
92 Chaloem Phrakiat Rama 9 Road,
Dokmai, Pravej, Bangkok 10250
Phone: +66-2-725 8999
Telefax: +66-2-725 8998

Turkey

GRUNDFOS POMPA San. ve Tic. Ltd.
Sti.
Gebze Organize Sanayi Bölgesi
İhsan dede Caddesi,
2. yol 200, Sokak No. 204
41490 Gebze/Kocaeli
Phone: +90 - 262-679 7979
Telefax: +90 - 262-679 7905
E-mail: satis@grundfos.com

Ukraine

Бізнес Центр Європа
Столичне шосе, 103
м. Київ, 03131, Україна
Телефон: (+38 044) 237 04 00
Факс: (+38 044) 237 04 01
E-mail: ukraine@grundfos.com

United Arab Emirates

GRUNDFOS Gulf Distribution
P.O. Box 16768
Jebel Ali Free Zone
Dubai
Phone: +971-4- 8815 166
Telefax: +971-4-8815 136

United Kingdom

GRUNDFOS Pumps Ltd.
Grovebury Road
Leighton Buzzard/Beds. LU7 4TL
Phone: +44-1525-850000
Telefax: +44-1525-850011

U.S.A.

GRUNDFOS Pumps Corporation
9300 Loiret Blvd.
Lenexa, Kansas 66219
Phone: +1-913-227-3400
Telefax: +1-913-227-3500

Uzbekistan

Grundfos Tashkent, Uzbekistan The
Representative Office of Grundfos
Kazakhstan in Uzbekistan
38a, Oybek street, Tashkent
Телефон: +(998) 71 150 3290 / 71 150
3291
Факс: +(998) 71 150 3292

Addresses revised 31.03.2020

99559293 0320

ECM: 1282053

www.grundfos.com

GRUNDFOS X