

PIKA200 Pro - Firmware Instructions

1. Please update the firmware with PIXAPRO firmware update software G3. G3 can be downloaded from the [essentialphoto](http://essentialphoto.co.uk) website.

2. Firmware Version Checking: Press and Hold the "MODE" button whilst switching on the PIKA200 Pro. The firmware update version (e.g. V X.X) will be displayed on the LCD panel.

Version	Update Comment	Notes	Release Date
V1.5	1. To add compatibility with Flash Trigger for Leica --- ST-IV+L Wireless System	Please check to see if there is a sticker saying "Version A" on the light fixture, then download the corresponding firmware to upgrade.	16/08/2022
V1.4	1. To add compatibility with R200 ring flash light head. Please check out if there is a sticker "Version A" on the light fixture, and then choose the corresponding firmware to upgrade.	Before updating this firmware version, please make sure that your gear has download the G3 firmware launcher installer.	20/06/2022
V1.3	1. The E3 false alarm has been resolved. 2. To add Compatibility of Ring Lamps	Please check to see if there is a sticker saying "Version A" on the light fixture, then download the corresponding firmware to upgrade.	14/01/2022

Note: For more information, please download the latest version of the instruction manual from: www.essentialphoto.co.uk/firmware/