

CITI300 Pro - Firmware Instructions

1. Please update the firmware with PIXAPRO firmware update software G3. G3 can be downloaded from the [essentialphoto](http://essentialphoto.co.uk) website.
2. Firmware Version Checking: Pressing the "MENU" button to Enter the C.Fn menu. The firmware update version (e.g. V X.X) will be displayed on the top right-hand corner of the screen.

Version	Update Comment	Release Date
V1.2	1. To add compatibility with Flash Trigger for Leica --- ST-IV+L (XProIIL) Wireless Trigger System	16/08/2022

Note: For more information, please download the latest version of the instruction manual from:
www.essentialphoto.co.uk/firmware/