

## ST-III N Transmitter (For Nikon) Firmware Instructions

1. Please update the firmware with PIXAPRO firmware update software G1. G1 can be downloaded from the essentialphoto website.

2. To check your current firmware version, switch the ST-III Trigger off, then press and hold the “MODE” button whilst switching the receiver on, and the firmware update version (e.g. Version 10 will read U-10) will be displayed on the LCD panel.

Version	Update Comment	Release Date
V25	1. To resolve the over exposure issue when mounting the flash on Z6/Z7 cameras	22/12/2020
V24	1. To add the Fn-11 C.Fn custom setting so that the customer can set RF ID value.	10/08/2018
V23	1. To solve the problem that M value do not change when being output over 1/4 after the camera flash on the transmitter end is set to i-TTL mode and the master group is set to M mode.	01/12/2017
V22	1. To solve the problem that the output value	12/09/2017
V21	1. To add C.Fn custom settings. The transmitter's parameters that set by Pixapro APP are not changed. And the transmitter is only for triggering.	19/08/2017
V20	1. To solve the compatibility problem of using SB910 or SB5000.	21/06/2017
V19	1. To solve the problem that the high-speed continuous shooting speed becomes slow in high-speed sync mode.	30/06/2016
V17	1. To solve the problem of missing flashes when using high-speed sync function on D700. 2. To solve the not-flash problem in second curtain sync functions when the shutter speed is slower than 1s.	20/06/2016

Note: For more information, please download the latest version of the instruction manual from: [www.essentialphoto.co.uk/firmware/](http://www.essentialphoto.co.uk/firmware/)

Version	Update Comment	Release Date
V16	<ol style="list-style-type: none"> <li>To add the triggering operation at close range: Press the TEST Button to power the transmitter on, holding on until the STATUS indicator lamp blinks for 2 times. Now the wireless remote distance is from 0 to 30 meters.</li> </ol>	07/06/2016
V15	<ol style="list-style-type: none"> <li>To solve the problem that the single group C do not fire flashes in the Multi mode, as well as D and E groups do not fire flashes when turn off the A, B and C group.</li> <li>To solve the out-of-sync exposure problem of FV Lock.</li> </ol>	16/04/2016
V14	<ol style="list-style-type: none"> <li>The former C.Fn setting values are changed to defined values.</li> <li>To add the beeper control in C.Fn functions (set C.Fn-08 to on). To see the concrete C.Fn functions, please refer to X1N Custom Function Settings. xlsx.</li> </ol>	26/03/2016
V13	<ol style="list-style-type: none"> <li>To add ST-III T N simplified operation method. xlsx.</li> <li>The power output of M/Multi is the same as the receive end.</li> </ol>	18/03/2016
V12	<ol style="list-style-type: none"> <li>To solve the not triggering problem when using the second curtain function with shutter over 1s.</li> <li>To solve the problem that the output of Hybrid360 cannot be set by Pro AC 2.4GHz or ST-I 2.4GHz.</li> <li>Double-click the &lt;CH&gt; Button to turn on/off the modeling lamp of CITI600.</li> </ol>	19/02/2016
V11	<ol style="list-style-type: none"> <li>To solve the triggering problems of some cameras.</li> <li>To solve the out-of-sync problem of D80 or D90 cameras whose shutter is 1/250s.</li> </ol>	31/12/2015
V10	<ol style="list-style-type: none"> <li>To solve the problem that Nikon SB series camera flash cannot be triggered probably.</li> <li>Users can turn off the transmitter's AF-assist function (Set C.Fn-06 to --).</li> </ol>	29/12/2015
V09	<ol style="list-style-type: none"> <li>To solve the black side phenomenon when using D750 or D610 camera in FP flash.</li> <li>The minimum output can be set to 1/256 in the M/Multi mode (Set C.Fn-05 to 1/128-).</li> </ol>	24/12/2015
V08	<ol style="list-style-type: none"> <li>In order to improve anti-interference ability, the frequency of CH9/CH12/CH15/CH18/CH21/CH24/CH27/CH30 has been adjusted. As these 8 channels are not compatible with the old version, please update the relevant product.</li> </ol>	26/11/2015
V06	<ol style="list-style-type: none"> <li>To solve the problem that 1/1 will turn to 1/128 when keep adding in the M mode.</li> </ol>	11/11/2015

Note: For more information, please download the latest version of the instruction manual from:  
[www.essentialphoto.co.uk/firmware/](http://www.essentialphoto.co.uk/firmware/)

Version	Update Comment	Release Date
V05	1. To solve the problem that M icon is not displayed in the M mode.	11/11/2015
V04	1. Fully press the Test Button on the transmitter will trigger the receiver (if – is not set).	10/11/2015
V03	1. To support RFS2.1 2. To add Multi (stroboscopic) functions.	05/11/2015