

ST-III N Receiver (For Nikon) Firmware Instructions

1. Please update the firmware with PIXAPRO firmware update software G1. G1 can be downloaded from the [essentialphoto](http://www.essentialphoto.co.uk) website.

2. To check your current firmware version, switch the ST-III Trigger off, then press and hold the “GR” button whilst switching the receiver on, and the firmware update version (e.g. Version 10 will read 10U) will be displayed on the LCD panel.

Version	Update Comment	Release Date
V21	1. The customer can set RF ID. Operation: press the CH and GR button simultaneously and power it on to enter the RF ID setting interface. Short or long press the CH button to add the ID value while short or long press the GR button to decrease. Power off the flash trigger after 5s, and ID value can be set and saved. Then, power it on, and the ID value will affect RF reception.	10/01/2018
V20	1. To solve the problem that M value do not change when being output over 1/4 after the camera flash on the receive end is set to i-TTL mode and the receiver is set to M mode.	01/12/2017
V19	1. To solve the problem that the camera flash' output value changes with the camera ISO when the camera flash in the receiver end is set to i-TTL mode and the receiver is set to M mode.	12/09/2017
V18	1. To solve the compatibility problem of using SB910 or SB5000.	21/06/2017
V16	1. To keep pace with the program of the transmitter.	21/06/2017
V15	1. To solve the problem that the new channel's signal is not received when diminish the channel amount by double-clicking.	13/04/2016
V13	2. To adjust the relevant value downwardly by double-clicking the relevant button.	15/03/2016
V12	1. To solve the problem that 1/1 output value in the M mode is less than ISO100 when ISO's value is over 100. 2. To solve the not triggering problem when using the second curtain function with shutter below 1s.	02/02/2016

Note: For more information, please download the latest version of the instruction manual from: www.essentialphoto.co.uk/firmware/

Version	Update Comment	Release Date
V11	1. To solve the out-of-sync problem of D80 or D90 cameras whose shutter is 1/250s.	31/12/2015
V10	1. To solve the problem that Nikon SB series camera flash cannot be triggered probably.	29/12/29
V09	2. To solve the black side phenomenon when using D750 or D610 camera in FP flash.	24/12/2015
V08	1. In order to improve anti-interference ability, the frequency of CH9/CH 12/CH15/CH18/CH21/CH24/CH27/CH30 has been adjusted. As these 8 channels are not compatible with the old version, please update the relevant product.	26/11/2015
V04	1. Even if the group of the receiver is set to OFF, the LED light will also blink when receiving the flash signal.	11/11/2015
V03	1. To support RFS2.1 2. To add Multi (stroboscopic) functions.	31/10/2015

Note: For more information, please download the latest version of the instruction manual from:
www.essentialphoto.co.uk/firmware/