

ST-IV N Transmitter (For Nikon) Firmware Instructions

1. Please update the firmware with PIXAPRO firmware update software G2. G2 can be downloaded on the [essentialphoto](http://essentialphoto.co.uk) website.
2. To Check Firmware Version: Press the "MENU" button to enter the menu, and the firmware update version (e.g. Version 1.4) will be displayed on the LCD panel.

Version	Update Comment	Release Date
V1.7	1. To add Decimal Display form of power value.	07/11/20
V1.6	1. To strengthen the wireless transmitting signal and decrease the odds of mis-firing due to possible the interference of external 2.4GHz wireless signals (note: adjusting the CH value is an effective way to avoid the external interference).	25/10/18
V1.5	1. Change C.FN-MIN option to C.FN-STEP, which gives you the ability to adjust compatible lights in 1/10 stop increments.	28/08/2018
V1.4	1. To add modeling flash function.	10/01/2018
V1.3	<ol style="list-style-type: none"> 1. To restore the standby (sleep) function; 2. To adjust the button function of "CH/Zm": Zm means the short button while CH means the long button; 3. To restore the 0~30m wireless firing distance; 4. To restore the problem of the underexposed M value during the TCM process in certain circumstance. 5. To restore the sync problem in high-speed sync when only using D/E group. 	31/10/17

Note: For more information, please download the latest version of the instruction manual from: www.essentialphoto.co.uk/firmware/