

ST-IV F Transmitter (For Fujifilm) Firmware Instructions

1. Please update the firmware with PIXAPRO firmware update software G2. G2 can be downloaded on the [essentialphoto](http://essentialphoto.co.uk) website.
2. To Check Firmware Version: Press the "MENU" button to enter the menu, and the firmware update version (e.g. Version 1.4) will be displayed on the LCD panel.

Version	Update Comment	Release Date
V1.3	1. To add Decimal Display form of power value.	07/11/20
V1.2	1. To strengthen the wireless transmitting signal and decrease the odds of mis-firing due to possible the interference of external 2.4GHz wireless signals (note: adjusting the CH value is an effective way to avoid the external interference).	13/11/2018
V1.1	1. Change C.FN-MIN option to C.FN-STEP , which gives you the ability to adjust compatible lights in 1/10 stop increments.	28/08/2018

Note: For more information, please download the latest version of the instruction manual from:
www.essentialphoto.co.uk/firmware/