

ST-IV Trigger Pentax - Firmware Instructions

1. Please update the firmware with PIXAPRO firmware update software G3. G3 can be downloaded from the [essentialphoto](http://essentialphoto.com) website.
2. Firmware Version Checking: Switch the flash on, then press the "MENU" button and enter C.Fn custom functions. The firmware update version (e.g. Ver X.X) will be displayed on the LCD panel.

Version	Update Comment	Release Date
V1.2	1. To add Decimal Display form of power value.	07/11/20

Note: For more information, please download the latest version of the instruction manual from:
www.essentialphoto.co.uk/firmware/