

Instruction Manual for PiXAPRO Firmware Update Software G3

1. Download G3 Software


1. Please download the PiXAPRO firmware update software G3 for Windows. The G3 Software can be downloaded from the essentialphoto.co.uk website.

2. Extract the files from the .zip folder and run the G3 software (installation is not required)

2. Connect Your Device

1. Please discharge your device before connecting your device to your computer. To do so, simply remove the battery and press and hold the ON/OFF button for 2 seconds (Press and hold the "TEST" button for two seconds if your device has a power switch as opposed to a power button)


2. Connect your Device to your computer using the appropriate type of USB cable for your device (Micro USB or USB type C)



3. Open the File

1. Download the firmware file for the product that you would like to update from the essentialphoto.co.uk website (Located in the "Downloads" tab of the product listing). and extract the contents of the .zip file.


2. Click the "Open File" button, locate the .bin file that you have just extracted from the .zip file that you have just downloaded, and click "Open"



Note: For more information, please download the latest version of the instruction manual from the "Downloads" tab of the product listing on the essentialphoto.co.uk website.

3. Update your Device

1. Once the file has been loaded into the G3 software, click "Update" and the software will update the firmware for you.
2. Once the Update is complete, simply disconnect your device from your computer, and you are ready to go.



Note: For more information, please download the latest version of the instruction manual from the "Downloads" tab of the product listing on the essentialphoto.co.uk website.