

ST-III Plus Trigger Sony - Firmware Instructions

1. Please update the firmware with PIXAPRO firmware update software G3. G3 can be downloaded from the [essentialphoto](http://essentialphoto.co.uk) website.

2. Firmware Version Checking: Switch the flash on, then press the "MENU" button and enter C.Fn custom functions. The firmware update version (e.g. Ver X.X) will be displayed on the LCD panel.

Version	Update Comment	Release Date
V1.4	1. To match the update of Godox flash APP.	30/06/2022
V1.3	1. To solve the problem that occasionally ST-III-Plus-S could not receive the correct settings sent over Bluetooth when communicating with the camera.	14/02/2022
V1.2	1. To solve the problem of not sending the modified value to the receiving end in APP mode. 2. When restoring the factory settings, the Bluetooth password is reset to the initial value ("000000"). 3. To solve the problem of the settings of Zoom value.	30/06/2022
V1.1	4. To resolve the problem of turning on anti-red eye flash and flash missing with the newest firmware of cameras like a6000 and a6500.	13/08/2019
V1.0	1. Original Firmware	

Note: For more information, please download the latest version of the instruction manual from: www.essentialphoto.co.uk/firmware/