

ST-III Plus Trigger Fuji - Firmware Instructions

1. Please update the firmware with PIXAPRO firmware update software G3. G3 can be downloaded from the [essentialphoto](http://essentialphoto.com) website.

2. Firmware Version Checking: Switch the flash on, then press the "MENU" button and enter C.Fn custom functions. The firmware update version (e.g. Ver X.X) will be displayed on the LCD panel.

Version	Update Comment	Release Date
V1.4	1. To add compatibility of Camera X-S10, GFX100S, and X-H2S.	30/08/2022
V1.3	1. To match the update of Godox flash APP.	30/06/2022
V1.2	1. To fix the occasional stuck problem when using it on the camera. 2. Optimize the algorithm logic of the AF focus lamp to support the use of the AF focus lamp in extremely dark places.	16/11/2021
V1.1	1. To resolve the problem where the modified value wouldn't be sent to the receiver end in APP mode. 2. To reset the Bluetooth password to the initial value when restoring the factory default.	20/07/2020

Note: For more information, please download the latest version of the instruction manual from: www.essentialphoto.co.uk/firmware/