

## WMicS1 Pro Upgrade Instructions


Each device requires upgrading two files, Main and Code.

The file selection and upgrade mode must be the same as specified, otherwise it will not work properly. You need a USB TYPE-C cable installed with Windows XP or Windows 7, Windows 10, or Windows 11.

- 1、 Shut down the device and disconnect the USB cable.




- 2、 Run the upgrade program on your computer.




- 3、Upgrade the TX Main.







When the machine is turned off, hold the menu key and insert the USB cable



Screen display after access






After the Mian upgrade is completed, shut down the main and disconnect the USB cable

---


Code






When the machine is turned off, hold the menu key and insert the USB cable



Screen display after access





Wait for the upgrade to complete, shut down and restart.

#### 4、upgrade RX

The process is the same as TX, and attention should be paid to selecting the upgrade file for RX.