Instruction Manual for PIXAPRO Firmware Update Software G2

Preparing for updates

1. The firmware update software G2 can be run in operating systems Windows 10 (64bit), Windows 8.1（64bit), Windows 7 (32bit or 64bit) or Windows XP (32bit or 64bit).
2. Before installing this application, please shut down other applications especially antivirus software.

Download and Install the Application

1. Download the G2 application from the official website and complete the installation according to the guide.

Upgrade the Device with G2

G2 Interface

Upgrade Methods

Step 1: Select the Document

Please download the relevant product firmware (model.dfu)
Then, click the "Select File" to open the .dfu file.

Step2: Connect the Device

1. Please discharge the device before updating.

Name of Device	Discharge Methods
PIKA200, ST-III O, ST-III F	Remove the battery and press the OFF/ON button for 2 seconds (press the test button if do not have OFF/ON button).

2. For the first firmware update, Windows will prompt you to install a USB driver. Please click "Connect" after finishing the driver installation. When getting correct connection, "STM Device in DFU Mode" will display in about 1 minute.
3. Updating.

Firmware software G2, can be downloaded from
www.essentialphoto.co.uk/firmware