

Assembly video Visit designbydelta.com/downloads



bike hanger

Assembly instructions RS4200

- 1 Locate stud beneath wallboard.
- 2 Slide hook into base and lock into pin.
- Position plate at desired height and screw into place. (screws should be in center of wall stud)



IMPORTANT SAFETY NOTE

Make sure hook is secured to base using locking pin, and that the plate is mounted level

Tools Required



Hand Drill 1/8"(3mm)



Spirit Level



Way of locating studs within the wall (see hardware store for advice)

