

## How to Install Aluminium Floor Bunding

Installation is straightforward. The process requires minimal experience.

1. Ensure the surface under the floor bunding is appropriate
2. Clean the surface so it's free of anything that could affect adhesion
3. Layout your bunding to determine you have enough materials
4. Cut lengths as required to custom fit your layout
5. Layout the bunding using a chalk line and leave a 2-3mm gap in between lengths (for expansion)
6. Pre-drill holes for the concrete fasteners
7. Vacuum away the dust
8. Apply adhesive to the bottom of the floor bunding and adhere to ground surface.
9. Insert the concrete screws
10. Once the lengths are installed, run a bead of adhesive along both sides where it meets the ground and in the gap between the lengths
11. Allow the adhesive to cure before using the bunding