

How to Install Drive Over Floor Bunding

Installation is simple.

Minimum tools are required and the drive over floor bunding can be cut easily.

Each length and corner of drive over floor is manufactured with pre-moulded points for bolts to assist with installation.

The required banded areas can be easily configured using the moulded 90° corner pieces.

Each 1m length installation kit consists of:

- 6 x countersunk concrete fasteners
- 1 x tube of adhesive sealant

Before purchasing floor bunding ensure you check ground clearance of forklifts.

