

MudPod & Mini MudPod Fitting Instructions



Remove the ashtray from the top of the dashboard. The ashtray is secured with a spring clip at each side. Route your wiring through this aperture.



Bend the tabs on the base plate to 90 degrees. At this stage you have the option to secure the Pod base plate with the double sided sticky pads. Remember to attach the sticky pads to the base plate before bending the tabs into position.



Offer up the base plate to the dash, sliding the tabs inside the ashtray aperture. The taller upright fold should align with the windscreen side of the dash. Press the tabs firmly into place by bending them back under the dash trim as far as possible.



Position the Pod over the base plate keeping one side of the fixing plates outside of the Pod. Mark a fixing hole slightly towards the top of the hole (to account for the thickness of the base plate). Repeat the procedure for the opposite side of the console.



Remove the Pod and drill the holes with a 4.5mm drill. Take the spire clips and slide over the tabs on the end plate. The smooth face of the spire clips should face outwards. Position the pod over the mounting frame and secure using the short screws provided. **JOB DONE!**

Additional Fitting Information

The unique design of the base plate dispenses with the need to for any fixings to be screwed into the dashboard. We have however provided you with two screws and two screw holes within the base plate should you wish to make your Pod a more permanent fixture, or locate the Pod in an alternative location.

