



## MUD-UK Land Rover Solutions

### Post 02 Rear Door Gas Strut Fitting Instructions



Remove the grab-handle plastic insert.



The door trim is held in place with trim fasteners in the locations circled above. To release the centre trim clip, slide the trim panel downwards.



Undo the door check-strap fastener.



Slide the check-strap out of the end of the track channel.



Remove the check-strap bracket and refit using the spacer plates. The two bolts securing the check-strap into the bodytub are captive.



Remove gas-strut from the bracket. Position the bracket on the door and mark fixing locations. Check clearance for spare wheel and position bracket accordingly. This is especially important on vehicles fitted with oversize tyres and non standard rear lamps.



Drill fixing holes using a 5mm drill. Attach using the supplied rivets. Re-attach the gas strut to the bracket and secure.



Attach the gas strut to the check-strap bracket.  
Note that the gas-strut attaches UNDERNEATH the bracket tab.  
Tighten the lock nut just enough to allow the strut move freely within the bracket.  
Replace the door trim.

**Tel: +44 (0) 1422 881951**

Email: [mud@mudstuff.co.uk](mailto:mud@mudstuff.co.uk)

Web: [www.mudstuff.co.uk](http://www.mudstuff.co.uk)