

MUD Cubby Box Tray Fitting Instructions

1. Fit spacer strip underneath lid hinge.



2. Remove top 2x screws on catch.

3. Loosen bottom 2x screws on catch.

4. Slide catch upwards in order to engage with latch on the cubby lid.



6. Tighten 2x bottom screws and re-fit 2x top screws on the catch.

