



PALS Cubby Box Panel Fitting Instructions

Please read all of the instructions before fitment.

Tel: 01422 881951

Email: mud@mudstuff.co.uk

Online: www.mudstuff.co.uk

Kit includes

1x PALS Panel
4x Screws/Plastic Cup Washers/ Black Screw Caps/Spacers
1x MUD Badge

- Position the panel on the rear of the cubby box.
- Mark the positions of the fixings onto the rear of the cubby box.
- Use a bradawl to create a hole for the fixings or drill fixing holes with a 4mm drill
- Place fixing screws within plastic cup washers.
- Position the black spacer washers between the PALS panel and the cubby box on each fixing
- Once fixings are screwed into place and tightened down, the black screw caps snap into place on top of the cup washers
- We recommend attaching any MOLLE pouches to the panel before fixing it in place.