



Tel: 01422 881951

Email: mud@mudstuff.co.uk

Online: www.mudstuff.co.uk

PALS Rear Window Panel Fitting Instructions

Please read all of the instructions before fitment.

Kit includes

1x PALS Panel
1x Foam Strip
6x Screws/Plastic Cup Washers/ Black Screw Caps
1x MUD Badge

- Position/centralise the panel on the rear door frame.
- Mark the positions of the fixings onto the door frame.
- Drill fixing holes into door frame with a 4.5mm drill.
- Peel off adhesive backing from insulating foam strip and attach to the outer edge of PALS panel.
- Place fixing screws within the plastic cup washers.
- Once fixings are screwed into place and tightened down, the black screw caps snap into place on top of the cup washers.
- We recommend attaching any MOLLE pouches to the panel before fixing it to the door.