



RAM Defender Dashboard Mount

For Dashboard Mount

-TdcI/Puma models use the smaller diameter screw with washer.

-Td5, Tdi and earlier models use the larger diameter screw. Washer not required.

For Puma/TdcI Grab Handle Mount

Use M6 bolt with washer and spacer.