



Corporate Office: PerTronix Inc. 440 E. Arrow Highway, San Dimas, California 91773 * Phone 909.599.5955 • FAX 909.599.6424

Installation Instructions and Warranty Information

30-9030 ~ 2013-2020 Subaru BRZ
Scion FRS/Toyota FT86



⚠ WARNING:

This product can expose you to chemicals including Lead, Nickel, Cadmium and Chromium which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov

Rev. 1 12-10-20 DSL

PerTronix© thanks you for choosing JBA Exhaust, the best fitting, highest quality exhaust on the market. In order to realize the full potential of our good fit, please read and understand these instructions completely prior to starting work.

Be sure to work safe! Whenever you work under the vehicle be sure that it is located on level, solid ground and is supported by adequate safety stands! Remember: Hot asphalt will not support most jack stands!

1. Allow vehicle, and exhaust pipes to cool down.
2. Disconnect negative battery cable.
3. Lubricate all rubber isolators and hangers.
4. Unbolt the two spring loaded bolts on the flange just past the catalytic converter.
5. Using a muffler stand or another person to hold the muffler assembly in place, remove the hangers from the rubber isolators and the muffler assembly from the vehicle
6. Bolt the JBA intermediate pipe in place using the supplied gasket, bolts, lock washers and nuts.
7. Place one Accu Seal clamp over the outlet of the pipe and slip the mid pipe onto the intermediate pipe and slip the hanger in to the rubber isolator.
8. Place an Accu Seal clamp over the inlet of the muffler and slip muffler assembly in its place, reattaching factory rubber isolators into hangers.
9. Place an Accu Seal clamp over each end of the muffler outlets and insert a 90° pipe in each end with the hanger rod pointed towards the muffler. Slip the hanger into the rubber isolators
10. Slip a Stainless Tip and T-Bolt Clamp over both muffler outlet, adjust to preference and tighten until tip is secure.
11. Adjust all pipes and tips to the best fit and tighten the clamps - the Accu Seal clamps torque to 40-50 lbs. ft. The tip clamps just need to be hand tight.
10. Start vehicle and check for leaks, tighten as needed.

Parts List:

- (1) JBA muffler assembly
- (1) Intermediate pipe with resonator
- (1) Mid pipe
- (2) Polished Stainless Exhaust Tip
- (4) 2.5" Accu Seal clamp
- (2) 2.5" T Bolt Clamp

LIMITED ONE YEAR WARRANTY

All JBA HEADERS and exhaust products are guaranteed, to the original purchaser, to be free of defects in materials and workmanship for one year. This warranty covers the replacement or repair of the product only and does not cover the cost of removal and installation, customer applied aftermarket coatings or any discoloration or corrosion of finished surfaces.

Damage or product failure resulting from collision, improper installation, off-road use, road hazards, the use of exhaust insulating wrap or like products or rust occurring after installation, is not covered by the warranty. The warranty extends only to the original purchaser.

Should a part become defective it should be returned to the original selling retailer and must be accompanied with the sales receipt. If there is no retailer in your area, call the factory for a return authorization and return your part prepaid to the factory for inspection. PerTronix reserves the rights to replace or repair the alleged defective part and return the part freight collect.

JBA
performance**exhaust**®

