



NOTES:

1. Beware if using as a template as drawing may not print to scale.
2. The PowerHub Mini requires a minimum of 60mm clearance at the rear (measured from the front of the furniture).
3. If using wood screws (provided) to secure the trim, then drill 6 small pilot holes ($\varnothing 1\text{mm}$) at locations marked with a \odot on the drawing. If using bolts and nuts (not provided), then drill 6 suitable diameter holes instead.