

# DEFENDER3D

## 2023 Wireless Tray Fitment Instructions

Thanks for your valued purchase of the Defender L663 Wireless Charger Tray. These trays always fit with the round cup/coin indentation on the Left, regardless of the country you are in.

Firstly, install the supplied charging mat into the tray, and ease the flat cable into the cable retention clip underneath.

Then connect the USB cable to the relevant outlet below.

When fitting these trays, you will notice that they are a tight fit, depending on your trim finish. We recommend that you offer one of the shorter sides into the trim first, and then ease the opposite side into the trim, while pulling the trim away from the charger tray. The trim is very tough and can take the force required but use your discretion.

The charger tray will then sit firmly in place, when slid up towards the cup holders. Note the gap between the tray and the dash bulkhead is intentional to allow cables to pass through from the outlets below.

2. Locate short side into trim 'crease.'



1. Firmly pull the trim outwards to allow tray to locate. You may need a 2<sup>nd</sup> pair of hands to help with this 😊

3. Gently slide tray up to cup holder trim.