



FITTING INSTRUCTIONS



**SCAN THE QR CODE FOR
THE FITTING VIDEO**

**LAND ROVER
DEFENDER
110 COUNTY
STATION
WAGON
HEADLINER**

CONTENTS

| | |
|---------------------|--|
| <u>Page 02</u> | <u>Required Equipment</u> |
| <u>Page 03</u> | <u>What's in the box</u> |
| <u>Page 04 - 07</u> | <u>Step One: Removal</u> |
| Page 04 | • Middle Piece |
| Page 05 | • Telephone Piece |
| Page 05 | • Rear Cabin Light |
| Page 06 | • Rear Panel Fir Trees |
| Page 06 | • Removal Of Rear Headlining Panel |
| Page 07 | • Front Section Sun Visors, Mirror and Mirror Holder |
| Page 07 | • Alarm Sensor |
| Page 07 | • Door Frame Fir Trees |
| <u>Page 08 - 11</u> | <u>Step Two: Fitting</u> |
| Page 8 | • Front Section |
| Page 8 | • Wiring For The Light |
| Page 8 | • Attaching The Front Section |
| Page 9 | • Rear Section |
| Page 9-10 | • Middle Section |
| Page 10 | • Rear Telephone Piece (end piece) |
| Page 11 | • Interior Lights |
| Page 11 | • Sun Visors and Rear View Mirror |
| <u>Page 12</u> | <u>Step Three: ENJOY</u> |



REQUIRED EQUIPMENT

Nylon or plastic mallet



8mm socket



Tack lifter or trimming tool



Screwdriver



Bar clamp (optional)



Hand clips (optional)



WHAT'S IN THE BOX

Front Headlining Section



Rear Headlining Section



Middle Headlining Section



Telephone Piece (end piece)



Fir Tree Pieces



STEP ONE: REMOVAL

Middle Piece

Use the tack lifter to remove the fixings from the middle section of the headlining. Once completed, the panel will fall out easily. If this doesn't happen, the headlining middle panel can be slightly flexed downward at the corners to allow it to be removed. The middle headlining panel should be removed through either of the side doors.



Note: Some of the fixings may shear on removal. If this happens they can be removed with pliers.



STEP ONE: REMOVAL

Telephone (end piece)

Begin at the rear of the vehicle and remove any grab handles from the rear telephone (end piece) if fitted. Remove all fire tree fixings from the rear telephone section (end piece). This will allow the telephone piece to be removed from the car.



Cabin Light

Remove the rear cabin light by levering the light cover from the housing, this can be done using a plastic trim tool. Remove the M6 nuts (x2) that are located under the lens. This will allow the full housing to be removed. Once the housing is out, turn over the lighting unit and remove the power plug. Remove the backing metal plate by rotating it sideways and pulling it through the hole.



Note: Some of the fixings may shear on removal. If this happens they can be removed with pliers. Plastic trim tool is recommended as the likelihood of scratching the lens is reduced.



STEP ONE: REMOVAL

Rear Panel Fir Trees

Using the trim removal tool, locate the fir trees (6 in a row) and remove. No need to keep these as your new Vault headlining comes with replacements.



Removal Of Rear Headlining Panel

Pull the headlining rear panel off the roof channel by pulling down on the corners (picture, right). Go to the rear of the headlining panel and remove the panel from the roof channel. CAUTION, the headlining will fall as now it isn't being supported by the roof channel.



Once the headlining has been removed, this can now be taken out of the rear tailgate door.



Note: Some of the fixings may sheer on removal. If this happens they can be removed with pliers.



STEP ONE: REMOVAL

Front Section

Remove the sun visors, rear view mirror and rear view mirror mounting pad (photo - right).

Front Cabin Light

Please see above under "Cabin light" as this is the same way of removing this part.

Alarm Sensors

Remove the sensors (if applicable) by using a plastic trim removal tool to pry the part away from the headlining and disconnect.

Door Frame

Remove the fir tree clips along the door frame on both sides (2 on each side). Once the fir trees have been removed, the front section of the headlining can be removed through the front door.

Note: Some of the fixings may shear on removal. If this happens they can be removed with pliers.



STEP TWO: FITTING

Front Section

Place the front section of your new headlining in the front of your Defender (as shown - right). For ease of fitting, we would recommend the use of hand clamps or use the front seat headrest (pulled all the way up) to help support the panel in place. Align the holes in the roof with the holes in the headlining panel (door frame and middle of the Defender).



Wiring For The Light

Make sure the wiring for the light is placed into the cut out. This will make it easier to wire the light back in when fitted.



Attaching The Front Headlining

Using a screwdriver, locate the fir tree fixing holes in the door frame. Once located, attach using your new trimmed fir trees. Fir trees may be tight, the use of a plastic mallet may be required to tap in flush.



STEP TWO: FITTING

Rear Section

Place the new rear headlining section into the back of the Defender. Push fit the panel into the roof channels starting at the corners. Line the holes in the headlining with the fixing holes in the roof. Locate the fixing holes using a screwdriver, once located, attach using a new trimmed fir tree clip. Just like the front piece, these will be tight. Use of the plastic mallet maybe required to allow the fir tree clip to sit flush with the headlining.

Tip - As shown in the picture - right. You can use a trim tool to hold the fir tree clip in place so it can be hammered in more easily.

Middle Section

Bring this part into the Defender through the middle doors. This will need to be slightly flexed to allow the corner parts to fit into the roof channel.



STEP TWO: FITTING

Middle Section Continued

Once located, find the fixing holes through the holes in the headlining into the fixing holes of the roof.

When the hole has been located, insert a fir tree clip and tap in place using a plastic mallet. Just like before, these are tight.

Locate all the fir tree holes and repeat fixing the fir tree process.

Rear Telephone Piece (end piece)

Push fit the rear telephone piece into place and re-attach any grab handles that were removed previously. Use fir tree clips to cover any holes that aren't used.



STEP TWO: FITTING

Refitting Cabin Lights (front and rear).

Place the metal backing plate through the hole at an angle. Once on the other side, twist the metal plate back into place so it won't come back through the hole. Plug the power wires back into the light housing. Reattach the housing to the backing plate using the 2 x M6 nuts. Once in place, clip the plastic lens back.



Front Sun Visors

Re-attach the sun visors using the original screws. Hopefully, you would of purchased the Vault Alston sun visors to compliment the new headlining. If you have, your new sun visors come with new screws. Just to let you know, the new sun visors might need the locator bracket adjusted to suit your defender fixing holes.



Rear View Mirror

Re-attach the mirror holder using the original screws. Re-attach the rear view mirror.



STEP THREE: ENJOY

TELL US HOW WE DID!

Email; Sales@vault-classic.com and let us know how things went. Always like to hear feedback from our customers.

Also, if you think we did well, please take two minutes to review our product on the Vault Classic website or Google. You can use the QR code below to go straight to the review page.

