



You'll notice on the camera loom there are a pair of thin white and a green loop wires.

The Green wire is the 'Flip Image' wire. Cutting the Green wire will flip the image from a reverse camera image to a forward facing camera image. The default camera image as supplied is a reverse camera image so this wire should be left intact.

The WHITE wire is for the Parking Lines. If you wish to remove parking lines from the image, cut the White wire.

