

Fold each corner, matching up the finger-pressed line and the side seams. Measure down from the corner 3.75 cm (1½in) and draw a line with chalk perpendicular to the seam. The line should be 7.5 cm (3in) long (1d). Stitch along the line with an overlock stitch on the sewing machine or overlocker, trimming off the corners.