

# retrospec

## EverythingBin Installation Instructions

The following will guide you through the installation of your EverythingBin.

### **Step 1: Basket Placement**

Place the large basket above the rear rack or frame you are mounting to, ensuring proper alignment of the bolt holes with the insertion points on the rear rack or frame. The basket will be positioned perpendicular to the bike. The basket should sit flush to the rack/frame.

### **Step 2: Bolt Installation**

With the bolt holes aligned, insert bolts/washers. Begin finger-tightening each until snugly in place. Utilize a 3mm allen wrench and 10mm wrench; securely tighten each bolt, firmly connecting the rear basket to the rear rack (8Nm max torque).

### **Step 3: Check Fit**

After tightening the last bolt, check that the installation is secure. While insure the bike is secure, grab the basket and try to move it. There should not be any slop. If there is, visually inspect the interface between the rack/frame and the basket. If there is a gap, loosen all bolts and adjust the basket as needed to achieve a flush fit and retighten bolts.