

# Assembly instructions

1. Turn the handle pole out, then use S3 Allen Key to loosen the M6 locking screw, then take down the handle, flange, and rubber washer from the valve body.
2. Pass the valve body through the bathtub hole, and then connect the flange to the valve body.
3. Put the handle on the valve stem (please pay attention direction and position), then use the lock nut to tighten the flange to the valve body.
4. Screw the M6 locking screw to the handle then turn the handle pole in to the handle.
5. Connect the inlet and outlet pipe.

