

STEP 1

Place the washer on the top of the POSTreat



STEP 2

Priming for few minutes



STEP 3

Install POSTreat Steel into upper chamber

Rotate Clockwise



STEP 4

Install the other POSTreat (same as Step 3)



STEP 5

Place the fitted upper chamber over lower chamber



Assembled

