



Bluetooth® Karaoke Microphone with Speaker & Lights

EKM10 Instructions

1. Press and hold the power button to turn on or off the microphone for 2 seconds. When the device is turned on, the blue light will show and flash.
2. For Bluetooth® connection: Open the Bluetooth® setting on your device, scan and select 'EKM10' to connect. An audio prompt will confirm connection. Note the microphone must be turned on to pair.
3. Once paired search for karaoke tracks or your favourite music on the internet through your device. You can also play music files from an TF card input positioned underneath the control panel.
4. Mic volume, Echo effect and Music volume can all be adjusted using the relevant buttons, the blue lights indicate the setting.
5. Long press the 'Mode' button to activate the Voice Changer. There are four voices to choose from; Baby, Female, Male, Scary. Press the mode button once each time to change the voice.
6. Pick your song via your device and sing directly into the microphone head, adjust the settings to find the perfect mix of mic volume, echo and music.
7. The microphone will shut down automatically if not used for five minutes.

Charging instructions

1. When the battery is too low, the microphone will shut down automatically.
2. Using standard USB and adapter cable, two red lights will appear on the front of the EKM10 when charging.

3. The charging time is 3-4 hours and the red lights will disappear once the device is fully charged.
4. Fully charged the EKM10 will give you 8-10 hours playing time.

Technical parameter Output Power: 5W
Maximum pressure level and GT: 115 dB (a)
Battery capacity: 18650 Lithium battery 1200mA
Charging power: DC 5V

Please scan the QR code for the ultimate karaoke experience providing you with thousands of free HD quality karaoke songs direct to your smartphone or tablet using our smart karaoke app.

New songs are added every week so keep logging in to keep your collection up to date.

If you prefer to use a smart TV, laptop, PC or Mac you can go directly to our YouTube channel www.easykaraoke.com



easykaraoke.com

UK DISTRIBUTOR

John Hornby Skewes & Co. Ltd.

Salem House, Parkinson Approach, Garforth,
Leeds LS25 2HR, United Kingdom.

www.jhs.co.uk

Authorised EU Representative: Pieters Musical Agencies
Sparrelaar 19, 5467 JP Veghel, Netherlands

