

# **BOUNCY CASTLE SET-UP AND SAFETY**

## **CARE AND SAFETY**

- Do NOT use in the rain
- Do NOT use on concrete
- Do NOT allow children to climb on the sides of the castle.
- NO shoes
- NO water or detergents or oil
- NO food or drinks to be consumed on castle
- NO jewellery, rings, etc
- NO sharp objects
- NO one over the age of 10 years of age on castle
- Damage to the castle will be charged for

**Adult supervision required at all times**

## **SET UP**

- Lay out the ground sheet and position castle on top
- Unfold (take note of how it is folded for re-packing it later)
- Position the fan blower end into the sock vent and tie off with the Velcro strap
- Tie off the second sock vent with the Velcro strap
- Switch on the fan
- Help the sides of the castle up as it inflates. Inflation takes approx 2 minutes.
- Do NOT cover the air intake of the blower and ensure it doesn't get knocked over.
- Secure the corners of the castle with the 4 pegs provided

## **DISMANTLE**

- Turn off the fan and remove the blower end from the vent sock
- Open both vents as this allows the air to escape
- Fold the deflated castle lengthwise towards the fan sock/vents at the end
- Fold into approx 1 metre sections at a time toward the vents pushing out air as you go.
- Allow time to deflate during the folding process.
- Pack the castle back into the bag
- Please return the castle to us clean and dry and on time as lateness may affect someone else's party.

