


PIXAPRO®

Heavy-Duty Rolling Utility Cart with Handle


User Guide

K-070006


PIXAPRO LTD.
48 Brick Kiln Street, Brierley Hill, West Midlands DY5 1JG
Tel: +44 (0) 121 552 3113
Email: info@essentialphoto.co.uk

Installation instructions


1、Body Frame *1
2、Hanging Board*2
3、Base*1
4、M10*30mm Hexagon Socket Screws *8
5、8mm Allen Key*1




Hanging Board





Base



Body Frame







Maintenance

1. Regularly tighten screws, rivets, screw rods and other connecting parts to ensure the stability and safety of the cart, and promptly replace any parts in bad condition.
2. Please use this product correctly according to the instructions. If the product is damaged, it can be repaired free of charge during the specified warranty period.
3. **Warranty policy:** Under normal circumstances, the warranty is 3 years. For minor problems, spare parts will be free of charge.
   Guidance on replacement, products that cannot be repaired by the client can be arranged to be sent back to the factory for after-sales repair. Product repair or reshipment costs shall be borne by the purchaser.
4. **Please note: Any one of the following conditions is not covered by the warranty.**
   The warranty period has expired;
   Loss caused by failure to use, maintain, and store products in accordance with the requirements of the product instructions;
   Damage and human losses caused by force majeure;