

Cleanview Turbo

1994U

No Power

1. Plug machine into a functioning outlet and try to turn on.
2. If machine does not turn on, unplug machine and test a different device (ex: phone charger) in the same outlet.
3. If outlet doesn't work for different device, test the machine in a different outlet.
4. If the machine still won't turn on, unplug the machine and run palm along entire length of cord. The cord should be smooth and have no punctures or tears.
5. Also inspect outlet prongs on plug for damage. If damage is found on cord or plug, see step 7
6. Is the amp limit on their circuit breaker exceeded?
7. Inform them most homes are set up in zones with several outlets attached each one circuit breaker.



Example shows that all the outlets in each room are

- in an individual zone
 - on a single breaker
- Also, all outlets in both bathrooms are on 1 breaker

This example shows 7 zones attached to 7 different circuit breakers in a house. Each room has several outlets.

- If the total power plugged into those outlets exceeds the breaker when this unit is turned on, it may be tripping the breaker. They may need to find a different outlet in a different zone, or safely unplug/turn off another appliance on that same zone.

If the unit still won't turn on,

BISSELL Consumer Care: please refer to product changeover guide.

External Support: Contact BISSELL