

ReadyClean

40N7, 47B2, 20R7, 40H5 Series

Brush is Not Rotating

IF THE CONSUMER HAS A 47B2 WITH A DATE CODE OF 13301C ONLY, SET UP RA CUT CORD AND ISSUE REPLACEMENT PER RA DEST. GUIDE. DO NOT FOLLOW ANY FURTHER TROUBLESHOOTING

****47B2 and 20R7 Series only****

- 1) **Check the brush ends for debris build-up or broken belt.**
 - a. Turn machine off & unplug from wall outlet.
 - b. Remove solution & collection tanks.
 - c. Lie machine down to access the bottom of the machine.
 - d. With a Phillips head screwdriver, unscrew the belt cover & remove.
 - e. Brush can now be removed.
 - f. Belt can be removed by sliding off the motor pulley.
 - g. Clean or replace brush or belt if necessary. Attach belt to motor pulley & brush, insert brush into right side end cap.
 - h. Reattach the left end cap and slide brush back into place.
 - i. Replace the belt cover & screw into place.
 - j. Manually rotate brush to make sure it rotates freely and that the belt is aligned properly.

