



KV 4 Vibrapad

The KV 4 Vibrapad is the quick, lightweight and cordless way to effortlessly remove dirt and grime from smooth surfaces, making scrubbing by hand a thing of the past.

1 LED Display

- The in-built LED display on the on/off switch tells you when the battery needs to be charged.

3 Easy handling

2 Hygienic


4 Versatile



KV 4 Vibrapad

Technical data		
Order Number		1.633-922.0
EAN code		4054278600024
Container contents: fresh water	ml	180
Battery running time	min.	35
Battery charging time	min.	160
	m/s ²	1,6
Current type	V / Hz	100-240 / 50-60
Weight including battery	kg	0,5
Dimensions (L x W x H)	mm	260 × 94 × 100
Equipment		
Window cleaner concentrate (1 × 20 ml)	■	
Lithium ion battery	■	
Battery charger	■	
		1 x
■ Included in delivery.		

KV 4 VIBRAPAD 1.633-922.0



		Order Number	Quantity				Price	Description	
Power supplies									
WV 1 - WV 5 Window Vac Battery Charger	1	2.633-115.0	1 piece(s)					This battery charger is a suitable replacement, should you misplace your original charger. It is compatible with all Kärcher Window Vacs with the exception of the WV 6.	■
Hip bag									
WV Hip Holster Bag	2	2.633-006.0	1 piece(s)					The WV Hip Holster Bag provides practical storage for your Window Vac and accessories, whilst on the move.	□
Replacement cloths									
KV Cleaning Pads *EU	3	2.633-132.0	2 piece(s)						□
Extensions									
WV Evolution Extension Set	4	2.633-144.0	1 piece(s)					The Window Vac Extension Set is compatible with all WV & KV models, with a 1.5m reach the extension set ensures all those hard to reach areas are cleaned quickly and effectively.	□

■ Included in delivery. □ Available accessories.