

IMPORTANT: How to Handle your Glass Bottom Tank. ♥♥

- To lift the Glass Tank or move it ensure you do the following:
 - Empty the Glass Tank of water by opening the tap and pouring into a bucket (empty to below the tap level).
 - ✓ Remove / lift the Upper Tank from the Glass (bottom) Tank.
 - Remove all Mineral Stones and Silver Stones <u>BEFORE</u> lifting or moving.
- ✓ To lift the empty Glass Tank place your hands around the sides close to the bottom of the Glass Tank, hold firmly, move to position and place down gently (do not drop) especially onto hard surfaces to avoid damage or breakage.
- ✓ Place pre-rinsed Mineral Stones and Silver Stones carefully onto the bottom of the Glass Tank to avoid damaging the Glass Tank. Failure to do so may cause the glass to chip or break and void warranty.
- ✓ The Glass Tank should always be placed onto the zazen base Stand and be on a level stable surface.
- When placing the Upper Tank onto the Glass Bottom Tank ensure the Upper Tank is empty of water.

Helping you ive a longer, healthier



- NEVER LIFT the Glass Tank from the top rim or move the Glass Tank when full of water.
- Do not drop Mineral and Silver Stones into the Glass Bottom Tank this will result in damaging the Glass Tank.
- ! Keep out of reach of small children who may pull the system over and cause the Glass Tank to break
- Do not drop the Glass Tank onto a hard surface, this may break or damage the Glass Tank.



Date


Initial's

INSTALLATION INSTRUCTIONS

Assembling your zazen Alkaline Water System with optional Glass Bottom Tank

- 1 Read Care and Handling of the Glass Tank (over page) before proceeding.
- Place the stand where you will sit vour System.
- 3 Place the Glass Tank gently onto the Stand.
- 4 Place the tap "A" through hole in the bottom tank with a silicon washer "B" on each side. Screw the magnetic back "C" onto tap inside the bottom tank and tighten.
- 5 Gently place pre-soaked Silver Stones and Mineral Stones ONE AT A TIME into the Glass Tank. *If you have Alkalinity Enhancers (AAE) balls sprinkle amongst the stones away from the back of the magnetic tap so they can't get sucked into the back of the tap.
- 6 Screw the Multi-Stage Filter Cartridge into Cartridge Connector and gently sit in the top of the glass tank (filter will hang in bottom tank).
- 7 Place the Silicon Washer* onto the Ceramic Filter stem and then insert the Ceramic Filter into the hole inside the Upper Tank. Fasten on with the Filter Nut* and tighten.
- 8 Gently place the Upper Tank onto the assembled Glass Tank
- 9 Fill Upper Tank with 4 litres of water and pop on the Lid.[^]
- 10 You will have 2 spare parts left over: 1 x BPA Free Bottom Tank & 1 x Middle Rim (not used with the Glass Tank). \heartsuit When you travel on holiday remember to pack your zazen Water System in your car using the BPA Free bottom tank instead of the Glass Tank.

STAND. ^Note: It will take 1½ to 2 hours to filter the 4 litre upper tank into the bottom tank. Do this twice to fill your system. Once the bottom tank is full, you cannot add more water to the upper tank or the system will overflow. *Silicon Washer & Filter Nut come with Ceramic Filter



OUR ONLINE

