

Nakatanenga LED Side Repeater Fitting Instructions

1. Remove the bulb from the factory bulb-holder and insert the printed circuit into the bulb-holder.



2. Insert the bulb-holder into the LED lamp housing and refit the lamp. Easy!

