

Installation Instructions

1. Attach the four adjustable legs (included).
2. Remove the protective plastic film from the panels. If the cabinet stand has been exposed to the sun or to heat, remove the film after the stand cools.
3. Place the stand in a flat and firm site.
4. Adjust the legs to prevent instability.
5. Open the doors.
6. Attach the dispenser to the stand. Secure the dispenser to the stand with the four bolts and washers provided.

Combination: SD-270DCM-270
SD-200DM-200
SD-500DCM-500
SD-750DCM-750

7. Seal the seam all the way around between the dispenser and stand with food grade silicone.

