




OAK BOK EXTENDABLE DINING TABLE ASSEMBLY INSTRUCTION FOR DINING TABLE INSTALLATION

HARDWARES



TOOLS




IN YOUR PACKAGE :

ASSEMBLY INSTRUCTION
HARDWARE (AS LISTED ABOVE)

PARTS TO BE INSTALLED

1. TOP PANEL 1pc
2. LEGS 2pcs
3. LEG 1set




RECOMMENDATION :




In order to avoid colour differences between the fixed table top and the extensions due to UV light, we suggest to put your dining table in extended version during the first month.

SYMBOLS



DIRECTION



NUMBER OF PERSON NEEDED



USE HAND



USE WRENCH TO TIGHTEN




USE SCREWDRIVER



USE TORX ALLEN SCREW



NOTICE




WHEN LIFTING THE TABLE :
- LIFT ONLY ON THE APRON
- MAKE SURE TABLE IS IN UNEXTENDED POSITION

OAK BOK EXTENDABLE DINING TABLE
 ASSEMBLY INSTRUCTION FOR DINING TABLE INSTALLATION





A. INSTALLING THE LEGS TO TABLE TOP



! USE SPAX SCREW M6x80





B. INSTALLING LEG SET TO TABLE TOP





- ! - USE SPAX SCREW M6x120 TO INSTALL LEG METAL CORNERS**
- INSTALL JCBC SCREWS ON RIGHT & LEFT SIDE OF APRON FIRST**
- MIDDLE SCREWS ON APRON ARE INSTALLED AFTER TABLE IS IN STANDING POSITION**

OAK BOK EXTENDABLE DINING TABLE ASSEMBLY INSTRUCTION FOR DINING TABLE INSTALLATION

C. REMOVE WOODEN PIECES





D. INSTALLING SCREW IN THE MIDDLE SIDE




ONE PERSON HOLD THE EXTENSION LEAVES

OAK BOK EXTENDABLE DINING TABLE ASSEMBLY INSTRUCTION FOR DINING TABLE INSTALLATION



E. EXTENDING



NOTE : LOCK AFTER EXTENDING



F. DISMANTLING



NOTE : UNLOCK BEFORE DISMANTLING

