

RT615 Digital Fridge/Freezer Thermometer

Features

- Easy installation
- Large and clear digital display
- Safety zone alert
- °C/°F switchable
- Low battery indication
- Water resistant to IP65
- Powers off when not in use

Specifications

- Range:** -13 to 122°F (-25 to 50°C)
Accuracy: ±1.8°F (±1°C) over full range
Resolution: 0.1° over full range
Reading Update: 10 seconds
Battery: 3 volt lithium, type CR2032 x 1 piece, about 5 years
Display: 2.3" x 0.87" (59mm x 22mm)
IP Rating: IP65
Dimensions: 2.8" x 2.3" x 0.83" (71mm x 59mm x 21mm)

Operation

1. Unpack the thermometer with care.
2. Press [RESET] button once.
3. Peel off protective sheet covering display.
4. Hang the thermometer onto a shelf inside the fridge or freezer or pull down the stand to place the thermometer on a shelf.
5. If the temperature is above 46°F (8°C), then the "*" symbol will flash in the upper right hand corner to indicate that the temperature inside the fridge needs to be adjusted.

Change from °F to °C

1. Unscrew and open the back door.
2. Slide the °C/°F switch to the desired temperature unit.
3. Replace the back cover and tighten the screws. Do not over tighten.

Note

Before opening the back cover for battery replacement or changing temperature unit, let the thermometer warm up to the room temperature otherwise moisture may condense onto the electronics and damage the thermometer.

Auto-Off

Unit powers off with the absence of light for use in fridge or freezer when door is shut to conserve battery life.



ThermoWorks

Utah, U.S.A.
Phone: 801-756-7705
Fax: 801-756-8948
www.thermoworks.com

RT615 Digital
Fridge/Freezer Thermometer



Made in China

