

KARPENTER


Designed by Us Defined by Nature

ASSEMBLING INSTRUCTION

DINING TABLE

Pre Assembly :

- Please read all instructions before beginning assembly
- Place all parts on a carpet or foam in shipping box. Find the letter (A,B,C,...) on each part and check with below part list to ensure we have all components.
- Save all packing materials until assembly is complete to avoid accidentally discarding smaller parts or hardware.
- This cart requires one people to do assembly.



Parts Included :



A - Top - 1 pc	B - Leg - 2 pcs
A line drawing of the rectangular table top, showing a recessed area in the center.	A line drawing of a single table leg, showing its L-shaped profile.

Hardware Enclosed :



aa - Hexagonal Bolt - 8 pcs	bb - Wrench - 1 pc
A line drawing of a hexagonal bolt with a threaded shaft and a hexagonal head.	A line drawing of an open-end wrench.
cc - JCBC Bolt - 4 pcs	dd - Allen Key - 1 pc
A line drawing of a JCBC bolt, which has a hexagonal head with a central hole and a threaded shaft.	A line drawing of an Allen key, showing its L-shaped profile.

Assembly Instructions :

1. Lay all components (A, B, C,...) onto clean smooth surface as carpet or cardboard.
2. Attach Leg (B) to the Top (A). Secured by Hexagonal Bolt (aa) Tighten by using Wrench (bb).



2. Fix Metal Support. Secured by JCBC Bolt (cc). Tighten by using Allen Key (dd)
Turn up the table. Assembly is completed



Care Instructions :

- Hardware may loosen over time. Periodically check to make sure all components are tight. Re-tighten if necessary.
- Dust with soft dry cloth.
- Avoid abrasive cleaners. If a cleaner is needed, use a mild-cleaner spray and blot with an absorbent cloth.
- For indoor use only.