



Flame-Thrower Coil Installation Instructions

Caution: Before performing any work, make sure to disconnect the battery to prevent vehicle damage or accidental electrical shock.

1. Verify that the original coil form factor, mounting type and connector match the new Flame-Thrower coil. Some coils types look similar, but are not interchangeable. Pay special attention to the color of the coil molded connector and pin count.
2. Carefully disconnect the wiring connector at the coil. Connectors have locking tabs that must be depressed prior to removal. Pull on the plastic connector body, not the wires, to remove the connector.
3. Remove any bolts that may be securing the coil and remove the coil.
4. Apply a small amount of dielectric grease to the coil boot.
5. Install the Flame-Thrower coil. Press down on the coil body to insure the coil fully engages with the spark plug.
6. Tighten the coil bolt(s) to the factory torque specification. Some coils include captive bolts, while others reuse the factory bolts.
7. Plug in the coil wiring connector.

LIMITED WARRANTY

PerTronix, LLC. warrants to the original Purchaser of its Flame-Thrower products that the product shall be free from defects in material and workmanship (normal wear and tear excluded) for a period of 90 days from the date of purchase.

If within the period of the foregoing warranty PerTronix finds, after inspection, that the product or any component thereof is defective, PerTronix will, at its option, repair such products or component or replace them with identical or similar parts PROVIDED that within such period Purchaser:

1. Promptly notifies PerTronix, in writing, of such defects.
2. Delivers the defective products product or component to PerTronix (Attn: Warranty) with proof of purchase date; and
3. Has installed and used the product in a normal and proper manner, consistent with PerTronix printed instructions

THE FOREGOING LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY OR MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

THE FURNISHING OF A REPAIR OR REPLACEMENT COMPONENT OR COMPONENTS SHALL CONSTITUTE THE SOLE REMEDY OF PURCHASER AND THE SOLE LIABILITY OF PerTronix WHETHER ON WARRANTY, CONTRACT OR FOR NEGLIGENCE, AND IN NO EVENT WILL PerTronix BE LIABLE FOR MONEY DAMAGES WHETHER DIRECT OR CONSEQUENTIAL.



Flame-Thrower Coil Installation Instructions

Caution: Before performing any work, make sure to disconnect the battery to prevent vehicle damage or accidental electrical shock.

1. Verify that the original coil form factor, mounting type and connector match the new Flame-Thrower coil. Some coils types look similar, but are not interchangeable. Pay special attention to the color of the coil molded connector and pin count.
2. Carefully disconnect the wiring connector at the coil. Connectors have locking tabs that must be depressed prior to removal. Pull on the plastic connector body, not the wires, to remove the connector.
3. Remove any bolts that may be securing the coil and remove the coil.
4. Apply a small amount of dielectric grease to the coil boot.
5. Install the Flame-Thrower coil. Press down on the coil body to insure the coil fully engages with the spark plug.
6. Tighten the coil bolt(s) to the factory torque specification. Some coils include captive bolts, while others reuse the factory bolts.
7. Plug in the coil wiring connector.

LIMITED WARRANTY

PerTronix, LLC. warrants to the original Purchaser of its Flame-Thrower products that the product shall be free from defects in material and workmanship (normal wear and tear excluded) for a period of 90 days from the date of purchase.

If within the period of the foregoing warranty PerTronix finds, after inspection, that the product or any component thereof is defective, PerTronix will, at its option, repair such products or component or replace them with identical or similar parts PROVIDED that within such period Purchaser:

1. Promptly notifies PerTronix, in writing, of such defects.
2. Delivers the defective products product or component to PerTronix (Attn: Warranty) with proof of purchase date; and
3. Has installed and used the product in a normal and proper manner, consistent with PerTronix printed instructions

THE FOREGOING LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY OR MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

THE FURNISHING OF A REPAIR OR REPLACEMENT COMPONENT OR COMPONENTS SHALL CONSTITUTE THE SOLE REMEDY OF PURCHASER AND THE SOLE LIABILITY OF PerTronix WHETHER ON WARRANTY, CONTRACT OR FOR NEGLIGENCE, AND IN NO EVENT WILL PerTronix BE LIABLE FOR MONEY DAMAGES WHETHER DIRECT OR CONSEQUENTIAL.

