

## ONLINE MANUAL



Need more help? Scan here to view the manual for more information.

You can also type the following link in a web browser:

[www.etekcity.com/support/manual/model/ek4150](http://www.etekcity.com/support/manual/model/ek4150)

## WARRANTY



Etekcity Corporation warrants all products to be of the highest quality in material, craftsmanship, and service, effective from the date of purchase to the end of the warranty period. Warranty lengths may vary between product categories.

Scan the QR code to register your product and extend your 1-year warranty by an additional year.

## CUSTOMER SUPPORT

**Etekcity Corporation**  
1202 N. Miller St., Suite A  
Anaheim, CA 92806

**Support Hours**  
Monday-Friday  
9:00 am-5:00 pm PST/PDT

**Email:** [support@etekcity.com](mailto:support@etekcity.com)  
**Toll-Free:** (855) 686-3835

\*Please have your invoice and order ID ready before contacting Customer Support.



**Digital Kitchen Scale**  
EK4150

## QUICK START GUIDE

### SPECIFICATIONS


<b>Weight Capacity</b>	176 oz / 11 lb / 5000 g / 5 kg
<b>Bowl Capacity</b>	2.06 qt / 1.96 L
<b>Increments</b>	0.1 oz / 1 g / 0.5°F
<b>Weight Units</b>	oz / lb / g / kg
<b>Temperature Range</b>	32°-104°F
<b>Timer</b>	99 minutes, 59 seconds
<b>Battery</b>	2 x 1.5V AAA batteries
<b>Auto-Off</b>	2 minutes
<b>Material</b>	Stainless steel

## DIGITAL DISPLAY




- A.** Timer
- B.** Temperature
- C.** Measurement Unit
- D.** Timer Set
- E.** Tare Function
- F.** Negative Weight Value
- G.** Zero Function
- H.** Weight Measurement

## FUNCTION DIAGRAM



Bottom



- |  |                               |
|--|-------------------------------|
| <b>A.</b> Stainless Steel Bowl               | <b>E.</b> Digital Display     |
| <b>B.</b> Digital Scale                      | <b>F.</b> On/Off              |
| <b>C.</b> Tare / Increase Timer              | <b>G.</b> Set Timer           |
| <b>D.</b> Unit Selection /<br>Decrease Timer | <b>H.</b> Battery Compartment |
|  | <b>I.</b> Anti-Skid Padding   |

## USING YOUR SCALE

**Note:** Before first use, remove plastic strip from battery compartment.

1. Press **ON/OFF** to turn on the scale. To turn it off, press the **ON/OFF** button again.
2. The scale will display "**0**" when it is ready for use. If it does not display "**0**" press **▲ Z/T** to reset the scale.
3. Timer Function:
  - a. When the scale is on, press **T-SET** .
  - b. Use **▲** and **▼** to set the desired time.
  - c. Press **T-SET** to confirm the selection for each time. Once you've set the desired time, press **T-SET** again to confirm and activate the timer alarm. When the time reaches "**00:00**" the digital scale will sound an alarm for 70 seconds unless otherwise deactivated.
  - d. To deactivate at any time, press **T-SET**.
4. To change the unit of measurement, press **UNIT** until the desired unit is displayed.

**Note:** Keep the scale away from water, liquid, or damp areas. If liquid is spilled on the scale, immediately wipe dry with a soft cloth to avoid damage.